



FOODI™ SMART XL PRO AIR OVEN OWNER'S GUIDE

It's important to read this instructions prior to using your new product for the first time.

Recipe book is not included

804106669A

IMPORTANT SAFEGUARDS

HOUSEHOLD USE ONLY • READ ALL INSTRUCTIONS BEFORE USE

When using electrical appliances, basic safety precautions should always be followed, including the following:

WARNING


- Read all instructions prior to using the oven and its accessories.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- If food contents were to catch fire during cooking, **DO NOT** open the oven door.
 - If you can safely do so, unplug the oven immediately.
 - DO NOT** throw water onto the fire. Food contents may contain grease and water may cause fire growth.
 - If fire were to emit from the oven door, call the fire department immediately.
 - DO NOT** use the oven after it has experienced a fire, it may have been damaged and present a risk of fire or shock.
- To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- Take inventory of all contents to ensure you have all parts needed to properly and safely operate your oven.
- DO NOT** use an extension cord. A short power-supply cord is used to reduce the risk of children grabbing the cord or becoming entangled and to reduce the risk of people tripping over a longer cord.
- NEVER** use outlet below counter level.
- Keep the appliance and its cord out of reach of children. Do not allow the appliance to be used by children. Close supervision is necessary when used near children.
- DO NOT** let cord hang over edges of tables or counters or touch hot surfaces, including stoves and other heating ovens.
- NEVER** leave the oven unattended while in use.
- DO NOT** place any object directly onto the heating elements and **DO NOT** cover crumb tray or any part of the oven with aluminum foil. This will cause the oven to overheat or cause a fire.
- DO NOT** use the oven with the crumb tray incorrectly installed. Crumb tray **MUST** be placed below lower heating elements.
- To protect against electrical shock **DO NOT** immerse cord, plugs, or main unit housing in water or other liquid.
- DO NOT** use the oven with damage to the power cord or plug. Regularly inspect the oven and power cord. If the oven malfunctions or has been damaged in any way, immediately stop use and call a Service Center.
- DO NOT** cover the air intake vents or air outlet vents while unit is operating. Doing so will prevent even cooking and may damage the unit or cause it to overheat.
- DO NOT** insert anything in the ventilation slots and do not obstruct them.
- DO NOT** place items on top of surface while unit is operating except for authorized recommended Ninja accessories.
- Before placing any accessories into the oven ensure they are clean and dry.
- Intended for countertop use only. **DO NOT** place the oven near the edge of a countertop, or on or near a hot gas or electric burner. Ensure the surface is level, clean and dry.
- This oven is for household use only. **DO NOT** use this oven for anything other than its intended use. Misuse may cause injury.
- DO NOT** store any materials, other than supplied accessories, in this oven when not in use.
- DO NOT** use outdoors. **DO NOT** use in moving vehicles or boats.
- DO NOT** use accessory and attachments not recommended or sold by SharkNinja.
- When using this oven, provide adequate space (at least 1 inch above and on all sides) for air circulation.
- A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, or the like when in operation. **DO NOT** place anything on the oven during operation.
- This oven has a tempered glass door and is more resistant to breakage. Avoid scratching door surface or nicking edges.
- DO NOT** place anything directly on heating elements and **DO NOT** use the oven without a wire rack or air fry basket installed.
- DO NOT** spray any type of aerosol spray or flavoring inside the oven while cooking.
- Use caution when inserting and removing anything from the oven, especially when hot.
- Outlet voltages can vary, affecting the performance of your product. To prevent possible illness, use a thermometer to check that your food is cooked to the temperatures recommended.
- Prevent food contact with heating elements. Excessive food loads may cause personal injury or property damage or affect the safe use of the oven.
- Over-size foods or metal utensils **MUST NOT** be inserted in a toaster oven, as they may create a fire or risk of electric shock.
- With the exception of parchment paper, **DO NOT** place any of the following materials in the oven: paper, cardboard, plastic, roasting bags and the like.
- Extreme caution should be exercised when using containers constructed of any materials other than metal or glass.
- DO NOT** touch hot surfaces. Oven surfaces and glass door are hot during and after operation. To prevent burns or personal injury, **ALWAYS** use protective hot pads or insulated oven mitts and use available handles.
- Spilled food can cause serious burns. Extreme caution must be used when the oven contains hot food. Improper use may result in personal injury.
- Please refer to the Cleaning & Maintenance section for regular maintenance of the oven.
- Cleaning and user maintenance shall not be done by children.
- Allow to cool completely before cleaning and moving for storage.
- When not in use, turn any control to 'off', then unplug. Grasp the plug by the body and pull from the outlet. **NEVER** unplug by grasping and pulling flexible cord.
- DO NOT** clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, causing a risk of electrical shock.
- DO NOT** use the oven as a source of heat or for drying
- This appliance has important markings on the plug blade. The entire supply cord is not suitable for replacement. If damaged, please contact a Service Center.
- To prevent possible illness, **ALWAYS** use an external food thermometer to check that your food is cooked to the recommended temperatures.
- DO NOT** place hands near thermometer or cord when in use to prevent burning or scalding. Thermometer will be hot. Use either oven mitts or tongs to remove thermometer from food and unit.
- The thermometer **DOES NOT** replace an external food thermometer. Use external food thermometer to check that food is cooked to recommended temperatures.

- Indicates the presence of a hazard that can cause personal injury, death or substantial property damage if the warning included with this symbol is ignored.
- Take care to avoid contact with hot surface. Always use hand protection to avoid burns.
- For indoor and household use only.

SAVE THESE INSTRUCTIONS

PARTS

- A** Main Unit (attached power cord not shown)
- B** Air Fry Basket
- C** Roast Tray
- D** Sheet Pan(s)
- E** 2 Wire Racks
- G** Foodi™ Smart Thermometer
- F** Removable Crumb Tray (already installed in unit)




IMPORTANT: Place crumb tray below lower heating elements. **DO NOT** slide into any rack positions.

COMMON-SENSE PRACTICES/GOOD HABITS:

- DO NOT** leave your toaster oven unattended while making food. If possible, unplug the oven while not in use to eliminate the possibility of accidents occurring.
- Have a fire extinguisher or fire containment blanket handy in a safe, known location. If you don't have a fire extinguisher, douse the flames with baking soda until they are put out.
- If a fire occurs and the food in the oven is not greasy, immediately unplug the unit and douse the flames with water until the fire is extinguished. **DO NOT** use water if grease is present, since it could make the fire worse. Use baking soda instead.

NOTE: Accessories may vary depending on the model. Refer to quick guide, if available.

ACCESSORY PLACEMENT



The oven has 4 available rack positions where your accessories can slide into the unit (see image above). When you select a function, the corresponding rack number(s) will illuminate on the control panel. The numbers on the control panel (see Fig. 1) will coincide with those on the interior of the unit.


BEFORE FIRST USE

- Remove and discard any packaging material.
- Remove all accessories from the package and read this manual carefully. Please pay particular attention to operational instructions, warnings, and important safeguards to avoid any injury or property damage.
- Wash the air fry basket, sheet pan, wire rack, roast tray, and removable crumb tray in warm, soapy water, then rinse and dry thoroughly. **DO NOT** put sheet pan, roast tray, or removable crumb tray in the dishwasher. Finishes may degrade. **NEVER** submerge the main unit in water.

We recommend placing all accessories inside the oven and running it on Air Roast at 450°F for 20 minutes without adding food. This removes any residues. This is completely safe and not detrimental to the performance of the oven.

NOTE: The accessories are hand-wash recommended. The air fry basket and wire racks can be put in the dishwasher, but may wear more quickly over time

USING THE CONTROL PANEL



FUNCTIONS

- WHOLE ROAST:** Simultaneously roast larger proteins, like a 5-lb chicken, and sides for a complete meal. Or cook a larger protein, like a 12-lb turkey, on its own.
- AIR ROAST:** Achieve a crispy outside and perfectly cooked inside for full-sized sheet pan meals, thicker proteins, and roasted veggies.
- AIR FRY:** Foods that would traditionally be fried—such as chicken wings, French fries, and chicken nuggets—with little to no added oil.
- BAKE:** Evenly bake everything from your favorite cookies to cakes.
- DEHYDRATE:** Dehydrate meats, fruits, and vegetables for healthy snacks.
- BROIL:** Evenly broil meats, fish and brown the tops of casseroles.
- TOAST:** Toast up to 9 slices of bread to your desired level of darkness.
- BAGEL:** Perfectly toast up to 9 bagel halves when they're placed cut-side up on the wire rack.
- PIZZA:** Cook frozen or homemade pizzas evenly.
- REHEAT:** Heat leftovers without over cooking.

NOTE: The oven's technology leads to faster cooking. Always monitor your food to prevent over cooking. On convection functions Whole Roast, Air Roast, and Air Fry, time by 30% and temperature by 25°F (14°C).

THERMOMETER MODE DISPLAY

- A. (Thermometer):** Illuminates when thermometer mode is enabled by plugging in the thermometer then pressing the PRESET or MANUAL button.
- B. DONENESS display:** Shows the different doneness levels when in thermometer mode. Press the TEMP/SHADE +/- buttons to select doneness. (Some models apply)
- C. TARGET:** Illuminates when using thermometer to show target temperature.
- D. CURRENT:** Illuminates when using thermometer to show current temperature of thermometer.

CONTROL PANEL DISPLAY & OPERATING BUTTONS

- (Power) button:** Press to turn the unit on and off.
- PREHEAT:** Flashes when the unit is preheating.
- SLICES:** Illuminates when using the Toast or Bagel function to designate number of slices.
- Time display:** Shows the cook time. The time will count down when cooking is in progress.

The image shown here is for illustrative purposes only and may be subject to change. The actual descriptions of control panel and their locations may vary, depending on the model.

USING YOUR FOODI™ SMART XL PRO AIR OVEN

USING THE FOODI SMART THERMOMETER

Before First Use

Make sure the thermometer jack is free of any residue and the cord is free of knots before plugging it into the jack.

- Remove the thermometer from storage. Then unwind the cord from the cord wrap to remove the thermometer on the right side of the unit.
- Plug the thermometer into the jack. Push firmly on the plug until it cannot go into the jack any further and you hear the plug click into place.
- The thermometer icon on the display will illuminate once the thermometer is plugged in and the thermometer mode is enabled by pressing the PRESET or MANUAL button. Select the desired cook function (e.g., Whole Roast) and change cook temperature accordingly.

NOTE: There is no need to set a cook time, as the unit will automatically turn off the heating element and alert you when your food has finished cooking.

- Press PRESET and use the FUNCTION +/- buttons to select your desired food type and the TEMP +/- buttons to set the internal doneness of your food (Rare through Well).

FOOD TYPE:	PRESET DONENESS TO:
Fish	Medium Rare (120°F)
	Medium (130°F)
	Medium Well (140°F)
	Well Done (150°F)
Chicken/Turkey	Well Done (165°F)
Pork	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (150°F)
	Well Done (160°F)

Beef/Lamb	Rare (120°F)
	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (145°F)
	Well Done (155°F)

NOTE: Default Preset doneness is automatically set to medium.

If selecting the MANUAL button, use the below recommended internal cook temperatures.

FOOD TYPE:	PRESET DONENESS TO:
Fish	Medium Rare (120°F)
	Medium (130°F)
	Medium Well (140°F)
	Well Done (150°F)
Chicken/Turkey	Well Done (165°F)
Pork	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (150°F)
	Well Done (160°F)
Beef/Lamb	Rare (120°F)
	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (145°F)
	Well Done (155°F)

- Place the accessory required for your selected cook function in the unit and close the hood. Press START/STOP to begin preheating.
- While the unit is preheating, insert the thermometer horizontally into the center of the thickest part of the piece of protein. Refer to the following chart for further thermometer placement instructions.
- When the unit has preheated and the unit beeps, open the door, place food with inserted thermometer in the unit, and close the door over the thermometer cord.

5 Temperature display: Shows the cook temperature.

NOTE: Time and temperature will always return to the settings used the last time the oven was in operation.

6 SHADE: Illuminates when using the Toast or Bagel function to designate desired shade.

7 RACK LEVEL: Depending on the function you choose, the illuminated rack level(s) will indicate where your accessory should be placed in the unit.

8 2 LEVEL: For functions that allow you to cook on 2 levels, press the button to select two level cooking and rack levels will update.

9 (Light) button: Press to turn the oven's interior light on and off while cooking.

NOTE: The light will automatically turn on when 1 minute of cook time remains and when door is open while cooking.

10 FUNCTION/FOOD TYPE +/- buttons: To select a cook function, press the FUNCTION +/- buttons.

NOTE: As you move through functions, you'll notice the rack level recommendations change for best results.

11 TIME/SLICES +/- buttons: To select a cook time, press the TIME +/- buttons. When using the Toast or Bagel function, these buttons will adjust the number of slices/bagel halves instead of the time. Time will increase in 1-minute increments over 1 hour and 5-minute increments over 1 hour. Hold the +/- buttons for 2 seconds to activate faster scrolling in 5-minute increments.

12 TEMP/SHADE +/- buttons: To adjust temperature, press the TEMP +/- buttons. When using the Toast or Bagel function, these buttons will adjust the shade level (1, lightest - 7, darkest) instead of the temperature. Temperature will increase in 5-degree increments. Hold the +/- buttons for 2 seconds to activate faster scrolling in 10-degree increments.

NOTE: The cook time and temperature may be adjusted at any time during the cooking cycle.


13 START/STOP button: Press to start or stop cooking.

14 PRESET button: Switches the display screen so you can set the thermometer, food type, and internal doneness based on the preset temperatures.

15 MANUAL button: Switches the display screen so you can manually set the thermometer internal doneness.

16 Foodi™ Smart Thermometer plugs in here as shown in the image above.

***17 DONENESS button:** Press to switch the display to the internal doneness settings for the thermometer. The display will show the different doneness levels. Press DONENESS repeatedly to toggle through the doneness levels. DONENESS can only be selected if a food type has previously been selected with the PRESET button. (Some models apply)



8 The display will show the current thermometer temperature and target thermometer temperature to show progress. Press PRESET or MANUAL to view the oven temperature and time since start of cook.

9 The unit will automatically stop when thermometer temperature has reached the target. Display will beep and show "COOK END".

10 Transfer protein to a plate and allow to rest for 5 minutes before serving.

NOTE: The thermometer will be HOT, wait for the thermometer to cool before cleaning and storing. Use either oven mitts or tongs to take the thermometer out of the protein.

HOW TO CORRECTLY INSERT THE THERMOMETER

FOOD TYPE	PLACEMENT	CORRECT	INCORRECT
Tenderloins Fish fillets Whole fish Prime rib Lamb rack Brisket Pork Shoulder Pork Loin Chuck Roast	<ul style="list-style-type: none"> Insert thermometer horizontally into the center of the thickest part of the meat. Make sure the tip of the thermometer is inserted straight into the center of the meat, not angled toward the bottom or top of it. Make sure the thermometer is close to (but not touching) the bone and away from any fat or gristle. 		
Whole chicken	<ul style="list-style-type: none"> Insert thermometer horizontally into the thickest part of the breast, parallel to, but not touching, the bone. Make sure the tip reaches the center of the thickest part of the breast and doesn't go all the way through the breast into the cavity. 		

NOTE: DO NOT use the thermometer with frozen protein or for cuts of meat 1 inch thick or thinner.

Indicates to read and review instructions to understand operation and use of product.

