

NINJA

"Recipe book not included"





NINJA SIZZLE™ GRILL

814100161



IMPORTANT SAFETY INSTRUCTIONS

INDOOR HOUSEHOLD USE ONLY. READ ALL INSTRUCTIONS BEFORE USE

	Read and review instructions to understand operation and use of product.
	Indicates the presence of a hazard that can cause personal injury, death or substantial property damage if the warning included with this symbol is ignored.
	Avoid contact with hot surface. Always use hand protection to avoid burns.
	For indoor and household use only.


⚠ WARNING To reduce the risk of injury, fire, electrical shock or property damage, basic safety precautions must always be followed, including the following numbered warnings and subsequent instructions. Do not use appliance for other than intended use.

- 1 To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- 2 This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 3 Keep the appliance and its cord out of reach of children. **DO NOT** allow the appliance to be used by children. Close supervision is necessary when used near children.
- 4 This appliance is for household use only. **DO NOT** use this appliance for anything other than its intended use. **DO NOT** use in moving vehicles or boats. **DO NOT** use outdoors. Misuse may cause injury.
- 5 To reduce the risk of fire, **DO NOT** place on or near a hot gas or electric burner or in a heated oven.
- 6 Ensure the surface is level, clean and dry. **DO NOT** place the appliance near the edge of a countertop during operation.
- 7 **ALWAYS** ensure the appliance is properly assembled before use. **DO NOT** place appliance on or near a gas oven or electric stovetop, or in a heated oven.
- 8 When using this appliance, provide at least 6 inches (15.25 cm) of space above and on all sides for air circulation.
- 9 **DO NOT** use an extension cord. A short power-supply cord is used to reduce the risk of children grabbing the cord or becoming entangled and to reduce the risk of people tripping over a longer cord.
- 10 To protect against electrical shock **DO NOT** immerse cord, plugs, or main unit housing in water or other liquid.
- 11 **DO NOT** use the appliance if there is damage to the power cord or plug. Regularly inspect the appliance and power cord. If the appliance malfunctions or has been damaged in any way, immediately stop use and contact a service center.
- 12 **NEVER** use outlet below countertop surface.
- 13 **DO NOT** place appliance and let cord hang over edges of tables, counters or touch hot surfaces.
- 14 Only use recommended accessories included with this appliance or authorized by SharkNinja. The use of accessories or attachments not recommended by SharkNinja may cause a risk of fire or injury.
- 15 Before placing any accessory into the cooker, ensure they are clean and dry.
- 16 **DO NOT** move the appliance when in use.

-
- 17 **DO NOT** touch hot surfaces. Appliance surfaces are hot during and after operation. To prevent burns or personal injury, **ALWAYS** use protective hot pads or insulated oven mitts and use available handles and knobs.
 - 18 **DO NOT** touch accessories during or immediately after cooking. The grill grate becomes extremely hot during the cooking process. Avoid physical contact while removing the accessory from the appliance. To prevent burns or personal injury **ALWAYS** use care when interfacing with product. Recommend use of long-handled utensil and protective hot pads or insulated oven mitts.
 - 19 **DO NOT** use this appliance for deep-frying.
 - 20 To prevent possible illness, **ALWAYS** use an external food thermometer to check that your food is cooked to the recommended temperatures.
 - 21 Should a grease fire occur or the unit emits black smoke, unplug immediately. Wait for smoking to stop before removing any cooking accessories.
 - 22 Please refer to the Cleaning & Maintenance section for regular maintenance of the appliance.
 - 23 To disconnect, turn unit to "OFF," then unplug from socket when not in use and before cleaning.
 - 24 Allow to cool before cleaning, disassembling, putting in or taking off parts, or storing.
 - 25 **DO NOT** clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
 - 26 Cleaning and user maintenance shall not be done by children.
 - 27 Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

SAVE THESE INSTRUCTIONS.

GETTING TO KNOW THE NINJA SIZZLE™ GRILL



NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

Accessory type and quantity may vary depending on the model.

BEFORE FIRST USE

- 1 Remove and discard any packaging material from the unit.
- 2 Remove all accessories from the package and carefully read the manual before use. Please pay particular attention to operational instructions, warnings, and important safeguards to avoid any injury or property damage.
- 3 Wash the grill with a damp, soapy cloth, then wipe with a clean, damp cloth and dry thoroughly. **NEVER** submerge the main unit in water.
- 4 We recommend turning the unit on and running it on 400°F for 10 minutes without adding food. Make sure the area is well ventilated. This removes any packaging residue and odor traces that may be present. This is completely safe and not detrimental to the performance of the grill.

HOW TO HAVE A VIRTUALLY SMOKE-FREE EXPERIENCE

Always use the recommended grill settings. Our chef-designed temperature settings maximize grill flavors and textures while minimizing smoke.

325°F	375°F	400°F	500°F
When using thicker barbecue sauces Burgers	Frozen meats Marinated proteins or proteins with sauce Bacon Steaks Chicken Salmon	Hotdogs Pancakes Fried eggs Grilled cheese	Veggies Fruit Fresh/Frozen seafood

If using oil or fat during the cooking process, we recommend using oils with high smoke points. For best results, Canola, Refined Coconut, Avocado, Vegetable, or Grapeseed oils are recommended. Olive Oil, Butter, Margarine, or aerosol cooking sprays are NOT recommended.

COOKING WITH THE NINJA SIZZLE™ GRILL

- 1 To install the grill, position it over the base with the grease trap toward the front. Place the cooking grate down ensuring the sides align with the exterior of the base.
- 2 Make sure the unit is plugged in, then turn the dial to the desired temperature. The power indicator light will illuminate.
- 3 Allow the grill to preheat with the lid closed for 7 minutes before cooking.
- 4 When preheat is complete, open the lid and place ingredients on the grill grate.
- 5 Once ingredients are cooked to the desired doneness, remove from the grill and turn the dial until it clicks into the "OFF" position. The power indicator light will turn off.
- 6 To remove the grill for cleaning, ensure the dial is in the "OFF" position, and the unit is unplugged and has had sufficient time to cool. Open the lid and lift the cooking grate straight up by grabbing the vertical walls along the edge of the cooking surface.

NOTE: Ninja Sizzle Grill can be used with the lid open or closed.

INSTALLING AND REMOVING THE SPLATTER LID

- 1 After allowing the unit to cool, remove the lid by opening it until it is approximately vertical (**Figure 1**). Then lift the lid straight up out of the hinge base.
- 2 To install the lid, hold it vertically with the handle facing up and the hinge pivots over the hinge base (**Figure 2**). Ensure that the flat sections of the hinge pivots are oriented vertically (**Figure 3**). Lower the lid hinge pivots into the hinge base, then close the lid.




Figure 1




Figure 2




Figure 3

CLEANING YOUR GRILL

The unit should be cleaned thoroughly after each use. Always let the appliance cool before cleaning.

1 Unplug the unit from the wall outlet before cleaning. Keep the lid open after removing your food to allow the unit to cool quicker.

2. To prolong the nonstick coating of the grill, we recommend hand-washing in warm, soapy water then air or towel-drying all parts. The splatter lid is dishwasher safe.

3 If food residue or grease is stuck on the grill grate, splatter lid, or any other removable part, soak in warm, soapy water before cleaning.

4 To clean the base heating unit of the grill, use a damp, soapy cloth, then wipe with a clean, damp cloth and dry thoroughly.

NOTE: NEVER use abrasive tools or cleaners. **NEVER** immerse the main unit in water or any other liquid. Do not place in dishwasher.

TROUBLESHOOTING GUIDE

- **Why is the unit emitting smoke?**

When using the Grill function, always select the recommended temperature setting. Make sure the splatter shield is installed.

- **Why did a circuit breaker trip while using the unit?**

The unit uses 1450 watts of power, so it must be plugged into an outlet on a 15-amp circuit breaker. Using an outlet on a 10-amp breaker will cause the breaker to trip. It is also important that the unit be the only appliance plugged into an outlet when in use. To avoid tripping a breaker, make sure the unit is the only appliance plugged into an outlet on a 15-amp breaker.

TECHNICAL SPECIFICATIONS

Voltage: 120V~, 60Hz

Watts: 1450W

PRINTED IN MEXICO

Elbrd:J.M SC: 12.21.2023

OBPN: GR100Series_IB_MP_Mv11_230515

SHDML: GR100_15_B

814100161

