

NINJA



**RECIPE BOOK
NOT INCLUDED**

**FOODI® DOUBLE OVEN
Owner's Guide**

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USE • FOR HOUSEHOLD USE ONLY

- Read and review instructions to understand operation and use of product.
- Indicates the presence of a hazard that can cause personal injury, death or substantial property damage if the warning included with this symbol is ignored.
- Avoid contact with hot surface. Always use hand protection to avoid burns.
- For indoor and household use only.

WARNING

To reduce the risk of injury, fire, electrical shock or property damage, basic safety precautions must always be followed, including the following numbered warnings and subsequent instructions. Do not use appliance for other than intended use.


- 1 To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- 2 Take inventory of all contents to ensure you have all parts needed to properly and safely operate your oven.
- 3 This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 4 To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- 5 **DO NOT** use an extension cord. A short power-supply cord is used to reduce the risk of children grabbing the cord or becoming entangled and to reduce the risk of people tripping over a longer cord.
- 6 **NEVER** use outlet below counter level.
- 7 Keep the appliance and its cord out of reach of children. **DO NOT** allow the appliance to be used by children. Close supervision is necessary when used near children.
- 8 **DO NOT** let cord hang over edges of tables or counters or touch hot surfaces, including stoves and other heating ovens.
- 9 **NEVER** leave the oven unattended while in use.
- 10 If food contents were to catch fire during cooking, **DO NOT** open the oven door.
 - If you can safely do so, unplug the oven immediately.
 - **DO NOT** throw water onto the fire. Food contents may contain grease and water may cause fire growth.
 - If fire were to emit from the oven door, call the fire department immediately.
 - **DO NOT** use the oven after it has experienced a fire, it may have been damaged and present a risk of fire or shock.
- 11 **DO NOT** place any object directly onto the heating elements. **DO NOT** cover the crumb tray, heating elements, or walls of oven. This will cause the oven to overheat or cause a fire.
- 12 **DO NOT** use the oven with crumb tray incorrectly installed. Crumb tray **MUST** be placed below lower heating elements.
- 13 To protect against electrical shock **DO NOT** immerse cord, plugs, or main unit housing in water or other liquid.
- 14 **DO NOT** place appliance on hot surfaces, near a hot gas or electric burner, in a heated oven, or on a stovetop.
- 15 **DO NOT** use the oven with damage to the power cord or plug. Regularly inspect the oven and power cord. If the oven malfunctions or has been damaged in any way, immediately stop use and call Customer Service.
- 16 **DO NOT** cover the air intake vents or air outlet vents while unit is operating. Doing so will prevent even cooking and may damage the unit or cause it to overheat.
- 17 **DO NOT** insert anything in the ventilation slots and do not obstruct them.
- 18 **DO NOT** place items on top of surface while unit is operating except for authorized recommended Ninja® accessories.
- 19 Before placing any accessories into the oven ensure they are clean and dry.
- 20 Intended for countertop use only. **DO NOT** place the oven near the edge of the countertop. Ensure the surface is level, clean and dry.
- 21 This oven is for household use only. **DO NOT** use this oven for anything other than its intended use. Misuse may cause injury.
- 22 **DO NOT** store any materials, other than supplied accessories, in this oven when not in use.
- 23 **DO NOT** use outdoors. **DO NOT** use in moving vehicles or boats.
- 24 **DO NOT** use accessory and attachments not recommended or sold by SharkNinja.
- 25 When using this oven, provide adequate space (at least 1 inch above and on all sides) for air circulation.
- 26 A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, or the like when in operation.
- 27 This oven has a tempered glass door and is more resistant to breakage. Avoid scratching door surface or nicking edges.
- 28 **DO NOT** place anything directly on heating elements and **DO NOT** use the oven without a wire rack or air fry basket installed.
- 29 **DO NOT** spray any type of aerosol spray or flavoring inside the oven while cooking.
- 30 Use caution when inserting and removing anything from the oven, especially when hot.
- 31 Outlet voltages can vary, affecting the performance of your product. To prevent possible illness, use a thermometer to check that your food is cooked to the temperatures recommended.
- 32 Prevent food contact with heating elements. Excessive food loads may cause personal injury or property damage or affect the safe use of the oven.
- 33 Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- 34 With the exception of parchment paper, **DO NOT** place any of the following materials in the oven: paper, cardboard, plastic, roasting bags and the like.
- 35 Extreme caution should be exercised when using containers constructed of any materials other than metal or glass.
- 36 **DO NOT** touch hot surfaces. Oven surfaces and glass door are hot during and after operation. To prevent burns or personal injury, **ALWAYS** use protective hot pads or insulated oven mitts and use available handles.
- 37 Spilled food can cause serious burns. Extreme caution must be used when the oven contains hot food. Improper use may result in personal injury.
- 38 Please refer to the Cleaning & Maintenance section for regular maintenance of the oven.
- 39 Cleaning and user maintenance shall not be done by children.
- 40 Allow to cool completely before cleaning and moving for storage.
- 41 When not in use, press the Power Button to turn the unit off, then unplug. Grasp the plug by the body and pull from the outlet. **NEVER** unplug by grasping and pulling flexible cord.

- 42 **DO NOT** clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, causing a risk of electrical shock.
- 43 **DO NOT** use the oven as a source of heat or for drying.
- 44 This appliance has important markings on the plug blade. The entire supply cord is not suitable for replacement. If damaged, please contact a service center.
- 45 To prevent possible illness, **ALWAYS** use an external food thermometer to check that your food is cooked to the recommended temperatures.
- 46 **DO NOT** place hands near thermometer or cord when in use to prevent burning or scalding. Thermometer will be hot. Use either oven mitts or tongs to remove thermometer from food and unit.
- 47 The thermometer **DOES NOT** replace an external food thermometer. Use external food thermometer to check that food is cooked to recommended temperatures.

SAVE THESE INSTRUCTIONS


PARTS & ACCESSORIES

- A Main Unit**
(attached power cord not shown)
- B Air Fry Basket**
Install when using the Air Fry function. Hand-wash recommended.
- C Sheet Pan(s)**
Place on top of the wire rack. Hand-wash only.
- D 2 Wire Racks**
Use on its own or place the sheet pan on top. Hand-wash recommended.
- E Removable Crumb Tray**
(already installed in unit)
Must remain installed when the top oven is in use. Also able to use in the bottom oven. Hand-wash only.
- F Foodi® Smart Thermometer**



• Accessory type and quantity may vary depending on the model.

USING THE CONTROL PANEL



- TOP**
 - BROIL
 - TOAST
 - BAGEL
 - BAKE
 - REHEAT
 - KEEP WARM
- TEMP SHADE**
- TEMP SLICES**

- BOTTOM**
 - WHOLE ROAST
 - AIR ROAST
 - AIR FRY
 - CONV. BAKE
 - PIZZA
 - DEHYDRATE
- TEMP**
- TIME**

- PRESET**
- DONENESS**
- MANUAL**



FUNCTIONS

Once you've selected a function below, you can change temperature/shade and time/slices.

TOP OVEN:

- BROIL:** Evenly broil meats or fish and brown the tops of casseroles.
 - TOAST:** Toast up to 6 slices of bread to your desired level of darkness.
 - BAGEL:** Perfectly toast up to 6 bagel halves when they're placed cut-side up on the wire rack.
 - BAKE:** Evenly bake everything from your favorite cookies to cakes.
 - REHEAT:** Heat leftovers without over cooking.
 - KEEP WARM:** Keep food warm after cooking.
- NOTE:** The Dehydrate, Reheat, Keep Warm, and Cookies functions are not included on all models.

BOTTOM OVEN:

- WHOLE ROAST:** Simultaneously roast large proteins (like a 4½-lb chicken) and sides for a complete meal.
- AIR ROAST:** Achieve a crispy outside and perfectly cooked inside for full-sized sheet pan meals, thicker proteins, and roasted veggies.
- AIR FRY:** Foods that would traditionally be fried—such as chicken wings, French fries, and chicken nuggets—with little to no added oil.
- CONVECTION BAKE (CONV. BAKE):** Evenly bakes cookies, cakes, brownies, and other goods faster.
- PIZZA:** Cook frozen or homemade pizzas evenly.
- DEHYDRATE:** Dehydrate meats, fruits, and vegetables for healthy snacks.

NOTE: The oven's technology leads to faster cooking. Always monitor food to prevent overcooking. Refer to cook charts in the Inspiration Guide for more guidance on cook times and temperatures.

• The actual number of ports may have a different name or location.

IMPORTANT: Place crumb tray below lower heating elements in the Top Oven or at the very bottom of the Bottom Oven. **DO NOT** slide into any rack positions.

COMMON-SENSE PRACTICES/GOOD HABITS:

- **DO NOT** leave your toaster oven unattended while making food. If possible, unplug the oven while not in use to eliminate the possibility of accidents occurring.
- Have a fire extinguisher or fire containment blanket handy in a safe, known location. If you don't have a fire extinguisher, douse the flames with baking soda until they are put out.
- If a fire occurs and the food in the oven is not greasy, immediately unplug the unit and douse the flames with water until the fire is extinguished. **DO NOT** use water if grease is present, since it could make the fire worse. Use baking soda instead.


BEFORE FIRST USE

- 1 Remove and discard any packaging material from the unit.
- 2 Remove all accessories from the package and read this manual carefully. Please pay particular attention to operational instructions, warnings, and important safeguards to avoid any injury or property damage.
- 3 Wash the air fry basket, sheet pans, wire rack, and removable crumb tray in warm, soapy water, then rinse and dry thoroughly. **DO NOT** put sheet pan or removable crumb tray in the dishwasher. Finishes may degrade. **NEVER** submerge the main unit in water.

We recommend placing all accessories inside the oven and running the top oven on Bake at 450°F for 25 minutes, with the bottom oven on Air Fry at 450°F for 25 minutes without adding any food. Make sure the area is well ventilated, as some odor may be released. This removes any packaging residue and odor traces that may be present. This is completely safe and not detrimental to the performance of the oven.

NOTE: The accessories are hand-wash recommended. The air fry basket and wire racks can be put in the dishwasher, but may wear more quickly over time.


• Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.



- 7 TOP**
 - BROIL
 - TOAST
 - BAGEL
 - BAKE
 - REHEAT
 - KEEP WARM
- 8 TEMP SHADE**
- 9 TIME SLICES**

- 7 BOTTOM**
 - WHOLE ROAST
 - AIR ROAST
 - AIR FRY
 - CONV. BAKE
 - PIZZA
 - DEHYDRATE
- TEMP**
- TIME**

- PRESET**
- DONENESS**
- MANUAL**



CONTROL PANEL DISPLAY & OPERATING BUTTONS

- 1 **Power button:** Press to turn the unit on and off.
 - 2 **SHADE:** Illuminates when using the Toast or Bagel function to designate desired shade.
 - 3 **SLICES:** Illuminates when using the Toast or Bagel function to designate number of slices.
 - 4 **Time display:** Shows the cook time. The time will count down when cooking is in progress.
 - 5 **Temperature display:** Shows the cook temperature.
- NOTE:** Time and temperature will always return to the settings used the last time the oven was in operation.
- 6 **PREHEAT:** PRE will display on the clock while the oven is preheating. If the oven is already up to temperature from using a previous cooking function, the unit will skip preheating, and the cook timer will start.
 - 7 **TOP and BOTTOM buttons:** To select a cooking function, press the TOP button and turn dial to select Top Oven functions (Broil, Toast, Bagel, Pizza, Reheat, and Keep Warm) or the BOTTOM button and turn dial to select Bottom Oven functions (Whole Roast, Air Roast, Air Fry, Convection Bake, Pizza, and Dehydrate). Press and hold TOP or BOTTOM button for 3 seconds to turn off that oven.
- NOTE:** The cook time and temperature may be adjusted at any time during the cooking cycle.

- 8 **TEMP/SHADE button:** To adjust temperature, press the TEMP/SHADE button (Top Oven) or the TEMP button (Bottom Oven), then rotate dial to increase or decrease temperature in 5-degree increments. When using the Toast or Bagel function, the dial will adjust the shade level from 1 (lightest) to 7 (darkest) instead of the temperature.
- 9 **TIME/SLICES button:** To select a cook time, press the TIME/SLICES button (Top Oven) or the TIME button (Bottom Oven), then rotate dial to increase or decrease time in 1-minute increments under 1 hour and 5-minute increments over 1 hour. When using the Toast or Bagel function, these buttons will adjust the number of slices/bagel halves instead of the time.
- 10 **SMART FINISH button:** When cooking in both ovens, press before pressing START/STOP dial to have both ovens finish at the same time.
- 11 **START/STOP dial:** Push to start or stop cooking. When using both ovens, START/STOP will start or stop both ovens. To stop or Start one oven, press TOP or BOTTOM then the START/STOP dial.
- 12 **Light button:** Press to turn the oven's interior light on and off.

THERMOMETER MODE DISPLAY

- A. Thermometer:** Illuminates when thermometer mode is enabled by plugging in the thermometer and pressing the PRESET or MANUAL button.
- B. DONENESS display:** Shows the different doneness levels when in thermometer mode.
- C. TARGET:** Illuminates when using thermometer to show target temperature.
- D. CURRENT:** Illuminates when using thermometer to show current temperature of thermometer.

HOW TO REDUCE SMOKE

We recommend using canola, coconut, avocado, grapeseed, or vegetable oil instead of olive oil.




Recommended:
Canola
Refined coconut
Avocado
Vegetable
Grapeseed

Not recommended:
Olive oil
Butter
Margarine

The unit may produce smoke when cooking on a hotter setting than what is recommended.

WHEN TO USE THE ROAST TRAY

Use Roast Tray on Sheet Pan when cooking on convection functions (such as Whole Roast, Air Roast, and Air Fry), or with greasy foods like: whole chicken, chicken wings, bacon, marinated meats, or oiled vegetables.



NOTE: Roast Tray not included with purchase.


USING YOUR FOODI® DOUBLE OVEN

USING THE COOKING FUNCTIONS IN TWO OVENS

The oven has 1 available rack position in the top oven and 2 available rack positions in the bottom oven for sliding accessories into the unit.

Positioning the Racks

Each cook function corresponds to a specific oven and rack level. See the chart below to determine the recommended accessory and rack level for each cook function. For best results, use only the recommended accessories for each function and remove others from the oven.



		BROIL	TOAST	BAGEL	BAKE	REHEAT/KEEP WARM
TOP OVEN	LEVEL 3	Sheet Pan on Wire Rack	Wire Rack	Wire Rack	Sheet Pan on Wire Rack	Sheet Pan on Wire Rack

NOTE: When cooking greasy, drippy foods, place the Sheet Pan on the Wire Rack below to catch the drippings.

		WHOLE ROAST	AIR ROAST	AIR FRY	BAKE	PIZZA	DEHYDRATE
BOTTOM OVEN	LEVEL 2			Air Fry Basket			Air Fry Basket
	LEVEL 1	Sheet Pan on Wire Rack	Sheet Pan on Wire Rack	Add sheet pan on wire rack for greasy, drippy foods	Sheet Pan on Wire Rack	Sheet Pan on Wire Rack	

NOTE: Always place Sheet Pan on Wire Rack. **DO NOT** place directly on heating elements.

TECHNICAL SPECIFICATIONS

Voltage: 120V-, 60Hz

USING YOUR FOODI® DOUBLE OVEN

To turn on the unit, plug the power cord into an outlet and press the button. The unit will automatically shut off after 10 minutes of inactivity.

USING TWO OVENS

NOTE: PREHEAT FOR BEST RESULTS. Add food only when preheating is complete (up to 3 minutes after pressing START/STOP). Broil, Toast, Bagel, Keep Warm, and Dehydrate do not have a preheat. If Smart Finish is enabled, preheat will only occur in the oven with the longest cook time.

- Press the POWER button to turn the oven on or off.
- Press TOP and turn dial to select top oven functions. Press TOP again to confirm function selection.
- Press the TEMP/SHADE button and then turn the dial to set the cook temperature for the top oven function (shade darkness will be adjusted for Toast and Bagel). Press again to confirm the setting.
- Press the TIME/SLICES button and turn the dial to set the cook time for top oven function (number of slices will be adjusted for Toast and Bagel). Press again to confirm the setting.
- Press BOTTOM and turn dial to select bottom oven functions. Press again to confirm the setting.
- Press the TEMP button and then turn the dial to set the cook temperature for the bottom oven function. Press again to confirm the setting.
- Press the TIME button and then turn the dial to set the cook time for the bottom oven function. Press again to confirm the setting.
- Press the START/STOP to start cooking in both ovens. Preheating is required for Bake, Whole Roast, Air Roast, Air Fry, Convection Bake, and Pizza..

USING TWO OVENS WITH SMART FINISH

- Press the POWER button to turn the oven on or off.
- Press TOP and turn dial to select top oven functions. Press TOP again to confirm function selection.
- Press the TEMP/SHADE button and then turn the dial to set the cook temperature for the top oven function (shade darkness will be adjusted for Toast and Bagel). Press again to confirm the setting.
- Press the TIME/SLICES button and turn the dial to set the cook time for top oven function (number of slices will be adjusted for Toast and Bagel). Press again to confirm the setting.
- Press BOTTOM and turn dial to select bottom oven functions. Press again to confirm the setting.
- Press the TEMP button and then turn the dial to set the cook temperature for the bottom oven function. Press again to confirm the setting.
- Press the TIME button and then turn the dial to set the cook time for the bottom oven function. Press again to confirm the setting.
- To use different settings in both ovens and have them finish at the same time, press the SMART FINISH button. Set after setting function, temperature for one oven then setting other, or set after setting function, temperature, and time for both ovens.
- Press the START/STOP to start cooking in both ovens. Preheating is required for Bake, Whole Roast, Air Roast, Air Fry, Convection Bake, and Pizza.
- When the unit beeps to signify it has preheated, immediately place food in unit and close the door.

NOTE: After preheat is finished, the oven with the shorter cook time will display HOLD. If using the Foodi® Smart Thermometer, the top oven will display the probe and target cook temperatures, while the bottom oven will display cooking progress bars.

TOP OVEN FUNCTIONS

Broil

NOTE: The unit does not preheat in Broil mode.

- To select the function, press the TOP button and rotate dial until BROIL illuminates. The default time and temperature settings will display. Press the TOP button again to confirm function selection.
- Press the TIME/SLICES button and rotate dial to select a cook time up to 30 minutes. Press the TIME/SLICES button again to confirm time selection.
- Press the TEMP/SHADE button and rotate dial to select either HI or LO. Press the TEMP/SHADE button again to confirm temperature selection.
- Place ingredients on the sheet pan. Place the sheet pan on the wire rack on Level 3 in the Top Oven and close the oven door, press START/STOP dial to start cooking.
- When cook time is complete, the unit will beep and END will appear on the display.

Toast

NOTE: The unit does not preheat in Toast mode.

- To select the function, press the TOP button and rotate dial until TOAST illuminates. The default amount of slices and darkness level will display. Press the TOP button again to confirm function selection.

- Press the TIME/SLICES button and rotate dial to select the number of bread slices. You may toast up to 6 slices at once. Press the TIME/SLICES button again to confirm time selection.

- Press the TEMP/SHADE button and rotate dial to select a darkness level. Press the TEMP/SHADE button again to confirm temperature selection.

NOTE: There is no temperature adjustment available for the Toast function, and the unit does not preheat in Toast mode. It is very important to select the exact number of slices to avoid over- or under-toasting.

- Place bread slices on the wire rack in the Top Oven. Close oven door and press START/STOP dial to begin cooking.

- When cook time is complete, the unit will beep and END will appear on the display.

NOTE: You can also manually adjust the time once cooking has started to better choose your preferred shade.

Bagel

NOTE: The unit does not preheat in Bagel mode.

- To select the function, press the TOP button and rotate dial until BAGEL illuminates. The default number of slices and darkness level will display. Press the TOP button again to confirm function selection.
- Press the TIME/SLICES button and rotate dial to select the number of slices. You may toast up to 6 bagel slices at once. Press the TIME/SLICES button again to confirm time selection.
- Press the TEMP/SHADE button and rotate dial to select a darkness level. Press the TEMP/SHADE button again to confirm temperature selection.

NOTE: There is no temperature adjustment available for the Bagel function, and the unit does not preheat in Bagel mode. It is very important to select the exact number of slices to avoid over- or under-toasting.

- Place bagel slices, cut-side up, in the middle of the wire rack in the Top Oven. Close oven door and press START/STOP dial to begin cooking.

- When cook time is complete, the unit will beep and END will appear on the display.

Bake

- To select the function, press the TOP button and rotate dial until BAKE illuminates. The default time and temperature settings will display.
- Press the TIME/SLICES button and rotate dial to select a cook time up to 4 hours.

NOTE: If cooking for 1 hour or less, the clock will count down by minutes and seconds. If cooking for more than 1 hour, the clock will count down by hours and minutes.

- Press the TEMP/SHADE button and rotate dial to select a temperature between 180°F and 450°F. Press the TEMP/SHADE button again to confirm temperature selection.
- Press START/STOP dial to begin preheating.

- Place ingredients on the sheet pan, cake pan, or casserole dish. When the unit beeps to signify it has preheated, immediately place the sheet pan on the wire rack on Level 1 in the Bottom Oven. Close oven door.

NOTE: The timer will start counting down as soon as the unit has preheated. If ingredients are not ready to go into the oven, simply press the TIME button and rotate dial to add more time.

- During cooking, you can turn on the light to check on progress.

- When cook time is complete, the unit will beep and END will appear on the display.

NOTE: For best results with baked goods such as cookies, line the Ninja® Sheet Pan with parchment paper.

Reheat

NOTE: The Reheat function is not included on all models.

- To select the function, press the TOP button and rotate dial until REHEAT illuminates. Press the TOP button again to confirm function selection.
- Press the TIME/SLICES button and rotate dial to select a reheat time up to 4 hours. Press the TIME/SLICES button again to confirm time selection.
- Press the TEMP/SHADE button and rotate dial to select a temperature between 100°F and 450°F. Press the TEMP/SHADE button again to confirm temperature selection.
- Place food on the sheet pan or in an oven-safe container and place the pan or container on the wire rack in the Top Oven. Close oven door and press START/STOP dial to begin warming.
- When cook time is complete, the unit will beep and END will appear on the display.

Keep Warm

NOTE: The Keep Warm function is not included on all models.

- To select the function, press the TOP button and rotate dial until KEEP WARM illuminates. The default time and temperature settings will display. Press the TOP button again to confirm function selection.

- Press the TIME/SLICES button and turn the dial to select a time up to 2 hours. Press the TIME/SLICES button again to confirm time selection.

NOTE: There is no temperature selection available for the Keep Warm function.

- Place food on the sheet pan or in an oven-safe container and place the pan or container on the wire rack on level level 3 in the top oven. Close oven door and press START/STOP dial to begin warming.

- When warming time is complete, the unit will beep and END will appear on the display.

BOTTOM OVEN FUNCTIONS

NOTE: When using only Bottom Oven with high moisture foods (like frozen foods), it is normal to see condensation in the Top Oven window.

Whole Roast

- To select the function, press the BOTTOM button and rotate dial until WHOLE ROAST illuminates. The default time and temperature settings will display. Press the BOTTOM button again to confirm function selection.
- Press the TIME button and rotate dial to select a cook time up to 4 hours. Press the TIME button again to confirm time selection.
- Press the TEMP button and rotate dial to select a temperature between 250°F and 450°F. Press the TEMP button again to confirm temperature selection.
- Place pizza on the sheet pan or directly on the wire rack on Level 2 in the Bottom Oven. Close oven door and press START/STOP dial to begin preheating.

NOTE: Food cooks faster when using the Whole Roast function so refer to cook charts in the Inspiration Guide for more guidance on cook times and temperatures.

- Place ingredients directly on sheet pan. When the unit beeps to signify it has preheated, immediately place sheet pan on the wire rack on Level 1 in the Bottom Oven. Close oven door.

- When cook time is complete, the unit will beep and END will appear on the display.

Air Roast

- To select the function, press the BOTTOM button and rotate dial until AIR ROAST illuminates. The default time and temperature settings will display. When cooking 2 layers, select the 2 LEVEL button so that 2 LEVEL appears on the display.
- Press the TIME/SLICES buttons to select a cook time up to 4 hours.
- Press the TEMP button and rotate dial to select a temperature between 250°F and 450°F. Press the TEMP button again to confirm temperature selection.
- Press START/STOP dial to begin preheating.

- Place ingredients on the sheet pan. When the unit beeps to signify it has preheated, immediately place the sheet pan on the wire rack on Level 1 in the Bottom Oven. Close oven door.

- When cook time is complete, the unit will beep and END will appear on the display.

Air Fry

- To select the function, press the BOTTOM button and rotate dial until AIR FRY illuminates. The default time and temperature settings will display. When cooking 2 layers, select the 2 LEVEL button so that 2 LEVEL appears on the display.
- Press the TIME/SLICES buttons to select a cook time up to 4 hours. Press the TIME button again to confirm time selection.
- Then press the TEMP button and rotate dial to select a temperature between 250°F and 450°F. Press the TEMP button again to confirm temperature selection.
- Press START/STOP dial to begin preheating.

- Place ingredients in the air fry basket on Level 2 in the Bottom Oven. If ingredients are fatty, oily, or marinated, place the sheet pan on wire rack on Level 1 in the Bottom Oven. Use air fry basket for dry ingredients.

- When the unit beeps to signify it has preheated, immediately slide the basket into Level 1 in the Bottom Oven. If also using the sheet pan, slide both into the oven at the same time, with the basket in the upper rack and the pan on the wire rack beneath the basket. Close oven door.

- When cook time is complete, the unit will beep and END will appear on the display.

- When cook time is complete, the unit will beep and END will appear on the display.

Convection Bake

- To select the function, press the BOTTOM button and rotate dial until CONVECTION BAKE illuminates. The default time and temperature settings will display. Press the BOTTOM button again to confirm function selection.

- Press the TIME button and turn the dial to select a cook time up to 4 hours. Press the TIME button again to confirm time selection.

NOTE: If cooking for 1 hour or less, the clock will count down by minutes and seconds. If cooking for more than 1 hour, the clock will count down by hours and minutes.

- Press the TEMP button and turn the dial to select a temperature between 180°F and 450°F. Press the TEMP button again to confirm temperature selection.

- Press START/STOP to begin preheating.

- Place ingredients on the sheet pan, cake pan, or casserole dish. When the unit beeps to signify it has preheated, immediately place the sheet pan on the wire rack on bottom level in the Bottom Oven. Close oven door.

NOTE: The timer will start counting down as soon as the unit has preheated. If ingredients are not ready to go into the oven, simply press the TIME button to add more time.

- During cooking, you can turn on the light to check on progress.

- When cook time is complete, the unit will beep and END will appear on the display.

NOTE: For best results with baked goods such as cookies, line the Ninja® Sheet Pan with parchment paper.

PIZZA

- To select the function, press the BOTTOM button and rotate dial until PIZZA illuminates. The default time and temperature setting will display. Press the BOTTOM button again to confirm function selection.

- Press the TIME button and rotate dial to select a cook time up to 4 hours. Press the TIME button again to confirm time selection.

- Press the TEMP button and rotate dial to select a temperature between 180°F and 450°F. Press the TEMP button again to confirm temperature selection.

- Place pizza on the sheet pan or directly on the wire rack on Level 2 in the Bottom Oven. Close oven door and press START/STOP dial to begin cooking.

- When cook time is complete, the unit will beep and END will appear on the display.

Dehydrate

NOTE: The unit does not preheat in Dehydrate mode.

- To select the function, press the BOTTOM button and rotate dial until DEHYDRATE illuminates. The default time and temperature settings will display. Press the BOTTOM button again to confirm function selection.

- Press the TIME button and rotate dial to select a dehydrate time up to 24 hours. Press the TIME button again to confirm time selection.

- Press the TEMP button and rotate dial to select a temperature between 85°F and 200°F. Press the TEMP button again to confirm temperature selection.

- Place ingredients in the air fry basket on Level 2 in the Bottom Oven. Close oven door and press START/STOP dial to begin cooking.

NOTE: For best results, lay ingredients flat on each layer; do not stack food.

- When cook time is complete, the unit will beep and END will appear on the display.

NOTE: Purchase additional dehydrate accessory to dehydrate up to 2 levels at one time.

NOTE: The Dehydrate function is not included on all models.

USING THE FOODI® SMART THERMOMETER

Before First Use

Make sure the thermometer jack is free of any residue and the cord is free of knots before plugging it into the jack.

- Remove thermometer from storage. Then unwind the cord from the corn wrap to remove the thermometer.

- Plug thermometer into jack on the right side of the control panel. You will feel it click into place.

- If using the top oven, press the TOP button and turn dial to choose function (e.g. Broil or Bake) for the top oven then press TEMP/SHADE and turn dial to set oven temperature. Press TEMP/SHADE (Top Oven) or TEMP (Bottom Oven) button then rotate dial to set oven temperature.

NOTE: The thermometer cannot be used in the top oven with Toast, Bagel, Reheat, or Keep Warm. It cannot be used in the bottom oven with Dehydrate.

NOTE: There is no need to set a cook time, as the unit will automatically turn off the heating element and alert you when your food has finished cooking.

- Press the PRESET button and rotate dial to choose Small or Large preset, depending on the size of the protein (TOP only allows Small preset).

- Press the DONEYESS button and rotate dial to choose the desired doneness.

- Insert thermometer in protein using the chart. Ensure thermometer is placed correctly or this may affect cooking results.

FOOD TYPE:	PRESET DONEYESS TO:
Fish	Medium Rare (120°F)
	Medium (130°F)
	Medium Well (140°F)
Chicken/Turkey	Well Done (150°F)
	Well Done (165°F)
	Well Done (160°F)
Pork	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (150°F)
Beef/Lamb	Well Done (160°F)
	Rare (120°F)
	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (145°F)
	Well Done (155°F)

NOTE: Default Preset doneness is automatically set to medium.

If selecting the MANUAL button, use the below recommended internal cook temperatures.

FOOD TYPE:	PRESET DONEYESS TO:
Fish	Medium Rare (120°F)
	Medium (130°F)
	Medium Well (140°F)
Chicken/Turkey	Well Done (165°F)
	Well Done (160°F)
	Well Done (150°F)
Pork	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (150°F)
Beef/Lamb	Well Done (160°F)
	Rare (120°F)
	Medium Rare (130°F)
	Medium (140°F)
	Medium Well (145°F)
	Well Done (155°F)

- Push the setting (START/STOP) dial to begin preheating. PRE will illuminate on the display during preheat.

- The target and current thermometer temperatures will switch back and forth on the display after preheat on Bake, Whole Roast, Air Fry, Air Roast, and Conv. Bake.

- Once unit has preheated, place the food with thermometer fully inside the unit. Then close door over cord draped over the top of the door to begin cooking.

- The screen will continue to display the current thermometer temperature as it approaches the target temperature during cooking.

- Press TEMP to see the oven temperature. Press TIME to see the time elapsed once cooking has started.

Preset Cooking Chart

FOOD TYPE:	PRESET	WEIGHT	EXAMPLES
Pork	Small	4 each, (4-6 oz each)	Italian Sausages
	Large	2 each, (10-12 oz each)	Bone-In Pork Chops
Chicken	Small	1 each (2 lbs)	Pork Tenderloin,
	Large	1 each (4-5 lbs)	Pork Loin/Roast
Beef	Small	3-4 each, depending on size (8-12 oz each)	Boneless Chicken Breast
	Large	3-4 each depending on size (6-10 oz)	Bone-In Chicken Thighs
Fish	Small	1 each (5 lbs)	Whole Chicken
	Large	2-4 each depending on size (6-12 oz each)	Steak
Beef	Small	1 each (3-4 lbs)	Top Round
	Large	1 each (3-4 lbs)	Top Round
Fish	Small	3-4 each depending on size (4 oz each), or 1 each (12-16 oz each)	Salmon Fillets or Side of Salmon
	Large	1 each (12-16 oz each)	Salmon Fillets or Side of Salmon

HOW TO CORRECTLY INSERT THE THERMOMETER

FOOD TYPE	PLACEMENT	CORRECT	INCORRECT
Tenderloins Fish fillets Whole fish Prime rib Lamb rack Brisket Pork Shoulder Pork Loin Chuck Roast	<ul style="list-style-type: none"> Insert thermometer horizontally into the center of the thickest part of the meat. Make sure the tip of the thermometer is inserted straight into the center of the meat, not angled toward the bottom or top of it. Make sure the thermometer is close to (but not touching) the bone and away from any fat or gristle. 		
	<ul style="list-style-type: none"> The thickest part of the fillet may not be the center. It is important that the tip of the thermometer hits the thickest part so desired results are achieved. 		

- Unit will be and display "END" when cooking is complete.

- Transfer protein immediately to a plate and allow to rest for 5 minutes before serving. This is an important step as proteins continue to cook after cooking completes.

- Hold the MANUAL button for 3 seconds to instantly read the internal temperature of the protein.

NOTE: The thermometer will be HOT. Wait for the thermometer to cool before cleaning and storing. Use either oven mitts or tongs to take the thermometer out of the protein.

USING SMART FINISH WITH THE FOODI® SMART THERMOMETER:

Make sure the thermometer jack is free of any residue and the cord is free of knots before plugging it into the jack.

- Remove thermometer from storage. Then unwind the cord from the corn wrap to remove the thermometer.

- Plug thermometer into jack on the right side of the control panel until it clicks in place.

- If using the top oven, press the TOP button and turn dial to choose function (e.g. Broil or Bake) for the top oven then press TEMP/SHADE and turn dial to set oven temperature. If using the bottom oven, press the BOTTOM button and turn dial to choose function (e.g. Whole Roast, Air Roast, Air Fry, or Conv.) for the bottom oven then press TEMP and turn dial to set oven temperature. Press TEMP/SHADE (Top Oven) or TEMP (Bottom Oven) button then rotate dial to set oven temperature.

- Press the PRESET button and rotate dial to choose Small or Large preset, depending on the size of the protein (TOP only allows Small preset).

- Press the DONEYESS button and rotate dial to choose the desired doneness.

- Select SMART FINISH and push the START/STOP dial to begin cooking. PRE will illuminate on the display during preheat.

- Open door and insert thermometer into protein.

- When cooking is complete, unit will beep. Transfer to a plate and allow to rest for 5 minutes before serving. This is an important step, as proteins continue to cook and retain juices after being removed from the source of heat.

- Hold the MANUAL button for 3 seconds to instantly read the internal temperature of the protein.

NOTE: During the initial cooking phase, the oven with the shorter cook time will display HOLD. The display will then transition to showing the probe's current and target temperature in the oven that you're using.

NOTE: Smart Finish is not compatible with the MANUAL setting.

Whole chicken

- Insert thermometer horizontally into the thickest part of the breast, parallel to, but not touching, the bone.
- Make sure the tip reaches the center of the thickest part of the breast and doesn't go all the way through the breast into the cavity.

NOTE: DO NOT use the thermometer with frozen protein or for cuts of meat 1 inch thick or thinner.

CLEANING & MAINTENANCE

EVERYDAY CLEANING

The unit should be cleaned thoroughly after every use.

- Unplug the unit from the outlet and allow it to cool down before cleaning.
- Empty crumb tray by sliding it out of the oven. The crumb tray can fit in both the Top and Bottom ovens.

NOTE: Empty crumb tray frequently. Hand-wash when necessary.

- After every use, wipe away any food splatter on the interior walls and glass door