

NINJA®

STORM™

OWNER'S GUIDE



Recipe book is not included

It's important to read this manual prior to using your new product for the first time.

IMPORTANT SAFETY INSTRUCTIONS For Household Use Only

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING YOUR NINJA® STORM™.

POLARIZED PLUG

WARNING: To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. **DO NOT modify the plug in any way.**

WARNING: Extension cords are not recommended for use with this product.

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

1 **WARNING:** Remove utensils prior to processing. Failure to remove may cause the jar to be damaged or to shatter which may cause personal injury.

- 2** **WARNING:** 4-Blade Assembly is sharp, not locked in place and removable, handle with care. When handling the 4-Blade Assembly, always hold it by the shaft. Failure to do so will result in a risk of laceration.
- 3** **WARNING:** 4-Blade Assembly is sharp and not locked in place. Remove the splashguard and carefully remove the 4-Blade Assembly first, holding it by the shaft before pouring. Failure to do so will result in a risk of laceration.
- 4** **WARNING:** 4-Blade Assembly is sharp and not locked in place. If using the pour spout, ensure that the splashguard is fully on the pitcher. Failure to do so will result in a risk of laceration.
- 5** **CAUTION:** If pouring with the lid or splashguard removed, ALWAYS remove the 4-Blade Assembly first. Failure to do so will result in a risk of laceration.
- 6** **CAUTION:** Do not blend hot liquids, doing so may cause excessive pressure build-up, resulting in risk of the user being burned.
- 7** To protect against electrical shock, do not submerge the appliance or allow the power cord to come into contact with water or any other liquid.
- 8** **DO NOT** allow the appliance to be used by children. Close attention is necessary when used near children. This is not a toy.

Accessory type and quantity may vary depending on the model.

The image shown here is for illustrative purposes only and may be subject to change.

- 9** Never leave an appliance unattended when in use.
- 10** Appliance accessories are not intended to be used in the microwave as it may result in damage to the accessories.
- 11** Remove the Master Pod from the appliance and unplug the power cord from the electrical outlet when not in use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the electrical outlet. Never pull from the power cord.
- 12** **DO NOT** abuse the power cord. Never carry the Master Pod by the power cord or yank it to disconnect from electrical outlet; instead grasp the plug and pull to disconnect.
- 13** **DO NOT** operate any appliance with a damaged cord or plug, or after the appliance malfunctions, has been dropped or damaged in any manner. This appliance has no serviceable parts.
- 14** **DO NOT** let the power cord hang over the edge of table or counter or touch hot surfaces such as the stove.
- 15** Always use appliance on a dry, level surface.
- 16** Keep hands, hair, clothing, as well as utensils out of container while processing to reduce the risk of severe injury to persons or damage to the appliance. A scraper may be used but only when the appliance is not running.
- 17** Avoid contact with moving parts.
- 18** **DO NOT** attempt to sharpen blades.
- 19** **DO NOT** use the appliance if blade assemblies are bent or damaged.
- 20** **DO NOT** expose pitcher to extreme temperature changes.
- 21** **DO NOT** use pitcher if it is cracked or chipped.
- 22** To reduce the risk of injury, **NEVER** operate the appliance without the splashguard in place; **DO NOT** try to defeat the interlock mechanism; make sure that the cutting blades are properly assembled before operating the appliance.
- 23** **DO NOT** operate this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- 24** The use of accessory attachments, including canning jars not recommended by the manufacturer may cause fire, electrical shock or risk of personal injury.
- 25** **DO NOT** remove the Master Pod before the Ninja 4-Blades Assembly has stopped turning.
- 26** **DO NOT** overfill.
- 27** **DO NOT** operate the appliance empty.
- 28** **DO NOT** try to defeat the interlock mechanism. Make sure that the 40 oz. 4-Blade Assembly is properly inserted before operating the appliance.
- 29** Immediately release the On/Off pulse button on the Master Pod in the event that the appliance malfunctions during use.
- 30** **DO NOT** operate the appliance for more than 15 seconds.
- 31** **THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY.** Do not use this appliance for anything other than its intended use. Do not use outdoors.
- 32** If the appliance overheats, a thermal switch will become activated and shut off the motor. To reset, unplug the appliance and let it cool down for approximately 10 minutes before using again.




TECHNICAL SPECIFICATIONS

Voltage: 120V., 60Hz.

Pitcher Capacity: 40 oz. (5 cups, 1.25 L)

SAVE THESE INSTRUCTIONS

Getting Started *The accessories may differ in quantity and appearance.



a Master Pod

b Splashguard

c Pitcher Storage Lid

d 40 oz. 4-Blade Assembly

e 40 oz. Pitcher with Non-Slip Base

f Power Cord (not shown)


The Ninja® Storm™ is an indispensable kitchen tool that is perfect for blending, whipping, ice crushing and food processing - all in the conveniently sized pitcher! For best results, be sure to carefully read all the instructions contained in the manual before using this appliance.



Thank you for purchasing the Ninja® Storm™.

Before First Use

▲ WARNING: 40 oz. 4-Blade Assembly is sharp and not locked in place. If using the pour spout, ensure that the splashguard is fully on the pitcher. Failure to do so will result in a risk of laceration.



PLEASE KEEP THESE IMPORTANT SAFEGUARDS IN MIND WHEN USING THE APPLIANCE:

IMPORTANT: Make sure that the Master Pod is plugged in for use.

IMPORTANT: Never add ingredients into the container before placing the 40 oz. 4-Blade Assembly in first.

IMPORTANT: Attachments are not interchangeable.

IMPORTANT: DO NOT attempt to operate the appliance without the splashguard on.

IMPORTANT: Never run the appliance empty.

IMPORTANT: Appliance accessories are not intended to be used in the microwave as it may result in damage to the accessories.

▲ CAUTION: Do not immerse the Master Pod into water or any other liquid.

1 Remove all packaging material from the appliance. Separate/remove all parts from each other.

2 Wash the lid, splashguard, pitcher, and 40 oz. 4-Blade Assembly in warm, soapy water. When washing the blade assembly, use a dish-washing utensil with a handle to avoid direct hand contact with blades.

▲ WARNING: Handle the 40 oz. 4-Blade Assembly with care when washing, as the blades are sharp.

3 Handle the 40 oz. 4-Blade Assembly with care to avoid contact with sharp edges. Rinse and air dry thoroughly.

4 The pitcher, lid, splashguard, and 40 oz. 4-Blade Assembly are all dishwasher safe. It is recommended that the lid, splashguard and blade assembly be placed on the top rack. Ensure that the blade assembly is removed from the pitcher before placing in the dishwasher.

5 Wipe the motor base clean with a damp cloth.

Assembly and Use of the Pitcher

▲ CAUTION: If pouring with the lid or splashguard removed, ALWAYS remove the 40 oz. 4-Blade Assembly first. Failure to do so will result in a risk of laceration.





Fig. 1

1 Review warning and caution statements before proceeding to number 2.

2 Place the pitcher on a clean, dry, level surface.

3 Add the ingredients to be processed into the pitcher.

4 Holding the 40 oz. 4-Blade Assembly by the shaft, place it onto the spindle pin inside the pitcher. (Fig. 1, a)

▲ WARNING: Place 40 oz. 4-Blade Assembly inside the pitcher carefully as blades are sharp.

▲ WARNING: DO NOT try to place the 40 oz. 4-Blade Assembly onto the Master Pod and then into the pitcher. (Fig. 1, b)

IMPORTANT: Never add ingredients into the pitcher before placing the blades in first.

5 Place the pitcher splashguard onto the top of the pitcher. (Fig. 1, c)

▲ WARNING: Handle the 40 oz. 4-Blade Assembly with care, as the blades are sharp.

▲ WARNING: Remove utensils prior to processing. Failure to remove may cause the pitcher to be damaged or to shatter, which may cause personal injury.

▲ WARNING: DO NOT try to place the 40 oz. 4-Blade Assembly onto the Master Pod and then into the pitcher.

▲ WARNING: DO NOT attempt to operate the appliance without the safety splashguard in place.

▲ WARNING: Never leave the appliance unattended while in use.

▲ CAUTION: Do not blend hot liquids, doing so may cause excessive pressure buildup, resulting in risk of the user being burned.

IMPORTANT: Make sure that the Master Pod is plugged in for use.




Fig. 2




Fig. 3

6 Place the Master Pod on top of the splashguard making sure that it is securely in place. (Fig. 2)

7 To start the appliance, plug the power cord into the electrical outlet, securely hold the Master Pod while operating and press on the On/Off pulse button located on the top of the Master Pod. (Fig. 3)

8 Hold the pitcher firmly while depressing the On/Off pulse button to ensure the unit stays in place.

NOTE: DO NOT operate the appliance continuously for more than 15 seconds at a time.

9 To stop the appliance, remove your fingers from the On/Off pulse button.

10 In order to obtain a better quality of chopping, operate the appliance by using the "pulse" method.

11 Make sure that the 40 oz. 4-Blade Assembly has stopped completely before removing the Master Pod.

12 If the ingredients stick to the side of the pitcher, stop the appliance, remove the Master Pod and the splashguard. Use a spatula to dislodge the pieces and then replace the splashguard and the Master Pod. Continue processing.

13 Depending on the consistency of the contents, use the pour spout to empty liquid contents.

14 For thicker consistencies, first remove splashguard and 40 oz. 4-Blade Assembly (by its shaft), then empty contents of the pitcher.

HINTS & TIPS FOR USING YOUR NINJA®

• The 40 oz. 4-Blade Assembly can be used for chopping meat, fish, vegetables, cheese etc.

• For mincing, chopping and pureeing, increase the length of pulses.

• For coarse chopping, use short, quick pulses and monitor food texture.

• Pre-cut larger pieces to make them fit into the pitcher. When chopping hard foods (e.g. meat, cheese) cut into 1-inch cubes.

• To crush ice into snow, start by using short pulses to break up large chunks. Continue until snow is achieved.

Cleaning and Maintenance

HOW TO CLEAN

▲ CAUTION: Remove the Master Pod from the appliance and unplug the power cord from the electrical outlet before assembling or disassembling parts and before cleaning.

▲ CAUTION: DO NOT immerse the Master Pod into water or any other liquid. Clean with a damp sponge or cloth and wipe dry.

1 Separate/remove all parts from each other.

2 Hand Washing: Wash the lid, splashguard, pitcher, and Ninja 4-Blade assembly in warm, soapy water. When washing the 40 oz. 4-Blade Assembly, use a dish-washing utensil with a handle to avoid direct hand contact with blades. Handle the 40 oz. 4-Blade Assembly with care to avoid contact with sharp edges. Rinse and air dry thoroughly.

▲ WARNING: Handle the 40 oz. 4-Blade Assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

3 Dishwasher: The pitcher, lid, splashguard, and 40 oz. 4-Blade Assembly are all dishwasher safe. It is recommended that the lid and blade assembly be placed on the top rack. Ensure the blade assembly is removed from the pitcher before placing in the dishwasher.

4 Wipe the motor base clean with a damp cloth.

HOW TO STORE

1 Store the Ninja® Storm™ upright with the 40 oz. 4-Blade Assembly inside the pitcher and splashguard and Master Pod on the pitcher. Do not place anything on top. Store the rest of the attachments along side the appliance or in a cabinet where they will not be damaged and won't cause a hazard. Loosely wrap the power cord around the Master Pod.

Troubleshooting Guide

PROBLEMS	POSSIBLE REASONS & SOLUTIONS
Motor Doesn't Start or Blades Don't Rotate.	Check that the bottom of motor head is clean and there is no food blocking connection when placing on containers. There is too much food in the pitcher. The unit has overheated. Unplug and wait approximately 10 minutes before using again. Make sure the splashguard is securely on pitcher. Make sure the Master Pod is securely placed on splashguard. Check that the plug is securely inserted into the electrical outlet. Check fuse or breaker. Replace fuse/reset breaker.
Food is Unevenly Chopped.	Either you are chopping too much food at one time, or the pieces are not small enough. Try cutting the food into smaller pieces of even size and processing smaller amounts per batch.
Food is Chopped Too Fine or is Too Watery.	The food has been over processed. Use brief pulses or process for shorter time. Let blades stop completely between pulses.
Food Collects On Splashguard/ Safety Cover or On the Sides of the pitcher.	You may be processing too much food. Turn the machine Off. When the blades stop rotating, remove the Master Pod and the splashguard. Remove some of the food being processed.
You Cannot Achieve Snow From Solid Ice.	Do not use ice that has been sitting out or has started to melt. Be sure to use short pulses in the beginning to break up large pieces.

REFURBISHED PRODUCT LIMITED NINETY DAYS WARRANTY

The **Refurbished Product Service Center** offers the following WARRANTY to the ORIGINAL purchaser of a product which we have refurbished.

This product that has been refurbished is warranted against any electronic or mechanical defects for a period of NINETY DAYS from the date of the original purchase by the consumer. Since this unit was sold as a refurbished item, the warranty does not apply to any cosmetic appearance items such as scratches. Should a defect occur, the **Refurbished Product Service Center** will repair or, at its option, replace defective unit/parts with new or rebuilt materials without charge for either parts or labor. Replacement unit/parts will be warranted for the remaining portion of the original warranty period.

This warranty does not cover installation or damage from accident, misuse, abuse, improper wiring, incorrect voltage, operating the unit against the instructions in the owner's manual or any product which has been opened, altered, or tampered with.

This warranty does not cover costs for removal and or installation of the unit for repair. Under no circumstances shall the service center be liable for any special, incidental or consequential damages or for any other expenses incurred by reason of use or sale of this product. This warranty is in lieu of any other warranties expressed or implied warranty of merchantability of fitness for particular use or otherwise.

This warranty gives the consumer specific legal rights and they may also have other rights which vary from State to State. Some States do not follow the exclusion or limitation of incidental or consequential damages, hence the above exclusion and limitations may not apply.

Refurbished Product Service Center
13225 Marquardt Avenue Santa Fe Springs, CA 90670.

WARRANTY REPAIR INFORMATION

If you need service on your unit and this product requires repair during the 90 days warranty period; please go to www.ConsumerServiceRefurbish.com or call the **Refurbished Product Service Center** at 562-946-3531 to obtain the required return authorization (RA) number. Pack the unit properly (the original carton is ideal for this purpose) along with a copy of your purchase receipt and a letter describing the problem. Send the unit freight prepaid and insured to:

Refurbished Product Service Center,
Att: Customer Service Department 13225 Marquardt Avenue Santa Fe Springs, CA 90670

Your unit will be promptly repaired and returned to you.

We will refuse to accept delivery of the returned unit unless the assigned RA number appears on the outside of the shipping carton.

Owner's Information
(Keep for your permanent records)

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP CODE: _____

PHONE: _____ E-MAIL: _____

MODEL: _____ SERIAL NO.: _____

SharkNinja Operating LLC
US: Newton, MA 02459
CAN: Ville St-Laurent, QC H4S 1A7

Ninja is a registered trademark of SharkNinja Operating LLC.
Storm is a trademark of SharkNinja Operating LLC.

Illustrations may differ from actual product. We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.

For SharkNinja U.S. Patent information visit sharkninja.com/USPatents

© 2016 SharkNinja Operating LLC

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.



PRINTED IN MEXICO Elbrd: Y.T._10-08-19
OBPN: QB751Q_30_SERIES_IB_160127_1
SC: 05-17-2017_TAB MODEL: QB751QBK_B

