

Please read this manual carefully before operating your unit and retain for future reference.

804106439

IMPORTANT SAFEGUARDS

⚠ WARNING PREVENT INJURIES! CAREFULLY READ ALL INSTRUCTIONS BEFORE USE!

When using electrical appliances basic safety precautions should be followed, including the following:

⚠ To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:

- Read all instructions before using the appliance.
- Read and follow the specific warning in the "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" section.
- This appliance must be grounded. Connect only to properly grounded outlet (see the "GROUNDING INSTRUCTIONS" section).
- Install or locate this appliance only in accordance with the "Countertop Installation" section.
- Some products, such as whole eggs and sealed containers - for example, closed glass jars - can explode and should not be heated in this appliance.
- Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance. This appliance is specifically designed to heat or cook food. It is not designed for industrial or laboratory use.
- As with any appliance, close supervision is necessary when it is used by children.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been damaged or dropped.
- This appliance should be serviced only by qualified service technicians. Contact a service center.
- Do not cover or block any openings on the appliance.
- Do not store or use this appliance outdoors.

- Do not use this product near water, such as near a kitchen sink, in a wet basement, near a swimming pool, or similar locations.
- Do not immerse cord or plug in water.
- Keep cord away from heated surfaces.
- Do not let cord hang over edge of table or counter.
- Place the front surface of the door 3 inches or more back from the countertop edge to avoid accidental tipping of the appliance during normal usage.
- Recommended clearances: 3 inches on each side, 12 inches on top, and 3 inches in the rear.
- Do not mount this appliance over a sink.
- Do not store anything directly on top of the appliance's surface when the appliance is in use.

- Oversized food or oversized metal cookware should not be used in this appliance because they increase the risk of electric shock and could cause a fire.
- When cleaning the surfaces of the door and the appliance that come together on closing the door, use only mild, nonabrasive soaps or detergents applied with a sponge or soft cloth.
- Do not clean with metal scouring pads. Pieces can burn off the pad and touch electrical parts, which involves a risk of electric shock.
- Do not cover the microwave rack or any part of the appliance with metal foil. This will cause overheating of the appliance.
- To reduce the risk of fire in the appliance interior:
 - Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the appliance to facilitate cooking.
 - Remove wire twist-ties from paper or plastic bags before placing bag in the appliance.

- If materials inside the appliance ignite, keep appliance door closed, turn appliance off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
- Do not use the interior for storage purposes. Do not leave paper products, cooking utensils, or food in the appliance when not in use.
- Do not use the microwave function without food in the appliance.

- Liquids such as water, coffee, or tea can be overheated beyond the boiling point without appearing to be boiling. This is called delayed eruptive boiling. Visible bubbling or boiling when the container is removed from the microwave appliance is not always present. THIS COULD RESULT IN VERY HOT LIQUIDS SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.

- To reduce the risk of injury to persons:
 - Do not use straight-sided containers with narrow necks. Use a wide-mouth container.
 - Strir liquid both before and halfway through heating it.
 - Do not overheat liquid.
 - Use extreme care when inserting a spoon or other utensil into the container. This may also cause delayed eruptive boiling.
 - After heating, allow the container to stand in the microwave appliance for a short period of time before removing the container.
 - Be careful when opening containers of hot food. Use potholders and direct steam away from your face and hands.
 - Vent, pierce, or slit containers, pouches, or plastic bags to prevent build-up of pressure.
 - Be careful when touching the turntable, door, or walls of the appliance, which may become hot during use.
 - Do not use paper products when the appliance is operated in the air fryer or oven mode.

- Cook meat and poultry thoroughly - meat to at least an internal temperature of 160° F/71° C and poultry to at least an internal temperature of 180° F/82° C.
- Make sure all cookware used with the microwave function in this appliance is suitable for microwaving (see the "Materials to Avoid with the Microwave Function" section).

- Do not store any materials, accessories, or containers inside the appliance when not in use.
- Use of the accessories:
 - Remove the Air Frying Rack and Baking Pan from the appliance when not in use.
 - Use potholders when handling the cooking accessories. They may be hot.
 - Be sure that the accessories are positioned properly inside the appliance. The Air Frying Rack and Baking Pan must always be placed on the Glass Tray.
 - DO NOT USE THE AIR FRY RACK AND BAKING PAN WITH THE MICROWAVE FUNCTION.

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- Do not attempt to operate this appliance with the door open as this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.
- Do not place any object between the appliance front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the appliance if it is damaged. It is particularly important that the appliance door closes properly and that there is no damage to the door (for example, make sure that it is not bent); hinges and latches (for example, make sure that they are not broken or loosened); door seals and sealing surface.

⚠ WARNING: For California Residents
This product can expose you to Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Using the Power Cord

- A short power-supply cord is provided to reduce the risk of becoming entangled or tripping over a longer cord.
- This appliance has been designed for use with a 3-prong, 120V dedicated electrical outlet only.
- Plug into a 3-prong wall outlet with no other appliances on the same outlet. Plugging other appliances into the outlet may cause the circuit to overload.

Electric Power

If the electrical circuit is overloaded with other appliances, your new appliance may not operate properly. It should be operated on a dedicated electrical circuit.

⚠ WARNING

- NEVER** put anything on top of the appliance.
- NEVER** cover the air vents on the top, back, and side of the cooking appliance.
- ALWAYS** use oven mitts when removing anything hot from the appliance.
- NEVER** rest anything on the door while it is open.
- DO NOT** leave the door open for an extended period.
- ALWAYS** ensure that nothing is protruding from the appliance before closing the door.
- ALWAYS** close the door gently; **NEVER** slam the door closed. **ALWAYS** handle the handle of the door when opening and closing the door.

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance

Appliance Specifications


Model Number	Supply Power	Rated Power	Capacity	Turntable Diameter	Temperature
BDK02	120V ~60Hz	Input Microwave: 1500W Output Microwave: 1000W Output Grill: 1150W Output Air Fry: 1800W	1 Cubic Foot	12.4 inches	Air Fry: 300°F/149° C-425°F/218° C Bake: 100°F/38° C-425°F/218° C

Countertop Use

Remove all packing material and accessories. Examine the oven for any damage, such as dents or a broken door. Do not install if the appliance is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown cover that is attached to the oven cavity to protect the magnetron.

- Select a level surface that provides enough open space for the intake and/or outlet vents. A minimum clearance of 3.0 inches (7.5cm) is required between the appliance and any adjacent walls. One side must be open.
 - Leave a minimum clearance of 12 inches (30cm) above the appliance.
 - Do not remove the legs from the bottom of the appliance.



Parts & Accessories

NOTE: Unpack all contents from the packaging. Contents vary by model.



is equipped with a cord with a grounding wire and grounding plug. The plug must be plugged into an outlet that is properly installed and grounded. Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-pronged grounding plug and a 3-slot receptacle that will accept the plug on the appliance.

- A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
- Longer cord sets or an extension cord should not be used unless the following precautions are followed (see 3, below).
- If a long cord or extension cord is used:
 - The marked electrical rating of the cord set or extension cord should match the rating of the appliance.
 - The extension cord must be a grounding-type 3-wire cord.
 - The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

IMPORTANT

Before initial use, hand wash the cooking accessories. Then, wipe the outside and inside of the appliance with a warm, moist cloth and mild detergent. Next, preheat the appliance for a few minutes to burn off any residue. Finally, wipe the appliance out with a wet cloth.

CAUTION: Upon first use, the appliance may smoke or emit a burning odor due to oils used to coat and preserve the heating elements.

- MAIN UNIT:** Features sturdy construction throughout.
- GLASS DOOR:** Sturdy, durable glass keeps heat in and helps ensure even heat distribution to food. NEVER cook with this door in the open position.
- DOOR HANDLE:** Always use the handle and avoid touching the Glass Door. The Door may become very hot during the cooking process and can cause injury.
- CONTROL PANEL:** Use the Control Panel to use the cooking presets and set the cooking time and temperature (see "The Control Panel" section).
- TURNTABLE ASSEMBLY:** Food, containers, and cooking accessories must always be placed on the Turntable Assembly when using all the appliance's cooking modes.

Turntable Installation

All food and food containers should be placed on the Glass Tray when cooked in this appliance. If the Glass Tray or the Turntable Ring are damaged, Contact a Service Center. To assemble the turntable:

- Place the Turntable Ring in the groove on the bottom of the inside of the appliance (see Fig. i).
- Place the Glass Tray on top of the Turntable Ring (see Fig. ii). Ensure that the Glass Tray is right side up.

⚠ WARNING

The metal components of this appliance will get extremely hot during use. Great care should be taken to avoid personal injury. Wear protective oven mitts or gloves.

Oversized metal utensils and accessories, including the Air Fry Rack and Baking Pan, should not be used with this appliance's microwave function.

- 5a. TURNTABLE RING:** Used to assemble the turntable so that food rotates during the cooking process.
- 5b. GLASS TRAY:** Used to assemble the turntable. The glass tray assembly is ALWAYS required for all cooking modes. It must not be removed.
- 5c. TURNTABLE SHAFT:** Used for rotating the Glass Tray when cooking food.
- 6. AIR FRY RACK:** Use for air frying onion rings, mozzarella sticks, French fries, and more. Cannot be used with Microwave mode and must always be placed on the Glass Tray.
- 7. BAKING PAN:** Use for baking pizzas and baked goods. Cannot be used with Microwave mode and must always be placed on the Glass Tray. May be sold separately.




FIG. i



FIG. ii

The Control Panel

A. INDICATORS

- Microwave
- Air Fry
- Heating Element (used with the Air Fry, Bake, or Broil settings)
- Defrost
- Lock
- Menu

- B. LED PANEL:** Displays functions, cooking times, temperatures, and weights.

- C. FUNCTION BUTTONS:** Use to set Microwave, Air Fryer, or Bake in manual mode. Bake and Air Fry have adjustable time and temperature. Microwave has adjustable power and time. Microwave Power Level: Press to change the power level.


- D. PRESET BUTTONS:** Use to select a preset cooking function, which sets a preset cooking time and temperature.

- E. FUNCTION MENU BUTTONS:** Use to select presets from the preset menu (see "Preset Cooking Chart" section) or to adjust the clock.

Micro Menu: Refer to the "Preset Cooking Chart" section for preset cooking times and temperatures.
Air Fry Menu: Refer to the "Preset Cooking Chart" section for preset cooking times and temperatures.
Clock/Timer Button: Press once to set the current time on the appliance. Press twice to set the timer on the appliance. Use the Control Knob to adjust and confirm the selected time.

- F. CONTROL KNOB:** Once a cooking mode, time, and temperature have been set either manually or by using the Preset Buttons, press the Control Knob to begin the cooking process. During the cooking process, press the Control Knob to add 30 seconds to the cooking time. The Control Knob can also be used to confirm settings, such as the clock/timer on the appliance.

- G. STOP/CLEAR/ECO BUTTON:** Press the Stop/Clear/Eco Button to stop the cooking process at any time. When the cooking process is stopped,



press the Stop/Clear/Eco Button to cancel the current cooking timer and enter standby mode. When the appliance is in standby mode, press the Stop/Clear/Eco Button to darken the control panel. When the panel is darkened, press any button on the panel to illuminate the panel.

- H. LOCK/MUTE BUTTON:** Press to mute or unmute the appliance. Hold to lock or unlock the appliance (see "Using the Lock and Mute Functions" section).

STANDBY MODE: When no cooking program is running, the appliance is in standby mode.

The actual descriptions of control panel and their locations may vary, depending on the model.

Using the Accessories

Using the Air Fry Rack

- Assemble the turntable (see the "Turntable Installation" section).
- Place food on the Air Fry Rack. Place the Air Fry Rack on the Tray (see Fig. iii). The Air Fry Rack can be flipped so that food can be placed closer to or farther from the top heating element.
- Choose a cooking mode, time, and temperature. Press the Control Knob to begin the cooking process.
NOTE: Do not use the Air Fry Rack with the microwave function.



FIG. iii

* Using the Baking Pan

- Assemble the turntable (see the "Turntable Installation" section).
- Place food on the Baking Pan. Place the Baking Pan on the Glass Tray (see Fig. iv) or on the Air Fry Rack (see Fig. v).
- Choose a cooking mode, time, and temperature. Press the Control Knob to begin the cooking process.

*Baking Pan(option not supplied)



FIG. iv



FIG. v

Instructions for Use

Before First Use

- Read all material.
- Remove all packing materials.
- Hand-washing is recommended. Wash all parts and accessories used in the cooking process with warm, soapy water.
- Never wash or submerge the cooking appliance in water. Wipe the inside and outside of the cooking appliance with a clean, moist cloth. Rinse with a warm, moist cloth.
- Before cooking food, preheat the appliance for a few minutes to allow the manufacturer's protective coating of oil to burn off. Wipe the appliance with warm, soapy water and a dishcloth after this burn-in cycle.

Setting the Clock

- Press the Clock/Timer Button once. The LED Panel will show "00:00."
- Turn the Control Knob to adjust the hour setting from 1 to 12.
- Press the Clock/Timer Button to confirm the hour setting.
- Turn the Control Knob to adjust the minute setting from 0 to 59.
- Press the Clock/Timer Button to confirm the time setting.

Setting the Kitchen Timer

- Press the Clock/Timer Button twice. The LED Panel will show "00:00."
- Turn the Control Knob to adjust the kitchen timer from 0 to 95 minutes.
- Press the Clock/Timer Button to start the kitchen timer.

Cookware in the Microwave

It is not necessary to buy new cookware. Many pieces already in your kitchen can be used successfully in your new appliance. The charts below will help you decide

which cookware and coverings should be used with each feature. Make sure the utensil does not touch the interior walls during the cooking process.

Cookware	Microwave	Air Fry	Bake
Heat-resistant glass, glass-ceramic	Yes	Yes	Yes
Metal	No	Yes	Yes
Heat-resistant glass	No	No	No
Microwave-safe plastics Note: Use only microwaveable cookware that is safe to 450° F/232° C.	Yes	No	Yes*
Plastic films and wraps	Yes	No	No
Paper products	Yes	No	No
Straw, wicker, and wood	No	No	No
Aluminum foil: Use as shielding only. Small smooth pieces may be used to cover thin parts of poultry to prevent overcooking. Airing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5cm) away from the oven walls.	No	Yes	Yes
Dinnerware: Microwave safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.	Yes	No	No
Oven cooking bags: Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.	Yes	Yes	Yes
Wax paper: Use as a cover to prevent splattering and retain moisture inside.	Yes	No	No

Materials to Avoid in the Appliance

Material	Reasons
Aluminum Tray	May cause arcing and could cause a fire in the oven. Transfer food to microwave-safe dish.
Food carton with metal handle	May cause arcing and could cause a fire in the oven. Transfer food to microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing and could cause a fire in the oven.
Metal Twist Ties	May cause arcing and could cause a fire in the oven.
Paper Bags	May cause a fire when using the air fryer or oven function.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

Instructions for Use Containers

CAUTION
PERSONAL INJURY HAZARD
Tightly closed containers could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

See the instructions in the "Materials You Can Safely Use in a Microwave Oven" and "Materials To Be Avoided in a Microwave Oven" sections.

There may be certain non-metallic materials that are not safe to use for microwaving. If in doubt, you can test the utensil in question by following the instructions in the "Material/Container Test" section.

Material/Container Test

- Fill a microwave-safe container with 1 cup (250 ml) of cold water and the container.
- Set the appliance to microwave mode and cook on maximum power for 1 minute. NOTE: Do not microwave the container for more than 1 minute.
- Carefully feel the container. If the container is warm, do not use the container in microwave mode.
- Do not exceed 1 minute cooking time to not overheat the container.

Cooking Function Information

Microwave Function

- Press the Microwave Button to manually adjust the power and time of the Microwave function.
- Press the Microwave Button or turn the Control Knob to select one of the ten power levels (see Fig. vi). Press the Control Knob to confirm the power level.
- Turn the Control Knob to adjust the cooking time. Press the Control Knob to confirm the cooking settings and begin the cooking process.

Fast Microwave

Turning the Control Knob while the appliance is in standby mode (see "The Control Panel" section) allows you to add or subtract time. Pressing the Control Knob will confirm the time and run the microwave at 100% power. Pressing the Control Knob again will increase the cooking time in 30-second increments.

Defrost Button

- Pressing the defrost button displays DEF1.
- You can scroll though the DEF1-DEF6 settings by repeatedly pressing the Defrost Button or by turning the Control Knob (see the Defrost Charts in the "Microwave Programming" section).
- Press the Control Knob to confirm the setting.

Popcorn Button

- Press the Popcorn Button.
- The LED Display will show "2.75 Oz." Turn the Control Knob to cycle between the available preset popcorn weights (2.75 oz., 3.2 oz., and 3.5 oz.).

Micro Menu Button

- Press the Micro Menu Button to activate the micro menu.
- Press the Micro Menu button repeatedly or turn the Control Knob to select one of the preset weights (see Fig. vii).
- Press the Control Knob to confirm the cooking settings.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

NOTE: Pressing the Control Knob increases the cooking time in 30-second increments.

Bake Function

- Press the Bake Function Button once. The LED Panel will display "350F".
- Turn the Control Knob to cycle between the available cooking temperatures (100° F/38° C, 150° F/65° C, 250° F/121° C, 275° F/135° C, 300° F/149° C, 325° F/163° C, 350° F/177° C, 375° F/190° C, 400° F/204° C, 425° F/218° C). Press the Control Knob to confirm the cooking temperature.
- Turn the Control Knob to adjust the cooking time (30-second intervals for 5-10 minutes, 1 minute intervals for 10-30 minutes, and 5-minute intervals for

Preventing Arcing

Arcing is sparks or electric flashes that crackle or pop. Arcing can produce heat that is quite intense and can damage the interior of the microwave or containers being used in the microwave. It can also cause fire. Arcing occurs when metal containers are used in the microwave and can also occur with the use of metal skewers, metal clamps, or twist ties for plastic bags. To prevent arcing, use the charts to determine which materials are microwave safe, or follow instructions from container/wrap manufacturer.

Plastic Cookware

Plastic cookware designed for microwave cooking is very useful, but should be used carefully. Even microwave-safe plastic may not be as tolerant of overcooking conditions as are glass or ceramic materials and may soften or char if subjected to short periods of overcooking. In longer exposures to overcooking, the food and cookware could ignite.

Follow these guidelines:

- Use microwave-safe plastics only and use them in strict compliance with the cookware manufacturer's recommendations.
- Do not microwave empty containers.
- Do not permit children to use plastic cookware without adult supervision.

Display	Level	Power
P100	10	100%
P90	9	90%
P80	8	80%
P70	7	70%
P60	6	60%
P50	5	50%
P40	4	40%
P30	3	30%
P20	2	20%
P10	1	10%

Fig. vi. The ten different microwave power levels.

- Turn the Control Knob to select the defrost weight (4-100 oz).
- Press the Control Knob to start defrosting.
- Turn food over when unit beeps twice.
- When the timer is complete, the appliance will beep five times and display "0:00."

- Press the Control Knob to begin the cooking process.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

Menu	Display	Weight
1 Beverage	C1	4 oz, 8 oz, 12 oz
2 Dinner Plate	C2	5 oz, 8 oz, 12 oz, 15 oz, 21
3 Soup	C3	8 oz, 16 oz, 24 oz
4 Potato	C4	8 oz, 16 oz, 24 oz
5 Vegetable	C5	4 oz, 8 oz, 16 oz
6 Oatmeal	C6	8 oz, 16 oz, 28 oz

Fig. vii. The six Micro Menu preset weights.

- 30-90 minutes). Press the Control Knob to begin the preheating process. The Fan Icon will flash to indicate that the appliance is preheating.
- When the appliance has preheated, the Fan Icon will stop flashing and the appliance will display the selected cooking time. Open the door, insert your food and accessories, and close the door. Press the Control Knob to start the timer.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

Using the Air Fry Menu

- Press the Air Fry Menu button.
- Turn the Control Knob to cycle through the 10 preset functions (AF1-AF10; see the "Air Fry Programming" section for preset times and temperatures).
- Once an air frying setting has been selected, press the Control Knob to begin the cooking process.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

French Fries Button

- Press the "French Fries" Button to set the appliance to French Fry mode.
- The LED Display will show "22:00" and begin counting down. Open the door, insert your food and accessories, and close the door.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

Pizza Button

- Press the Pizza Button to set the appliance to pizza mode.
- Press the Control Knob to start preheating the appliance. When the appliance has preheated, the LED Display will show "18:00" and begin counting down. Open the door, insert your food and accessories, and close the door.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

Air Fry Function

- Press the Air Fry Button to set the appliance to air fry mode. "400" will flash on the LED Display.
- Turn the Control Knob to cycle between the available cooking temperatures (300° F/149° C, 325° F/163° C, 350° F/177° C, 375° F/190° C, 400° F/204° C, 425° F/218° C). Press the Control Knob to confirm the cooking temperature.
- Turn the Control Knob to adjust the cooking time. Press the Control Knob to confirm the cooking time and start the timer.
- When the cooking timer is complete, the appliance will beep five times and display "0:00."

Using the Lock and Mute Functions

- When the appliance is in standby mode (see "The Control Panel" section), press the LOCK ON/OFF Button once to mute the appliance. When muted, the appliance's Control Panel and timer will not sound until the LOCK ON/OFF Button is pressed again to unmute the appliance.
- Hold the LOCK ON/OFF Button for 3 seconds to lock and unlock the appliance.

Cooking Guidelines & Tips

Internal Temperature Meat Chart

Use this chart and a food thermometer to ensure that meat, poultry, seafood, and other cooked foods reach a safe minimum internal temperature.

*For maximum food safety, the U.S. Department of Agriculture recommends 165° F for all poultry; 160° F for ground beef, lamb, and pork; and 145° F, with a 3-minute resting period, for all other types of beef, lamb, and pork. Also review the USDA Food Safety Standards.

Food	Type	Internal Temp.*
Beef & Veal	Ground	140°F (70°C)
	Steaks, roasts: medium	145°F (70°C)
	Steaks, roasts: rare	135°F (57°C)
	Breasts	165°F (75°C)
Chicken & Turkey	Ground, stuffed	165°F (75°C)
	Whole bird, legs, thighs, wings	165°F (75°C)
Fish & Shellfish	Any type	145°F (63°C)
	Ground	160°F (70°C)
Lamb	Steaks, roasts: medium	140°F (70°C)
	Steaks, roasts: rare	130°F (55°C)
	Chops, ground, ribs, roasts	160°F (70°C)
Pork	Fully cooked ham	140°F (60°C)

Tips

- Foods that are smaller in size usually require a slightly shorter cooking time than larger ones.
- Large sizes or quantities of food may require a longer cooking time than smaller sizes or quantities.
- Flipping or turning food halfway through the cooking process ensures that the food is evenly cooked.
- Adding a bit of vegetable oil to fresh potatoes is suggested for a crispier result. When adding oil, do so just before cooking and add only a small amount onto the potato.
- Snacks normally cooked in an oven can also be cooked in the appliance.
- Use premade dough to prepare filled snacks quickly and easily. Premade dough also requires a shorter cooking time than homemade dough.
- A baking tin or oven dish can be placed on the Air Fry Rack inside the appliance when cooking foods such as cakes or quiches. Using a tin or dish is also recommended when cooking fragile or filled foods.

804106439



W

PRINTED IN MEXICO / SC:08-04-2021
OBPN:PXL_MAFP_IB_WM_ENG_V1_200619
SHNMDL: BDK02_B / Elbrd:J.E. / TAB

Troubleshooting

Appliance not working as expected? Review the chart for possible causes and solutions. Go to www.Tristarcares.com or Contact a Service Center.

Problem	Possible Cause	Solution
Oven will not heat	Electrical cord for oven is not plugged in.	Plug power cord into wall socket.
	Door is open	Close the door and try again.
	Wrong operation is set.	Check instructions.
Arcing or sparking	Materials to be avoided in microwave oven were used.	Use microwave safe cookware only.
	The oven is operated when empty	Do not operate with oven empty.
	Spilled food remains in the cavity.	Clean cavity with wet towel.
Unevenly cooked foods	Materials to be avoided in microwave oven were used.	Use microwave safe cookware only.
	Food is not defrosted completely.	Completely defrost food.
	Cooking time, power level is not suitable.	Use correct cooking time, power level.
	Too much food is attempted to be cooked.	Cook smaller quantities of food.
Overcooked foods	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Undercooked foods	Materials to be avoided in microwave oven were used.	Use microwave safe cookware only.
	Food is not defrosted completely.	Completely defrost food.
	Oven ventilation ports are restricted.	Check to see that oven ventilation ports are not restricted.
	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Improper defrozing	Too much food is attempted to be cooked.	Cook smaller quantities of food.
	Materials to be avoided in microwave oven were used.	Use microwave safe cookware only.
	Cooking time, power level is not suitable.	Use correct cooking time, power level.
The appliance does not work	Food is not turned or stirred.	Turn or stir food.
	The appliance is not plugged in.	Plug power cord into wall socket.
	The appliance has no heat turned on by setting the preparation time and temperature.	Set the temperature and time.
Food not cooked	The appliance is unplugged into an outlet that is shared with other devices.	Plug the appliance into a dedicated power outlet.
	The appliance is overloaded.	Use smaller batches for more even cooking.
	The temperature is set too low.	Raise temperature and continue cooking.
Food is not fried evenly	Some foods need to be turned during the cooking process.	Check halfway through process and turn food if needed.
	Food of different sizes are being cooked together.	Cook similar sized foods together.
	If using multiple racks, trays need to be rotated.	Rotate trays from top to bottom and vice versa.
White smoke coming from appliance	Oil is being used.	Wipe down to remove excess oil.
	Accessories have excess grease residue from previous cooking.	Clean the components and appliance interior after each use.
French fries are not fried evenly	Wrong type of potato being used.	Use fresh, firm potatoes.
	Potatoes not blanched properly during preparation.	Use cut sticks and pat dry to remove excess starch.
	Too many fries are being cooked at once.	Cook less than 2 1/2 cups of fries at a time.
Fries are not crispy	Raw fries have too much water.	Dry potato sticks properly before mixing oil. Cut sticks smaller. Add a bit more oil.

Radio Interference

Operation of the microwave oven may cause interference to your radio, television, or similar equipment. Interference can be reduced or eliminated by taking the following measures:

- Clean the door and sealing surface of the oven.
- Reorient the receiving antenna of radio or television.
- Relocate the appliance with respect to the receiver.
- Move the appliance away from the receiver.
- Plug the appliance into a different outlet so that the appliance and the receiver are on different branch circuits.

Cleaning & Storage

Cleaning

Clean the appliance after each use. Remove the power cord from the wall socket and be certain the appliance is thoroughly cooled before cleaning.

- Wipe the outside of the appliance with a warm, moist cloth and mild detergent.
- To clean the door, gently scrub both sides with warm, soapy water and a damp cloth. **DO NOT** soak or submerge the appliance in water or wash in the dishwasher.
- Clean the inside of the appliance with hot water, a mild detergent, and a nonabrasive sponge. Do not scrub the heating coils because they are fragile and may break. Then, rinse the appliance thoroughly with a clean, damp cloth. Do not leave standing water inside the appliance.
- If necessary, remove unwanted food residue with a nonabrasive cleaning brush.
- Caked-on food on accessories should be soaked in warm, soapy water to remove the food easily. Hand washing is recommended.

Storage

- Unplug the appliance and let it cool thoroughly.
- Make sure all components are clean and dry.
- Place the appliance in a clean, dry place.

Frequently Asked Questions

- Does the appliance need time to heat up?**
Preheating is needed when you are cooking from a cold start when using the Bake or Air Fry cooking function. Add 3 minutes to the cooking time to compensate when preheating is necessary (preheating is automatic with the Bake and Pizza cooking functions).
- Can I check the food during the cooking process?**
You can check the cooking process at any time by looking through the glass door.
- What happens if the appliance still does not work after I have tried all the troubleshooting suggestions?**
Never attempt home repair. Contact a Service Center. Failure to do so could render your guarantee null and void.

AIR FRY

STEP 1

Insert Food

STEP 2

Set Cooking Mode

STEP 3

Confirm Settings

STEP 4

Remove Food

***Baking Pan (option not supplied)**

MICROWAVE

STEP 1

Insert Food

STEP 2

Confirm Settings

STEP 3

Remove Food

IMPORTANT: Wash with warm, soapy water before first use (only the Glass Tray is dishwasher safe). Read all instructions before using this appliance. Only use provided accessories or accessories described in the instruction Manual. Do not use air fryer accessories while using the microwave function. Inspect all accessories prior to use, and discard if damaged.