

NINJA®

HOT & ICED COFFEE MAKER



"Recipe Book not included"

804106514A

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE • HOUSEHOLD USE ONLY

Read all instructions before using your NINJA® HOT & ICED COFFEE MAKER.

When using electrical appliances, basic safety precautions should always be followed, including the following:

⚠ WARNING

To reduce the risk of fire, electric shock, serious injury, death, or damage when using this appliance, follow these basic safety precautions.

General Precautions

1 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

2 To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **DO NOT** force into outlet or try to modify to fit.

3 Keep the appliance and its cord out of reach of children less than 8 years.

4 To eliminate a choking hazard for young children, remove and discard the protective cover fitted on the power plug of this appliance.

5 Children shall not play with the appliance.

6 To protect against fire, electric shock, and injury to persons, **DO NOT** immerse cord, plugs, or body of machine in water or other liquid.

7 NEVER carry the appliance by the power cord or pull it to disconnect from electrical socket; instead grasp the plug and pull to disconnect.

8 DO NOT operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been dropped or damaged in any manner. Contact a Service center.

9 For household and work top use only. **DO NOT** let the power cord hang over the edge, or touch hot surfaces such as the stove.

10 NEVER use socket below counter.

11 To avoid risk of fire, electrical shock, or damage to the unit, **DO NOT** store or use unit in an appliance garage or under a wall cabinet.

12 Unplug from outlet when either the appliance or display clock is not in use, and before cleaning.

13 Turn off and allow to cool before putting on or taking off parts, and before cleaning the appliance.

Operating Notice

14 The use of an accessory not recommended by the manufacturer may create an overflow condition and scalding hazard, or result in fire, electric shock, or personal injury.

15 ALWAYS use appliance on a clean, dry, level surface.

16 DO NOT place on or near a hot gas or electric burner or in a heated oven.

17 DO NOT use this appliance for anything other than its intended use.

18 DO NOT use outdoors.

19 DO NOT touch hot surfaces. Use handles or knobs.

20 ALWAYS place a vessel beneath the brew basket to receive the brewed coffee.

21 Scalding may occur if brew basket is opened during a brew or clean cycle.

22 DO NOT remove the vessel while the appliance is running without the Drip Stop in the closed position. Return the vessel quickly and open the Drip Stop to continue the brew.

23 DO NOT fill water reservoir with anything other than water, as other liquids may damage your brewer.

24 DO NOT overfill the water reservoir. Fill water only to the Max Fill line.

25 DO NOT run the appliance without water.

26 Exceeding maximum brew basket capacity may cause overflow. **DO NOT** use fine or espresso ground coffee.

Glass Carafe

27 The carafe is designed for use with this appliance only. **DO NOT** place carafe on or near a hot gas or electrical burner, or in a heated oven.

28 DO NOT set a hot carafe on a wet or cold surface.

29 DO NOT use a cracked or scratched carafe or a carafe that has a loose or weakened handle.

30 DO NOT clean carafe with abrasive cleaners, steel wool pads, or other abrasive materials.

31 DO NOT place carafe in microwave.

32 DO NOT expose carafe to extreme temperature changes.

33 DO NOT drink directly from the carafe. Liquid from the carafe may be very hot.

34 DO NOT use the carafe to store food when not in use.

35 Ensure the carafe is completely empty before starting a cleaning or brewing cycle. Starting a cycle with water, coffee, or tea in the carafe will cause an overflow.

Care & Maintenance

36 Allow the appliance to cool before removing any parts and before cleaning.

37 To prevent illness from bacterial growth in the appliance, follow all cleaning instructions in the Care & Maintenance section of this Owner's Guide.

38 Clean the system on a weekly basis.

39 If the product is not operating properly, contact a Service center.

40 Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

Cord Statement


41 A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

42 DO NOT use extension cords with this product.

PARTS

NOTE: CLEAN BEFORE USE

- A CoffeeMaker (power cord & storage not shown)
- B Showerhead
- C Swinging Brew Basket
- D Control Panel
- E Single-Serve Cup Platform
- F Ninja Smart Scoop™
- G Flip-Top Water Reservoir Lid
- H Removable Water Reservoir
- I Removable Filter Holder
- J Ninja Carafe
- K Brew-Through Lid
- L Intelligent Warming Plate (not available on all models)



NOTE: The image shown here is for illustrative purposes only and may be subject to change.

NOTE: The actual number of accessories may vary depending on the model.

TECHNICAL SPECIFICATIONS


Voltage: 120V~, 60Hz

Water Reservoir Capacity: 50 oz.

PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

These instructions are designed to help you get a complete understanding of your new Hot & Iced Coffee Maker.

USING THE CONTROL PANEL



Not all functions are available on all models.

- 1 Programmable Digital Clock
- 2 Hour & Minute Buttons
- 3 Stay Warm Indicator/Button (not available on all models)
- 4 Delay Brew Button
- 5 Multi-Serve Dial
 - a Cup
 - b XL Cup
 - c Travel Mug
 - d XL Multi-Serve
 - e Half Carafe
 - f Full Carafe
- 6 Custom Brews
 - a Classic Brew
 - b Rich Brew
 - c Over Ice Brew
- 7 Drip Stop Indicator
- 8 Intelligent Clean Cycle Indicator/Button
- 9 Power Button

NOTE: The image shown here is for illustrative purposes only and may be subject to change. The actual descriptions of control panel and their locations may vary, depending on the model.

PREPARING FOR USE


Remove all packaging material and stickers from the coffee maker.

Wash the water reservoir, carafe, removable filter holder, and permanent filter (not available on all models) in warm, soapy water with a soft cloth. Rinse parts and dry thoroughly.

Before first use, prime the system by running a Full Carafe, Classic brew cycle with water only. After the cycle is complete, discard the water. For detailed instructions, refer to the Priming Your Ninja Hot & Iced Coffee Maker section.

PLEASE KEEP THIS IMPORTANT SAFEGUARD IN MIND WHEN USING THE APPLIANCE: **DO NOT** run the appliance without water.

SETTING THE CLOCK



- 1** When the unit is plugged in, the clock will flash on the control panel to indicate that the time has not been set.
- 2** Press the hour (H) or minute (M) button until you reach the current time. The AM or PM indicator will illuminate on the left side of the display as you are setting the time.
- 3** After 5 seconds, the clock will stop flashing and the clock will be set. To set the clock at the displayed time.

NOTE: If the clock stops flashing and does not display the correct time of day, pressing the hour (H) or minute (M) button at any time will cause the clock to flash again. You can now reprogram the correct time by following the previous steps.

NOTE: If you unplug the coffee maker or in the event of an extended power loss, you will need to reset the clock the next time the coffee maker is plugged in.

HIGH-ALTITUDE CALIBRATION BREW

Required for users in high-altitude areas. Not running the high-altitude calibration brew in a high-altitude area will result in excessive steaming during brewing.

Because water boils at lower temperatures at higher altitudes, running a calibration cycle before your first brew allows the unit to detect the boiling point of water at your location. Running a calibration cycle will help deliver a consistent brew each time.

- 1** Fill the water reservoir up to, but not exceeding, the Max Fill line.
- 2** Place the empty filter holder into the brew basket, and an empty vessel in the machine.
- 3** Press and hold both **CLASSIC** and **OVER ICE** until clock displays **CAL**.

4 A calibration cycle will begin. When complete, the unit will beep and **End** will appear on the clock display. Discard the water in the vessel.

NOTE: Pressing the CLASSIC, OVER ICE, or Power button will cancel the calibration cycle.

NOTE: This calibration is permanently saved and will not be lost if power is lost or brewer is unplugged. Brewer can be re-calibrated at anytime if the altitude where it is being used changes.

USING YOUR NINJA® HOT & ICED COFFEE MAKER

MEASURING YOUR COFFEE GROUNDS

For best results, use the measurements on the Ninja Smart Scoop™ or in the chart to the right to determine how much ground coffee to use for each brew size. The amount of ground coffee for each size will remain the same for any brew type you select. For example, if you select Cup and CLASSIC, you will use the same amount of coffee grounds as if you select Cup and OVER ICE.

NOTE: Measurements are based on level scoops—adjust to your preferred taste. More scoops result in stronger coffee but slightly lower volumes; fewer scoops result in weaker coffee and slightly higher volumes. Use a medium-sized grind if grinding whole beans. Grinding beans too finely may cause the brew basket to overflow.

NOTE: Decaffeinated coffee absorbs water differently than regular coffee grounds. Use fewer scoops to prevent overflow.

Serving Size	Ninja Smart Scoop*	Tablespoons
Cup/XL Cup	2-3 small scoops	2-3 Tbsp.
Travel Mug/XL Multi-Serve	3-5 small scoops	3-5 Tbsp.
Half Carafe	3-4 big scoops	6-8 Tbsp.
Full Carafe	4-6 big scoops	8-12 Tbsp.

USING THE BREW BASKET

1 Open the brew basket by swinging it out of the coffee maker.

Insert the Filter Holder in the brew basket.




2 Place a #4 paper cone filter in the filter holder or if your unit comes with a permanent filter, place it in the filter holder.

NOTE: If using a paper filter, first ensure the permanent filter is removed from the filter holder. Then fold the paper filter along the seams, open it fully, and firmly press it into the filter holder, making sure it is fully seated.



3 Use the Ninja Smart Scoop™ and follow the measurements on the scoop to fill the filter.



4 Slide the brew basket back into the coffee maker until it clicks into place.




PRIMING YOUR NINJA HOT & ICED COFFEE MAKER

1 Clean all accessories before your first brew. Plug in unit and power it on.

NOTE: We recommend fresh, cool, filtered water. Well water is not recommended.


2 Lift the Water Reservoir to the right and up off the coffee maker. Flip the Reservoir Lid open or remove the entire lid. Add water up to, but not exceeding, the Max Fill line. Return the water reservoir to the coffee maker.

DO NOT fill water reservoir with anything other than water, as other liquids may damage your coffee maker.



3 Insert the Filter Holder into the Swinging Brew Basket. Close the brew basket until you hear a slight click.


NOTE: **DO NOT** place any ground coffee in the brew basket.



5 With everything securely in place and the unit powered on, select the Full Carafe size and press CLASSIC.

When the cycle is complete, discard the water in the carafe.

You are now ready to use your Ninja Hot & Iced Coffee Maker.



HOW MUCH DO YOU GET IN YOUR CUP?

Each size and brew style produces a different amount of coffee to optimize strength and taste.

NOTE: The coffee grounds will absorb some of the water that is brewed, resulting in slightly less brewed coffee than water used.

NOTE: There may be some water left in the reservoir after your brew. This is normal and keeps the brewer from running out of water.

NOTE: Brew volumes may be slightly larger or smaller than what is stated due to various factors in the system.

APPROXIMATE BREW VOLUMES

Size	Classic	Rich	Over Ice	
			coffee	filled with ice
Cup	9.5 oz.	8.7 oz.	3.8 oz.	9.5 oz.
XL Cup	11.5 oz.	10.3 oz.	4.7 oz.	11.5 oz.
Travel Mug	14 oz.	13.2 oz.	5.8 oz.	14 oz.
XL Multi-Serve	18 oz.	16 oz.	7.3 oz.	18 oz.


USING THE DRIP STOP

Can't wait for the first cup?
The drip stop is used to close off the brew basket to prevent any coffee from dispensing. You will need to manually open and close the drip stop by moving the lever to your desired position. It can be closed and reopened at any point before, during, or after a brew.

When brewing a carafe, close the Drip Stop to pause the brew cycle and pour a cup. Promptly replace the carafe and open the Drip Stop to complete the brew.

If you forget to open the Drip Stop, the coffee maker will pause the brew, and after 20 seconds it will give you a friendly audible reminder. After 6 minutes, the brew will be canceled.


NOTE: If the Drip Stop is closed before you begin a brew, the coffee maker will notify you with 5 beeps and the Drip Stop indicator will illuminate. Set the Drip Stop to the open position and select your brew type.



CLOSING THE DRIP STOP AFTER A BREW

When the brew cycle is complete, set the Drip Stop to the closed position to stop dripping from the brew basket. While the Drip Stop is closed, the Drip Stop indicator will illuminate.

NOTE: Remember to open the Drip Stop when you are ready to brew again. If you forget, your coffee maker will give you a friendly audible reminder.




CUSTOM BREWS



NOTE: For single cup, lower the Single-Serve Cup Platform and set your vessel in the center of it. Ensure you are using at least a 12 oz. cup for the Cup size, 14 oz. cup for the XL Cup size, 16 oz. travel mug for the Travel Mug size, and 20 oz. travel mug for the XL Multi-Serve size.

CLASSIC AND RICH BREWS

NOTE: Rich brew will yield slightly less brewed coffee than Classic brew. See Approximate Brew Volumes chart for more information.



Use the Multi-Serve Dial to select the brew size. Place the empty vessel you would like to brew into under the brew basket.




To start a brew, press CLASSIC or RICH. The brew will begin, stop, and pause for a short period of time before it begins again. This process ensures even saturation of the coffee grounds. The unit will beep when the brew has completed.

To cancel a brew, press CLASSIC or RICH again. The screen will display "StOP."

NOTE: The unit will not beep when the brew starts. If "StOP" displays on the screen, the brew has been canceled. Press CLASSIC or RICH to begin the brew again.

OVER ICE BREW




Use the Multi-Serve Dial to select the brew size. Fill your desired vessel to the top with ice cubes and place the vessel below the brew basket.

NOTE: DO NOT use any glassware except for the Ninja® glass carafe, which is safe to use due to its specialized glass material.

IMPORTANT: Always fill the desired vessel to the top with ice before placing it below the brew basket. DO NOT add ice to the water reservoir.

NOTE: It is normal for some ice in the vessel to melt as the coffee is brewed. This will produce a cold beverage with the ideal strength and flavor.

NOTE: The unit will not beep when the brew starts. If "StOP" displays on the screen, the brew has been canceled. Press OVER ICE to begin the brew again.



To start a brew, press OVER ICE. The brew will begin, stop, and pause for a short period of time before it begins again. This process ensures even saturation of the coffee grounds. The unit will beep when the brew has completed.


To cancel a brew, press OVER ICE again. The screen will display "StOP."

INTELLIGENT WARMING PLATE

The Intelligent Warming Plate will automatically turn on during a Half or Full Carafe size of Classic or Rich brew. The Intelligent Warming Plate is set to a specific temperature target to avoid burning the coffee over time.

IMPORTANT: The HOT SURFACE indicator will illuminate when the warming plate is hot.

Thermal carafe (CM305) does not include a warming plate because of the thermal carafe's vacuum insulation.




STAY WARM BUTTON

Press STAY WARM after the brew to turn the Intelligent Warming Plate off. To turn on the Intelligent Warming Plate on at any time, turn the dial to one of the carafe sizes and press STAY WARM.

This feature is not available on all models.

IMPORTANT: The HOT SURFACE indicator will remain illuminated until the warming plate has cooled to a safe temperature.




TIME & TEMPERATURE ADJUSTMENT

You can adjust how long the Intelligent Warming Plate remains on (up to 4 hours) and/or set the temperature to High or Low. By default, the Intelligent Warming Plate is set to remain on for 2 hours, and is set to High to keep your coffee hot. The Low setting keeps your brew at a slightly lower temperature to preserve flavor longer.


This feature is not available on all models. To change the time/temperature settings of your warming plate, follow these instructions:

1 Press and hold STAY WARM until the clock begins to flash the current warming time.



2 Quickly press the hour (H) and/or minute (M) buttons to increase the time up to 4 hours or decrease the time to 0 hours. Press STAY WARM to set the new time. Or wait 5 seconds, and the unit will beep, signifying the new time has been set.


Setting the time to 0 hours will result in the stay warm function not coming on automatically while brewing. To manually turn it on or off, press the STAY WARM button.



3 Next, the clock will display the current warming plate temperature. To keep the same temperature, press STAY WARM, or wait 5 seconds for the same temperature to lock in. To change the temperature, press the hour (H) or (M) buttons, then press STAY WARM, or wait 5 seconds for the temperature to lock in.


NOTE: If you set the warming time to 0 hours, it will skip the warming temperature menu.

NOTE: If the warming plate is set to 0 hours, the Intelligent Warming Plate will not automatically activate during a carafe brew cycle.



CLEANING & MAINTENANCE

DELAY BREW



NOTE: The unit must remain on for the Delay Brew function to work. DO NOT power off or unplug after setting Delay Brew.

IMPORTANT: Make sure the Drip Stop is in the open position.

- 1 Plug in the unit and turn it on by pressing the power button.
- 2 After filling the water reservoir and adding ground coffee to the filter holder, be sure the reservoir and brew basket are securely in place. Place the appropriate-size vessel under brew basket.
- 3 Press DELAY BREW. DELAY BREW will illuminate and the clock will begin to flash "12:00" or the last Delay Brew time that was set.
- 4 Once the proper time has been set, select the size of the vessel that you would like to brew into.
- 5 Select the brew style that you desire from the 3 flashing buttons. The selected brew style will remain illuminated.
- 6 Once the time, brew size, and brew style have been set, allow DELAY BREW to stop flashing, or press DELAY BREW to activate. When activated, the unit will beep and DELAY BREW and your selected options will remain illuminated. To cancel, press DELAY BREW again.

NOTE: If you attempt to change your selections while Delay Brew is set, the unit will beep and DELAY BREW will flash. To change your selections, cancel DELAY BREW.

CARE & MAINTENANCE

After each Brew

NOTE: For best results, we recommend rinsing the reservoir after brewing and refilling with fresh water for the next brew.

- 1 After the unit has cooled, remove the filter holder from the brew basket. If using a paper filter, discard it. If using the permanent filter, wash it thoroughly with soap and warm water or place on top rack of dishwasher.
- 2 Wash the carafe and brew-through lid with soap and warm water. Use a bottle brush or a cloth to wash the inside of the carafe. DO NOT use a wire brush.

NOTE: The glass carafe, brew-through lid, removable filter holder, permanent filter, water reservoir, flip-top lid, and scoop are dishwasher safe.

- 3 After the coffee maker has cooled, wipe down the main unit, showerhead, and water reservoir shelf with a cloth and warm water. **DO NOT** immerse the coffee maker in water.

CLEANING THE WATER RESERVOIR

Empty the water reservoir and hand-wash or place in your dishwasher. For a better clean, we recommend placing it on the bottom rack of the dishwasher standing upright with the opening facing downward. We recommend doing this weekly.

CLEANING THE CARAFE

We recommend cleaning your carafe with warm, soapy water.

If you want to clean the carafe more thoroughly, we recommend using a soft foam brush, or placing it in the dishwasher (glass carafe only). **DO NOT** use a wire brush.

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

