



NINJA SIZZLE™ PRO XL 20-INCH INDOOR GRIDDLE + GRILL

814100550

“CLEAN BEFORE USE”



“RECIPE BOOK NOT INCLUDED”

IMPORTANT SAFETY INSTRUCTIONS

INDOOR HOUSEHOLD USE ONLY • READ ALL INSTRUCTIONS BEFORE USE

	Read and review instructions to understand operation and use of product.
	Indicates the presence of a hazard that can cause personal injury, death or substantial property damage if the warning included with this symbol is ignored.
	Avoid contact with hot surface. Always use hand protection to avoid burns.
	For indoor and household use only.


⚠ WARNING To reduce the risk of injury, fire, electrical shock or property damage, basic safety precautions must always be followed, including the following numbered warnings and subsequent instructions. Do not use appliance for other than intended use.

- 1 To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- 2 This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 3 Keep the appliance and its cord out of reach of children. **DO NOT** allow the appliance to be used by children. Close supervision is necessary when used near children.
- 4 This appliance is for household use only. **DO NOT** use this appliance for anything other than its intended use. **DO NOT** use in moving vehicles or boats. **DO NOT** use outdoors. Misuse may cause injury.
- 5 To reduce the risk of fire, **DO NOT** place on or near a hot gas or electric burner or in a heated oven.
- 6 Ensure the surface is level, clean and dry. **DO NOT** place the appliance near the edge of a countertop during operation.
- 7 **ALWAYS** ensure the appliance is properly assembled before use. **DO NOT** place appliance on or near a gas oven or electric stovetop, or in a heated oven.
- 8 When using this appliance, provide at least 6 inches (15.25 cm) of space above and on all sides for air circulation.
- 9 **DO NOT** use an extension cord. A short power-supply cord is used to reduce the risk of children grabbing the cord or becoming entangled and to reduce the risk of people tripping over a longer cord.
- 10 To protect against electrical shock **DO NOT** immerse cord, plugs, or main unit housing in water or other liquid.
- 11 **DO NOT** use the appliance if there is damage to the power cord or plug. Regularly inspect the appliance and power cord. If the appliance malfunctions or has been damaged in any way, immediately stop use and
- 12 **NEVER** use outlet below countertop surface.
- 13 **DO NOT** place appliance and let cord hang over edges of tables, counters or touch hot surfaces.
- 14 Only use recommended accessories included with this appliance. The use of accessories or attachments not recommended
- 15 Before placing any accessory into the cooker, ensure they are clean and dry.
- 16 **DO NOT** move the appliance when in use.

- 17 **DO NOT** touch hot surfaces. Appliance surfaces are hot during and after operation. To prevent burns or personal injury, **ALWAYS** use protective hot pads or insulated oven mitts and use available handles and knobs.
- 18 **DO NOT** touch accessories during or immediately after cooking. The grill plate becomes extremely hot during the cooking process. Avoid physical contact while removing the accessory from the appliance. To prevent burns or personal injury **ALWAYS** use care when interfacing with product. Recommend use of long-handled utensil and protective hot pads or insulated oven mitts.
- 19 **DO NOT** use this appliance for deep-frying.
- 20 To prevent possible illness, **ALWAYS** use an external food thermometer to check that your food is cooked to the recommended temperatures.
- 21 Should a grease fire occur or the unit emits black smoke, unplug immediately. Wait for smoking to stop before removing any cooking accessories.
- 22 Please refer to the Cleaning & Maintenance section for regular maintenance of the appliance.
- 23 To disconnect, turn unit to “OFF,” then unplug from socket when not in use and before cleaning.
- 24 Allow to cool before cleaning, disassembling, putting in or taking off parts, or storing.
- 25 **DO NOT** clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- 26 Cleaning and user maintenance shall not be done by children.
- 27 Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

SAVE THESE INSTRUCTIONS.

GETTING TO KNOW THE NINJA SIZZLE™ PRO XL 20-INCH INDOOR GRIDDLE + GRILL



NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

BEFORE FIRST USE

- 1 Remove and discard any packaging material and tape from the unit.
- 2 Remove all accessories from the package and carefully read the manual before use. Please pay particular attention to operational instructions, warnings, and important safeguards to avoid any injury or property damage.
- 3 Wash the grill plate with a damp, soapy cloth, then wipe with a clean, damp cloth and dry thoroughly. NEVER submerge the main unit in water.
- 4 We recommend turning the unit on and running it on 400°F for 10 minutes without adding food. Make sure the area is well ventilated. This removes any packaging residue and odor traces that may be present. This is completely safe and not detrimental to the performance of the grill.

RECOMENDED COOKING TEMPERATURES

Always use the recommended grill settings. Our chef-designed temperature settings maximize grill flavors and textures.

325°F	375°F	400°F	500°F
When using thicker barbecue sauces Burgers	Frozen meats Marinated proteins or proteins with sauce Bacon Steaks Chicken Salmon	Hotdogs Pancakes Fried eggs Grilled cheese	Veggies Fruit Fresh/Frozen seafood

If using oil or fat during the cooking process, we recommend using oils with high smoke points. For best results, Canola, Refined Coconut, Avocado, Vegetable, or Grapeseed oils are recommended. Olive Oil, Butter, Margarine, or aerosol cooking sprays are NOT recommended.

COOKING WITH GRILL/GRIDDLE MODE

- 1 To install the grill or griddle plate, position it over the base with the grease chimney toward the front. Place the grill plate down, ensuring the sides align with the exterior of the base.
- 2 Make sure the unit is plugged in, push the power button.
- 3 The unit will default to Grill/Griddle Mode.
- 4 Use the dial to select Low, Medium, or High,
- 5 Press the Time button and use the dial to program your time. The unit will default to 15 minutes. When finished, press the START/STOP button to start preheating.
- 7 After preheating is complete, the unit will beep and display "ADD FOOD". Push the START/STOP button to start the timer, or wait 15 seconds and it will start automatically.

NOTE: The unit can be used with the lid open or closed.

NOTE: Not all models have a built-in timer.

CUSTOM TEMP INSTRUCTIONS

- 1 To install the grill or griddle plate, position it over the base with the grease chimney toward the front. Place the grill plate down, ensuring the sides align with the exterior of the base.
- 2 Make sure the unit is plugged in, push the power button.
- 3 Use the Mode button to select Custom Temp.
- 4 The unit will default to 350°F. Use the dial to choose your desired temperature from a range of 250-500°F.
- 5 Press the Time button and use the dial to program your time. The unit will default to 15 minutes. When finished, press the START/STOP button to start preheating.
- 6 After preheating is complete, the unit will beep and display "ADD FOOD". Push the START/STOP button to start the timer, or wait 15 seconds and it will start automatically.

NOTE: Not all models have a built-in timer.

INSTALLING AND REMOVING THE SLOTTED LID

- 1 After allowing the unit to cool, remove the lid by opening it until it is approximately vertical. Then lift the lid straight up out of the hinge base.
- 2 To install the lid, hold it vertically with the handle facing up and the hinge pivots over the hinge base. Ensure that the flat sections of the hinge pivots are oriented vertically. Lower the lid hinge pivots into the hinge base, then close the lid.

CLEANING YOUR GRILL

The unit should be cleaned thoroughly after each use. Always let the appliance cool before cleaning.

- 1 Unplug the unit from the wall outlet before cleaning. Keep the lid open after removing your food to allow the unit to cool quicker.
- 2 To prolong the nonstick coating of the grill plate, we recommend hand-washing in warm, soapy water then air- or towel-drying all parts. The slotted lid is dishwasher safe.

NOTE: When cleaning the grease catch, let the oil cool and then easily scrape off.

- 3 If food residue or grease is stuck on the grill plate, splatter lid, or any other removable part, soak in warm, soapy water before cleaning.
- 4 To clean the base heating unit of the grill, use a damp, soapy cloth, then wipe with a clean, damp cloth and dry thoroughly.

NOTE: NEVER use abrasive tools or cleaners. NEVER immerse the main unit in water or any other liquid. Do not place in dishwasher.

TROUBLESHOOTING GUIDE

- **Why is the unit emitting smoke?**
When using the Grill/Griddle function, always select the recommended temperature setting. Recommended settings can be found in the Quick Start Guide and in the Inspiration Guide. Make sure the slotted lid is installed.
- **Why did a circuit breaker trip while using the unit?**
The unit uses 1800 watts of power, so it must be plugged into an outlet on a 15-amp circuit breaker. Using an outlet on a 10-amp breaker will cause the breaker to trip. It is also important that the unit be the only appliance plugged into an outlet when in use. To avoid tripping a breaker, make sure the unit is the only appliance plugged into an outlet on a 15-amp breaker.

The images shown in this manual are for illustrative purposes only and may be subject to change.

PRINTED IN MEXICO SC: 8/19/2025
Elbrd: J.L
SHMDL: GX101_B
OBPN: GX100Series_IB_15_MP_Mv3_250107

8 1 4 1 0 0 5 5 0
