






NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process.

For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.



1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following.

- Read all instructions carefully.
- Make sure the voltage of your electrical system corresponds to the voltage shown on the bottom of the machine.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electrical shock and personal injury, do not immerse cord, plug or appliance in water or other liquid.
- Keep the appliance out of the reach of children and do not leave appliance unattended while in operation.
- Close supervision is necessary when any appliance is used by or near children
- Unplug from the outlet when not in use and before cleaning.
- Do not operate with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner. Contact a service center.
- The use of accessory attachments not recommended by the manufacturer may result in fire, electrical shock, or personal injury.
- Do not use outdoors.
- Make sure the power cord does not hang over the edge of the table or counter-top to avoid getting accidentally caught or entangled.
- Do not place the appliance or its electrical parts on or near electric stoves, cooking surfaces, or gas burners.
- Plug cord into the wall outlet. To disconnect, first turn machine "off", then remove plug from wall outlet.
- Do not use the appliance for other than the intended use. This appliance is to be utilized for domestic use only. It is not intended to be used in: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments. The manufacturer declines all responsibility for any damage caused by improper, incorrect, or irresponsible use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the SUPPLY CORD is damaged, it must be replaced. Contact a service center.
- **WARNING:** To avoid the risk of injury, do not open the brewing chamber during the brewing process.

- The surface of the heating element remains hot after use and the outside of the appliance may retain the heat for several minutes depending on use.
 - Clean all the components thoroughly, taking particular care with parts in contact with the milk.
 - **IMPORTANT:** To prevent damage to the appliance, do not clean with alkaline detergents; use a soft cloth and, where applicable, neutral detergent.
 - Appliances with removable cord: avoid splashes of water on the power cord connector or socket at the back of the appliance.
 - **IMPORTANT:** Models with glass surfaces: do not use the appliance if the surface is cracked.
 - The coffee maker must not be placed inside a cabinet or kitchen unit during use.
 - The cleaning and user maintenance shall not be made by children without supervision.
- WARNING:** To reduce the risk of fire or electric shock, do not remove the cover or the exterior of the unit. Don't attempt to repair or modify the machine, doing so will void the warranty. Repair should be done by authorized service personnel only!

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

SHORT CORD INSTRUCTIONS

- A short power cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer, detachable power supply cords or extension cords are available and may be used if care is exercised in their use.
- If an extension cord is used, the marked electrical rating should be at least as great as the electrical rating of the appliance. If the appliance is provided with 3- wire, grounding type cord, the extension should be a GROUNDING TYPE 3 - WIRE CORD. The longer cord should be arranged so that it will not drape over the counter-top or table top where it can be pulled on by children or tripped over.
- Your product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

2. BEFORE USE

2.1 Checking the appliance

After removing the packaging, make sure the product is complete and undamaged and that all accessories are present. Do not use the appliance if it is visibly damaged. Contact a Service Center.

2.2 Installing the appliance

When you install the appliance, you should respect the following safety warnings:

- Use this appliance on a horizontal and stable surface.
- The appliance gives off heat. After positioning the appliance on the worktop, leave a space of at least 3 cm/ 1.18" between the surfaces of the appliance and the side and rear walls and at least 15 cm/ 5.90" above the coffee maker.
- Water penetrating the appliance could cause damage. Do not place the appliance near taps or sinks.
- The appliance could be damaged if the water it contains freezes. Do not install the appliance in a room where the temperature could drop below freezing point.
- Arrange the power cord in such a way that it cannot be damaged by sharp edges or contact with hot surfaces (e.g. electric hot plates).

2.3 Connecting the appliance

Check that the mains power supply voltage corresponds to that indicated on the rating plate on the bottom of the appliance. Connect the appliance to an efficiently earthed and correctly installed socket with a minimum current rating of 13A only.

If the power socket does not match the plug on the appliance, have the socket replaced with a suitable type by a qualified professional.

2.4 Setting up the appliance

The first time you use the machine, the water circuit is empty and the appliance could be very noisy. The noise becomes less as the circuit fills.

2.5 What water to use?

- Potable fresh water is recommended.
- Do not use sparkling (carbonated) or distilled water

2.6 Cleaning and maintenance of materials in contact with food

- When utilized for the first time, or after 3 days without use, clean the appliance and the removable accessories that come into contact with water, coffee and milk, as indicated in the instructions for use. Check in the instructions which accessories are dishwasher safe.

2.7 Making cappuccinos and milk-based drinks

- The machine can be used both with cow's milk and with plant-based beverages.
- Do not use raw milk.
- Use pasteurized or UHT milk, or plant-based beverages kept and stored in accordance with the indications given by the producer.
- The cleaning methods described in the instructions do not warrant the complete removal of allergens.
- Before dispensing any kind of drink, make certain that the machine has not been operated previously using types of milk, or types of plant-based beverage, containing allergens to which you may be allergic or substances you may be intolerant to.
- In the event that unused milk or plant-based beverage may be left in the jug, this can be kept in the refrigerator for further use, observing the indications for storage given by the producer of the beverage, and under no circumstances for longer than 2 days. If the milk jug is not returned to the refrigerator, empty the contents and clean the jug as described in the instruction manual.

3. INTRODUCTION

3.1 Letters in brackets

The letters in brackets refer to the description of the appliance.

3.2 Troubleshooting and repairs

In the event of problems, first try and resolve them by reading the information given in sections "21. Displayed messages" and "22. Troubleshooting".

If this does not resolve the problem or further information is required, Contact a Service Center.

4. DESCRIPTION

4.1 Description of the appliance (A)

A1. Bean hopper
A2. Grinding coarseness regulator
A3. Brewing unit
A4. Brewing unit door
A5. Water tank housing
A6. Water tank lid
A7. Water tank
A8. Coffee grounds container
A9. Coffee grounds container support
A10. Cup tray
A11. Tray grille
A12. Drip tray
A13. Coffee spouts (adjustable height)
A14. Accessories connector with lid
A15. Hot water spout housing
A16. Removable pre-ground coffee funnel
A17. Accessories storage lid
A18. Power cord

4.2 Description of the control panel (B)

B1. ON/Standby
B2. "Coffee" drinks menu
B3. "Milk" drinks menu
B4. "Profile" selection

4.3 Description of the homepage (main screen) (C)

C1. Selected profile
C2. Coffee routine icon
C3. Bean Adapt Technology
C4. Indicator lights:

- Energy saving active light
- Milk carafe cleaning required light
- Descaling required light
- Filter exhausted light

C5. Settings
C6. Drink customizing
C7. Drink selection

4.4 Description of the accessories (D) (*different for type and number according to model)

D1. "Total Hardness Test" indicator paper
D2. Pre-ground coffee scoop/cleaning brush
D3. Water softener filter
D4. Hot water spout
D5. Bean hopper with upper lid (2 in pack)
D6. Grinder protection lid
D7. Extractable funnel

4.5 Description of milk carafe (E)

Lattecrema HOT


E1. Froth adjustment/Clean dial
E2. Milk carafe lid
E3. Milk spout (adjustable height)
E4. Milk spout extension
E5. Milk container
E6. Milk intake tube
E7. Milk carafe connector (removable for cleaning)

5. SETTING UP THE APPLIANCE

Please note:

- Possible traces of coffee in the grinder are the result of settings tests performed on the appliance before sale, proof of the meticulous care and attention we invest in our products.
- The first time you use the appliance, all removable accessories (milk carafe (E), water tank (A7) and (A6), hot water spout (D4)) which come into contact with water or milk should be rinsed with hot water. We recommend washing the milk carafe in a dishwasher.

1. Connect the power cord (A18) to the mains supply (fig. 1).



The machine switches on and leads you to set it up: follow the instructions on the display and your machine will be ready for coffee!

Select your language:

2. Press the flag corresponding to the desired language, then press "Done" for next step.


Set time and day

3. Set time zone, then press "Next".

4. Set current day and time, then press "Next".


Fill the water tank

5. Remove the water tank (A7) (fig. 2) and fill to the MAX line with fresh potable water (fig. 3), then press "Next".



Set up the machine

6. Open the accessories storage lid (A17) and take out the hot water spout (D4) (fig. 4).




7. Slide down the accessory connector lid and insert the hot water spout (fig. 5). Press "Next".

8. Check that the grinding coarseness regulator (A2) is on "5", then press "Next".

9. Remove the grinder protection lid (D6). Press "Next".


Insert the bean hopper

10. Take one bean hopper (D5), turn it upside down and ensure the lower part is closed well rotating it until it clicks (fig. 6). The bean hopper is correctly closed when the two arrows are aligned (fig. 7). Press "Next".



11. Fill the bean hopper with coffee beans. Press "Next".

12. Insert the bean hopper in its housing and rotate it clockwise to lock it. For correct operation, align the "unlock" symbol to the mark on the ring (fig. 8) and, once inserted, rotate it to the "lock" position (fig. 9). Press "Next".



Prime the machine

13. Place a container with a minimum capacity of 200 ml/6.76 fl oz under the coffee spouts (A13) and hot water spout (fig. 10).

14. Press "Yes" to start rinsing. Wait until delivery automatically stops.

9. Place an empty 1,5 l / 50.7 fl oz container under the spouts (fig. 39). Press "Done": design starts ("Back" to go back to the previous screen or "X" to exit the procedure, remembering to remove the descaling solution from the tank)

Important! Danger of scalding

Hot water containing acid flows out of the spouts. Take care to avoid contact with splashes of this solution.

10. The descale program starts and the descaler liquid comes out of the hot water and coffee spouts. A series of rinses is performed automatically to remove all the scale residues inside the coffee machine;
- After about 20 minutes, the descaling action ceases;
11. The appliance is now ready to be rinsed through with clean water. Empty the container used to collect the descaler solution. Remove the water tank, empty, rinse under running water, fill with fresh potable water up to the MAX level and put back in the appliance (fig. 40). Press "Next";



12. Place the container used to collect the descaler solution empty under the spouts and press "Yes" to start rinsing;
13. Hot water is delivered from both the hot water spout and coffee spouts;
14. When the water in the tank has run out, empty the container used to collect the rinsing water;
15. Extract the water tank and put back the water softener filter if removed previously.
16. Fill the tank with fresh water up to the MAX level, put back in the appliance and press "Next" to continue.
17. Place the container used to collect the descaler solution empty under the spouts and press "Next" to start another rinsing cycle;
18. When the water in the tank has run out, empty the container used to collect the rinsing water, remove and empty the drip tray (A12) and grounds container (A8), then put back in the appliance. Press "Next".
19. The descaling process is now complete". Press "OK".
20. Extract the water tank, top up to the max level and put it back in the machine
21. The appliance performs a rapid preheat cycle and then goes back to the homepage.

Please note:

- If the descaling cycle is not completed correctly (e.g. electrical power failure) the appliance will request to complete it next time you switch it on;
- After descaling, it is normal for the grounds container (A8) to contain water.
- If the water tank has not been filled to the MAX level after descaling, the appliance prompts for a third rinse to ensure that the descaler solution has been completely eliminated from the machine's internal circuits. Before starting rinsing, remember to empty the drip tray.


20. WATER SOFTENER FILTER

Certain models are fitted with a water softener filter (D3). If this is not the case with your model, you are recommended to purchase one. Contact a Service Center.

To use the filter correctly, follow the instructions below.

20.1 Installing the filter


1. Press the settings menu (C5);
2. Scroll through the pages and select "Water filter";
3. Press "Yes" to enter the guided procedure
4. Remove the filter from the packaging and turn the date indicator to view the next 2 months (fig. 41);



Please note:

The filter lasts about two months if the appliance is used normally. If the machine is left unused with the filter installed, it will last a maximum of 3 weeks.

5. Press "Next" to continue ("Back" to go back to the previous screen; "X" to cancel the operation);
6. To activate the filter, run potable water through the hole in the center of the filter until water comes out of the openings at the side for more than a minute (fig. 42). Press "Next";
7. Extract the water tank (A7) (fig. 2) and fill with potable water; insert the filter in the water tank and immerse the bottom pressing the center of the filter 2 or 3 times to enable the air bubbles to escape (fig. 43). Press "Next";



8. Insert the filter in the filter housing (fig. 44) and push it down firmly. Close the tank with its lid (A6) and; press "Next";
9. Insert the hot water spout (D4). Press "Next";
10. Position an empty container with a minimum capacity of 0.5 liters under the hot water spout (fig. 6) and press "Yes" to activate the filter;
11. The appliance delivers hot water, then stops automatically. Press "OK" to go back to the homepage;
12. The filter is now active and you can use the coffee machine.

20.2 Replacing or removing the filter

Replace the filter (D3) when the replace filter message appears on the homepage (C). To replace the filter immediately, press "OK" and follow the instructions from point 3 of the previous section. To replace the filter later, press "Cancel". The filter symbol appears on the display to remind you the filter needs replacing.

To replace, proceed as follows:

1. Press the settings menu (C5);
2. Scroll through the pages until "Water filter" is displayed, then press "Read More";
3. Press "Yes" to enter the guided procedure;
4. Extract the water tank (A7) and exhausted filter.
5. To remove the filter, press "OK" ("Back" to go back to the previous screen; "X" to cancel the operation);
6. To replace the filter, press "Next" and follow the operations described in the previous section from point (4).

Please note:

After two months (see date indicator) or when the appliance has not been used for 3 weeks, you should replace the filter even if the message has not yet been displayed.

21. DISPLAYED MESSAGES

DISPLAYED MESSAGE	MEANING	SOLUTION
Time to fill the water tank with fresh water and then insert it	Insufficient water in the tank (A7).	Take out the tank, fill with potable fresh water to Max level, and reposition in the machine.
Please insert the water tank	The tank (A7) is not correctly in place.	Insert the tank correctly and press as far as it will go.
Fill the tank with fresh water. Please empty drip tray and grounds container	The amount of water in the tank is not enough to make the drink and the message to empty the grounds container will be displayed shortly.	The appliance asks for both operations to be performed so that no further intervention will be necessary and more drinks can be made one after the other without interruption.
Please insert the brewing unit	The brewing unit (A3) has not been replaced after cleaning.	Insert the brewing unit as described in section "18.10 Cleaning the brewing unit"
Please empty grounds container	The grounds container (A8) is full.	Clean as described in section "18.4 Cleaning the coffee grounds container"
Please insert grounds container and drip tray	The grounds container (A8) and/or drip tray (A12) is not correctly in place or is missing.	Insert the drip tray complete with grounds container and press as far as it will go.
Please add your preferred pre-ground coffee. - max: one scoop!	Preparation with pre-ground coffee has been selected.	Make sure the funnel (A16) is not blocked, then add one level scoop (D2) of pre-ground coffee, press "Next" on the display and follow the instructions in section "10.4 Making coffee using pre-ground coffee".
Fill the beans hopper and press "OK" to resume brewing	The coffee beans have run out.	Fill the beans hopper (A1) and press "OK" to resume brewing
Please insert the water spout	The spout (D4) is not correctly in place or is missing.	Insert the spout and push as far as it will go (fig. 5). The appliance emits a beep (if the beep function is enabled).
Please insert the milk carafe	The milk carafe is not inserted correctly or is missing.	Insert the milk carafe and push as far as it will go. The machine emits a beep (if the beep function is enabled).
Just doing a little cleaning. I'll be back in a few seconds	The appliance has detected impurities in its internal circuits.	Wait for the appliance to be ready again and reselect the required drink. Contact a Service Center.
The new settings have not been saved	While customising the drinks (see section "17. "My" function ("Hot" drinks only)", preparation has been deliberately interrupted by pressing "X" or an alarm has been triggered.	Press "X" to go back to the homepage (C) to view the alarm causing the interruption. Follow the instructions corresponding to the alarm displayed (see section "21. Displayed messages")
Sorry, I am unable to complete your drink. Please reduce the intensity and try again	The grinding is too fine and the coffee is delivered too slowly or not at all.	Select a milder "Intensity" (see "10.3 Customizing the drinks") or a coarser setting of the grinder
	If the water softener filter (D4) is present, an air bubble may have been released inside the circuit, obstructing delivery.	Press "OK" and deliver a little water (see section "14. Preparing hot water") until the flow is regular. If the problem continues, remove the filter (see section "20.2 Replacing or removing the filter")

DISPLAYED MESSAGE	MEANING	SOLUTION
If the delivery is slow and your espresso tastes burned, increase the grinding level by 1 (+1)	The grinding is too fine and the coffee is delivered too slowly or not at all.	Press "OK" and adjust the coffee grinder (see "9.4 Adjust grinder").
Sorry, I am unable to complete your drink. Please reduce the intensity and try again	Too much coffee has been used.	Select a milder "Intensity" (see "11.3 Customising the drinks") or reduce the quantity of pre-ground coffee (maximum 1 measure). Press "OK" to go back to the homepage or wait until the message disappears.
Remember to store the milk carafe in the fridge	A milk-based drink has been prepared and the milk carafe is still inserted in the appliance	Remove the carafe and place in the refrigerator.
The machine needs to be descaled. Press OK to start (~30min)	The machine must be descaled.	To proceed with descaling, press "OK" and follow the guided procedure, otherwise press "Cancel". In this case, the symbol (C4) appears on the homepage (C) to remind you that descaling is needed (see section "19. Descaling").
Oops, the process has been interrupted	Descaling process interrupted or not correctly completed	Press Ok to continue (see chap. "19. Descaling").
It's time to replace your water filter. Ready?	The water softener filter (D3) is exhausted.	Press "OK" to replace or remove the filter, or "Cancel" to carry out the procedure later. Follow the instructions in section "20. Water softener filter".
Something's not right: Can you refer to the user manual?	The inside of the appliance is very dirty.	Clean the inside of the appliance thoroughly, as described in section "18. Cleaning". If the message is still displayed after cleaning, contact a service center.
Water circuit empty. Press OK to start filling process	The water circuit is empty	Press "OK" to fill the circuit. Delivery stops automatically. It is normal for there to be water in the drip tray (A12) after filling. If the problem persists, make sure the water tank (A7) is fully inserted.
	A new water softener filter has been inserted (D3)	Make sure you have followed the instructions for inserting the new filter (sections "20.1 Installing the filter" and "20.2 Replacing or removing the filter"). If the problem continues, remove the filter.
	Energy saving is enabled.	To disable energy saving, proceed as described in section "8.4 General".
	The machine must be descaled.	The descaling procedure described in section "19. Descaling" needs to be performed.
	The filter must be replaced (D4)	Replace the filter or remove it as described in section "20. Water softener filter".
	Remember to clean the milk carafe (E).	Turn the froth adjustment dial (E1) to CLEAN.
The coffee beans profile has changed! Remember to brew at least 3 coffees before changing the coffee beans profile	The appliance needs to brew at least 3 coffees before Bean Adapt can be adjusted	Brew at least 3 coffees with the new coffee before changing the Bean Adapt

22. TROUBLESHOOTING

Below is a list of some of the possible malfunctions.

If the problem cannot be resolved as described, contact a service center.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The appliance does not come on	It is not plugged into the mains socket.	Plug into the mains socket (fig. 1) and push the ON/Standby button (B1).
It is difficult to insert the bean hopper	There are coffee beans in the hopper's housing on the machine	Clean the hopper's housing on the machine with the cleaning brush (D2) and a soft, damp cloth. To remove the coffee powder, use a hand vacuum cleaner.
The coffee is not hot.	The internal circuits of the appliance have cooled down because 2-3 minutes have elapsed since the last coffee was made.	Before making the coffee, heat the internal circuits by rinsing using the rinse function (in the setting menu).
	Coffee temperature setting too low.	Set a hotter coffee temperature in the settings menu (C5).
	The cups were not preheated.	Warm the cups by rinsing them with hot water (Please note: you can use the hot water function).
	The machine must be descaled	Proceed as described in section "19. Descaling". Next, check the water hardness in the setting menu and make certain the machine setting matches the local water supply hardness.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The coffee is weak or under extracted with pale color crema or no crema at all	The coffee is ground too coarsely.	Access the settings menu (C5) and follow the instructions to adjust grinding. The effect is only visible after delivering 3 coffees.
	Wrong grind size when using pre-ground coffee.	Use pre-ground coffee grinded for espresso.
	Coffee not fresh.	The coffee pack has been opened for too long and has lost its taste.
The coffee is delivered too slowly or a drop at a time.	The coffee is ground too finely.	Access the settings menu (C5) and follow the instructions to adjust grinding. The effect is only visible after delivering 3 coffees.
Coffee does not come out of one or both spouts.	The coffee spouts (A13) are blocked.	Clean the coffee spouts with a sponge or toothpick.
The coffee delivered is watery.	The funnel (A16) is clogged.	Clean the funnel with the help of the brush (D2) as described in section "18.9 Cleaning the pre-ground coffee funnel".
The appliance does not make coffee.	The appliance has detected impurities in its internal circuits. "Just doing a little cleaning..." is displayed.	Wait for the appliance to be ready again and reselect the required drink. Contact a service center.
The brewing unit (A3) cannot be extracted.	The appliance has not been turned off correctly	Turn the appliance off by pressing the button (B1) (see section "7. Turning the appliance off").
At the end of descaling, the appliance requests a third rinse.	During the two rinse cycles, the water tank (A13) has not been filled to the MAX level	Follow the instructions displayed by the appliance, but first empty the drip tray (A12) to avoid the water overflowing.
Milk does not flow from the milk spout (E3).	The milk carafe lid (E2) is dirty	Clean the milk carafe lid as described in section "18.11 Complete cleaning of the milk carafes (E)".
	The lid (E2) is not assembled correctly.	Assemble all the components correctly as described in sections "13.1 Preparing the milk carafes (E)" and turn the milk froth knob to the maximum froth position.
The milk contains large bubbles and squirts out of the milk spout (E3) there is little froth.	The milk is not cold enough or not suitable for the drink requested	For best results, make sure to use the right type of milk to prepare drinks (see section "13.2 Which milk to use?"). Use drinks at refrigerator temperature (about 5° C/41°F).
	The milk carafe lid (E2) is dirty	Clean the milk carafe as described in section "13.6 Cleaning the milk carafe after every use"
	There is water in the groove under the froth adjustment dial (E1)	Extract the dial and dry thoroughly.
	Plant-based drinks have been used.	When using plant base drink alternatives the results might change depending on the type and brand. These options might perform differently than cow milk, with less foam or larger bubbles. For best results make sure your milk alternative is at refrigerator temperature and follow indication on the display for suggestion.
	This is part of normal operation. To limit this from happening, empty the drip tray.	
The machine emits noises or small puffs of steam while not in use	The machine is ready for use, or has recently been turned off, and condensation is dripping into the hot vapouriser	

De'Longhi reserves the right to modify the technical specification and styling of its products at any moment, without compromising their functionality and quality.

23. TIPS FOR ENERGY SAVING

- To reduce energy consumption, after delivering one or more drinks, remove the milk carafe.
- Set Auto-off to the shortest selectable time (setting menu);
- Enable Energy Saving (setting menu);
- Always carry out the descaling cycle when prompted by the machine.

The images shown in this manual are for illustrative purposes only and may be subject to change.

PRINTED IN MEXICO / SC: 07-09-2026
Elbrd: J.M / SHNDML: EXAM44055_D
OBPN: 57132C9141_01_1224

8 1 4 1 0 0 7 4 3



**REFURBISHED PRODUCT
LIMITED NINETY DAYS
WARRANTY**

The **Refurbished Product Service Center** offers the following WARRANTY to the ORIGINAL purchaser of a product which we have refurbished.

This product that has been refurbished is warranted against any electronic or mechanical defects for a period of NINETY DAYS from the date of the original purchase by the consumer. Since this unit was sold as a refurbished item, the warranty does not apply to any cosmetic appearance items such as scratches. Should a defect occur, the **Refurbished Product Service Center** will repair or, at its option, replace defective unit/parts with new or rebuilt materials without charge for either parts or labor. Replacement unit/parts will be warranted for the remaining portion of the original warranty period.

This warranty does not cover installation or damage from accident, misuse, abuse, improper wiring, incorrect voltage, operating the unit against the instructions in the owner's manual or any product which has been opened, altered, or tampered with.

This warranty does not cover costs for removal and or installation of the unit for repair. Under no circumstances shall the service center be liable for any special, incidental or consequential damages or for any other expenses incurred by reason of use or sale of this product. This warranty is in lieu of any other warranties expressed or implied warranty of merchantability of fitness for particular use or otherwise.

This warranty gives the consumer specific legal rights and they may also have other rights which vary from State to State. Some States do not follow the exclusion or limitation of incidental or consequential damages, hence the above exclusion and limitations may not apply.

Refurbished Product Service Center
9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

**WARRANTY REPAIR
INFORMATION**

If you need service on your unit and this product requires repair during the 90 days warranty period; please go to **www.ConsumerService-Refurbish.com** or call the **Refurbished Product Service Center** at 562-946-3531 to obtain the required return authorization (RA) number. Pack the unit properly (the original carton is ideal for this purpose) along with a copy of your purchase receipt and a letter describing the problem. Send the unit freight prepaid and insured to:

Refurbished Product Service Center,
Att: Customer Service Department 9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

Your unit will be promptly repaired and returned to you. We will refuse to accept delivery of the returned unit unless the assigned RA number appears on the outside of the shipping carton.

Owner's Information

(Keep for your permanent records)

NAME: _____

ADDRESS: _____

CITY: _____

STATE: _____

ZIP CODE: _____

PHONE: _____

E-MAIL: _____

MODEL: _____

SERIAL NO.: _____