



"Recipe book not included"

ELETTA
EXPLORE

COFFEE MAKER



Instructions for use. Keep these instructions

ELECTRIC CHARACTERISTICS

120 V~ 60 Hz 1250 W

Please read this manual carefully before operating your unit and retain for future reference.

DeLonghi





NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process.

For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

NOTE: The actual descriptions of control panel and their locations may vary depending on the model.

NOTE: Accessory type and quantity may vary depending on the model.



IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following.

- Read all instructions carefully.
- Make sure the voltage of your electrical system corresponds to the voltage shown on the bottom of the machine.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electrical shock and personal injury, do not immerse cord, plug or appliance in water or other liquid.
- Keep the appliance out of the reach of children and do not leave appliance unattended while in operation.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner. Contact a service center.
- The use of accessory attachments not recommended by the manufacturer may result in fire, electrical shock, or personal injury.
- Do not use outdoors.
- Make sure the power cord does not hang over the edge of the table or counter-top to avoid getting accidentally caught or entangled.
- Do not place the appliance or its electrical parts on or near electric stoves, cooking surfaces, or gas burners.
- Plug cord into the wall outlet. To disconnect, first turn machine "off", then remove plug from wall outlet.
- Do not use the appliance for other than the intended use. This appliance is to be utilized for domestic use only. The manufacturer declines all responsibility for any damage caused by improper, incorrect, or irresponsible use.

WARNING: To reduce the risk of fire or electric shock, do not remove the cover or the exterior of the unit. Don't attempt to repair or modify the machine, doing so will void the warranty. Repair should be done by authorized service personnel only!

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

SHORT CORD INSTRUCTIONS

- A short power cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer, detachable power supply cords or extension cords are available and may be used if care is exercised in their use.
- If an extension cord is used, the marked electrical rating should be at least as great as the electrical rating of the appliance. If the appliance is provided with 3- wire, grounding type cord, the extension should be a GROUNDING TYPE 3 - WIRE CORD. The longer cord should be arranged so that it will not drape over the counter-top or table top where it can be pulled on by children or tripped over.
- Your product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

1. SAFETY WARNINGS

Danger!

This is an electrical appliance and may cause electric shock.

You should therefore follow these safety warnings:

- Never touch the appliance with damp hands or feet.
- Never touch the plug with damp hands.
- Make sure the socket used is freely accessible at all times, enabling the appliance to be unplugged when necessary.
- Unplug directly from the plug only. Never pull the cord as you could damage it.
- To disconnect the appliance completely you must unplug it from the mains socket.
- If the appliance is faulty, do not attempt to repair. Turn it off, unplug from the mains socket and Contact a service center.
- Before cleaning the appliance, turn it off, unplug from the mains socket and allow to cool.

Important:

Keep all packaging (plastic bags, polystyrene foam) away from children.

Danger of burns!

This appliance produces hot water and steam may form while it is in operation.

Avoid contact with splashes of water or hot steam.

When the appliance is in operation, the cup shelf could become very hot.

1.1 Designated use

This appliance is designed and made to prepare coffee and milk and heat beverages.

Any other use is considered improper and thus dangerous. The manufacturer is not liable for damage deriving from improper use of the appliance.

1.2 Instruction for Use

Read this Instruction for Use carefully before using the appliance. Failure to follow this Instruction for Use may result in injury or damage to the appliance.

The manufacturer is not liable for damage deriving from failure to respect this Instruction for Use.

Please note:

Keep this Instruction for Use. If the appliance is passed to other persons, they must also be provided with this Instruction for Use.

2. INTRODUCTION

Thank you for choosing this bean to cup espresso and cappuccino machine.

Take a few minutes to read this Instruction for Use. This will avoid all risks and damage to the appliance.

2.1 Letters in brackets

The letters in brackets refer to the description of the appliance.

2.2 Troubleshooting and repairs

In the event of problems, first try and resolve them by reading the information given in sections "21. Displayed messages" and "22. Troubleshooting".

If this does not resolve the problem or you require further information, Contact a service center.

2.3 Download the App!



Download the App then follow the instructions in the App to create your account.

In the App, you can find recipes, information, tips and curious facts about the world of coffee, together with information on your machine at your fingertips.

Models with Wi-Fi connection

In connected models, you can manage a number of functions remotely from the Coffee Link App.

This symbol highlights the functions you can control or consult using the App.

You can also create new beverages and save them in your appliance.

Please note:

- **Warning:** Changes or modifications not expressly approved by DE LONGHI could void the user's authority to operate the equipment.
- To cancel a remote command, act directly on the machine-display by pressing "Stop" or "Cancel".
- To access the functions from the App, enable connectivity from the appliance's settings menu (see "7.3 Connectivity (certain models only)").

3. DESCRIPTION

3.1 Description of the appliance (A)

- A1. Beans container lid
- A2. Beans container
- A3. Grinding coarseness regulator
- A4. Pre-ground coffee funnel
- A5. Brewing unit flap
- A6. Removable brewing unit
- A7. Coffee spouts (adjustable height)
- A8. Accessories connector
- A9. button: turns the appliance on and off (standby)
- A10. Coffee grounds container
- A11. Coffee grounds container support
- A12. Condensate tray
- A13. Cup tray
- A14. Tray grille
- A15. Drip tray
- A16. Flap grille (travel mug compartment)
- A17. Flap grille support (travel mug compartment)
- A18. Drip tray water level indicator
- A19. Water tank lid
- A20. Water tank

3.2 Description of the control panel (B)

- B1. "Cold" beverages menu
- B2. "To go" beverages menu
- B3. "Hot" beverages menu
- B4. "Favorites" beverages menu

3.3 Description of the homepage (main screen) (C)

- C1. Selectable beverages (direct selection)
- C2. To display and customize the beverage settings
- C3. Appliance settings menu
- C4. Indicator lights:

*Connected models only:

- Machine waiting for first connection
- Wi-Fi active light
- No network light

All models:

- Energy saving active light
- Milk carafe cleaning required light
- Descaling required light
- Exhausted filter light

C5. Customisable profiles (see "15. Selecting your personal profile")

3.4 Description of the accessories (D) (*varies according to model)

Accessories in the Starter pack:

- D1. "Total Hardness Test" indicator paper
- D2. Pre-ground coffee measuring spoon
- D3. Water softener filter
- D4. Cleaning brush
- D5. Hot water spout
- D6. Ice cube tray
- D7. Travel mug

3.5 Description of milk carafe (hot) (E)

Lattecrema HOT

- E1. Milk carafe lid
- E2. Milk carafe
- E3. Froth adjustment/Clean dial
- E4. Milk carafe connector (removable for cleaning)
- E5. Milk spout (adjustable height)
- E6. Milk intake tube (silicone)
- E7. Milk spout extension

3.6 Description of milk carafe (cold) (F)

Lattecrema COOL


- F1. Milk carafe lid
- F2. Milk carafe
- F3. Froth adjustment/Clean dial
- F4. Milk carafe connector (removable for cleaning)
- F5. Milk spout
- F6. Milk intake tube (rigid plastic)

4. SETTING UP THE APPLIANCE

Please note:

- Possible traces of coffee in the grinder are the result of quality tests performed on the appliance before sale, proof of the meticulous care and attention we invest in our products.
- The first time you use the appliance, all removable accessories (milk carafe (E) and (F), travel mug* (D7), water tank (A19) and (A20)) destined to come into contact with water or milk should be rinsed with hot water. We recommend washing the milk carafes in a dishwasher.
- You should customize water hardness as soon as possible following the instructions in section "18. Setting water hardness".


1. Connect the appliance to the mains supply (fig. 1).




2. Press the flag corresponding to the desired language and confirm the selection by pressing "Done".

Now follow the instructions indicated on the display of the appliance:


3. Remove the water tank (A20) (fig. 2) and fill to the MAX line with fresh water (fig. 3);




4. Then put the tank back and confirm by pressing "Next";
5. Fill the beans container (A2) (fig. 4), then confirm by pressing "Next".



6. Insert the hot water spout (D5) on the accessories connector (A8) (fig. 5) and place a container with a minimum capacity of 6,76 fl oz/200 ml under the coffee spouts (A7) and hot water spout (fig. 6);



7. Press "OK" to fill the water circuit. The appliance delivers water from the hot water spout (fig. 7);
8. At the end of delivery, the appliance proceeds to warm up by performing a rinse cycle, delivering hot water from the coffee spouts (fig. 8).



When at temperature, the appliance proposes a tutorial on how to use the machine.

Please note:

- The first time you use the appliance, you need to make 4-5 cappuccinos before the results in the cup will be satisfactory.
- The first time you use the machine, the water circuit is empty and the appliance could be very noisy. The noise becomes less as the circuit fills.

5. TURNING THE APPLIANCE ON

Please note:

- Each time the appliance is turned on, it performs an automatic preheat and rinse cycle which cannot be interrupted. The appliance is not ready for use until the cycle has been completed.

1. To turn the appliance on, press the button (A9) (fig. 9): the appliance comes on




2. When at temperature, the appliance performs a rinse cycle delivering hot water from the coffee spouts (A7); as well as heating the boiler, this also heats the internal circuits by circulating hot water.

Please note:

The filter lasts about two months if the appliance is used normally. If the machine is left unused with the filter installed, it will last a maximum of 3 weeks.

- Press "Next" to continue ("Back" to go back to the previous screen; "X" to cancel the operation);
- To activate the filter, run tap water through the hole in the centre of the filter until water comes out of the openings at the side for more than a minute (fig. 42). Press "Next";



- Extract the water tank (A20) (fig. 2) and fill with water; insert the filter in the water tank and immerse it completely for about ten seconds, sloping it and pressing it lightly to enable the air bubbles to escape (fig. 43). Press "Next";
- Insert the filter in the filter housing (fig. 44) and press as far as it will go; press "Next";
- Close the tank with the lid (A19), then put the tank back in the machine.
- Insert the hot water spout (D5). Press "Next";
- Position an empty container with a minimum capacity of 16.90 fl oz / 0.5 l under the hot water spout (fig. 6) and press "Next" to activate the filter;
- The appliance delivers hot water, then stops automatically. Press "OK" to go back to the homepage;
- The filter is now active and you can use the coffee machine.

19.2 Replacing or removing the filter

Replace the filter (D3) when the replace filter message appears on the homepage (C). To replace the filter immediately, press "OK" and follow the instructions from point 3 of the previous section. To replace the filter later, press "Cancel". The filter symbol appears on the display to remind you the filter needs replacing. To replace, proceed as follows:

- Press the settings menu (C3);
- Scroll through the pages until "Water filter" is displayed, then press "OK";
- Press "OK" to enter the guided procedure;
- Extract the water tank (A20) and exhausted filter.
- To remove the filter, press "OK" ("Back" to go back to the previous screen; "Cancel" to cancel the operation);
- To replace the filter, press "Next" and follow the operations described in the previous section from point (4).

Please note:

After two months (see date indicator) or when the appliance has not been used for 3 weeks, you should replace the filter even if the message has not yet been displayed.

19.3 Tips for Energy Saving

- To reduce energy consumption, after delivering one or more beverages, remove the milk carafes or accessories.
- Set auto-off to 15 minutes (see section "7.8 Set auto-off");
- Enable Energy Saving (see paragraph "7.9 General");
- Always carry out the descaling cycle when prompted by the machine.

20. REGULATORY COMPLIANCE (CONNECTED MODELS ONLY)

FCC for USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC for CND

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

De'Longhi reserves the right to modify the technical specification and styling of its products at any moment, without compromising their functionality and quality.

21. DISPLAYED MESSAGES

DISPLAYED MESSAGE	MEANING	SOLUTION
Please fill the tank with fresh water up to MAX level. Be sure to fill above Level 1	Insufficient water in the tank (A20).	Extract the tank, fill with fresh water to above Level 1 and put back in the appliance.
I don't have enough water for your beverage. Please fill the tank with fresh water up to MAX level. Be sure to fill above Level 1		
Please insert the water tank	The tank (A20) is not correctly in place.	Insert the tank correctly and press as far as it will go.
Fill the tank with fresh water. Please empty drip tray and grounds container	The amount of water in the tank is not enough to make the beverage and the message to empty the grounds container will be displayed shortly.	The appliance asks for both operations to be performed so that no further intervention will be necessary and more beverages can be made one after the other without interruption.
Please insert the brewing unit	The brewing unit (A6) has not been replaced after cleaning.	Insert the brewing unit as described in section "16.8 Cleaning the brewing unit"
Please empty grounds container	The grounds container (A10) is full.	Clean as described in section "16.3 Cleaning the coffee grounds container"
Please insert grounds container and drip tray	The grounds container (A10) and/or drip tray (A15) is not correctly in place or is missing.	Insert the drip tray complete with grounds container and press as far as it will go.
Please add your preferred pre-ground coffee. - max: one measure!	Preparation with pre-ground coffee has been selected.	Make sure the funnel (A4) is not blocked, then add one level measuring spoon (D2) of pre-ground coffee, press "Next" on the display and follow the instructions in section "9.4 Making coffee using pre-ground coffee".
Fill the beans container and press "OK" to resume brewing	The coffee beans have run out.	Fill the beans container (A2) and press "OK" to resume brewing
Please insert the water spout	The spout (D5) is not correctly in place or is missing.	Insert the spout and push as far as it will go (fig. 5). The appliance emits a beep (if the beep function is enabled).
Please insert the cold/hot milk carafe	The milk carafe (E) or (F) is not inserted correctly or is missing.	Insert the milk carafe and push as far as it will go. The machine emits a beep (if the beep function is enabled).
Just doing a little cleaning. I'll be back in a few seconds	The appliance has detected impurities in its internal circuits.	Wait for the appliance to be ready again and reselect the required beverage. Contact a service center.
The new settings have not been saved	While customising the beverages (see section "14. My" function ("Hot" beverages only)), preparation has been deliberately interrupted by pressing "X" or an alarm has been triggered.	Press "X" to go back to the homepage (C) to view the alarm causing the interruption. Follow the instructions corresponding to the alarm displayed (see section "21. Displayed messages")
I am unable to complete your beverage. Reduce the strength and try again	The grinding is too fine and the coffee is delivered too slowly or not at all. If the water softener filter (D3) is present, an air bubble may have been released inside the circuit, obstructing delivery.	Select a milder "Strength" (see "9.3 Customising the beverages") Press "OK" and deliver a little water (see section "11. Preparing hot water and hot tea") until the flow is regular. If the problem continues, remove the filter (see section "19.2 Replacing or removing the filter")
I am unable to complete your beverage. Adjust the coffee grinder, increasing the dial position one unit at a time	The grinding is too fine and the coffee is delivered too slowly or not at all.	Press "OK" and adjust the coffee grinder (see "7.4 Adjust grinder").
Please select a lighter strength or reduce pre-ground coffee quantity	Too much coffee has been used.	Select a milder "Strength" (see "9.3 Customising the beverages") or reduce the quantity of pre-ground coffee (maximum 1 measuring spoon). Press "OK" to go back to the homepage or wait until the message disappears.
Please store the milk carafe in the fridge	A milk-based beverage has been prepared and the milk carafe is still inserted in the appliance	Remove the carafe and place in the refrigerator.
The machine needs to be descaled. Press OK to start (~50min)	The machine must be descaled.	To proceed with descaling, press "OK" and follow the guided procedure, otherwise press "Cancel". In this case, the symbol (C4) appears on the homepage (C) to remind you that descaling is needed (see section "17. Descaling").
Please replace the water filter. Press OK to start	The water softener filter (D3) is exhausted.	Press "OK" to replace or remove the filter, or "Cancel" to carry out the procedure later. Follow the instructions in section "19. Water softener filter".

DISPLAYED MESSAGE	MEANING	SOLUTION
General alarm: Please refer to user manual / Coffee Link App	The inside of the appliance is very dirty.	Clean the inside of the appliance thoroughly, as described in section "16. Cleaning". If the message is still displayed after cleaning, contact a service center.
Water circuit empty. Press OK to start filling process	The water circuit is empty A new water softener filter has been inserted (D3)	Press "OK" to fill the circuit. Delivery stops automatically. It is normal for there to be water in the drip tray (A15) after filling. If the problem persists, make sure the water tank (A20) is fully inserted. Make sure you have followed the instructions for inserting the new filter (sections "19.1 Installing the filter" and "19.2 Replacing or removing the filter"). If the problem continues, remove the filter (section "19.2 Replacing or removing the filter").
	Energy saving is enabled.	To disable energy saving, proceed as described in section "7.9 General".
	The machine must be descaled.	The descaling procedure described in section "17. Descaling" needs to be performed.
	The filter must be replaced (D3)	Replace the filter or remove it as described in section "19. Water softener filter".
	Remember to clean the milk carafe (E) or (F).	Turn the froth adjustment dial (E3) or (F3) to CLEAN.
*Models with Wi-Fi connectivity:		
	The connection is configured in the appliance settings menu (C3).	Connect to the Coffee Link App.
	Indicates that the appliance is connected.	To disable the connection, proceed as described in section "7.3 Connectivity (certain models only)".
	Connectivity is active, but the cloud cannot be reached.	If just turned on, wait for the appliance to complete the start up procedure. If the problem continues, disable the connection then enable again as described in section "7.3 Connectivity (certain models only)". Make sure the lights on the router indicate that the network is active. If the problem continues, turn the appliance and home router off then on again.

22. TROUBLESHOOTING

Below is a list of some of the possible malfunctions.

If the problem cannot be resolved as described, contact a service center.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The appliance does not turn on	It is not plugged into the mains socket.	Plug into the mains socket (fig. 1).
The coffee is not hot.	The internal circuits of the appliance have cooled down because 2-3 minutes have elapsed since the last coffee was made. Coffee temperature setting too low.	Before making the coffee, heat the internal circuits by rinsing using the rinse function (see section "7.1 Rinsing"). Set a hotter coffee temperature in the settings menu (C3) (see section "7.5 Coffee temperature").
	The cups were not preheated.	Warm the cups by rinsing them with hot water (Please note: you can use the hot water function).
	The machine must be descaled	Proceed as described in section "17. Descaling". Next, check the water hardness ("18.1 Measuring water hardness") and make certain the machine setting matches the local water supply hardness ("18.2 Setting water hardness").
The coffee is weak or not creamy enough (under extracted).	The coffee is ground too coarsely.	Access the settings menu (C3) and follow the instructions to adjust grinding. The effect is only visible after delivering 3 coffees (see section "7.4 Adjust grinder").
	The coffee is unsuitable.	Use coffee for espresso machines.
	Coffee not fresh.	The coffee pack has been opened for too long and has lost its taste.
The coffee is delivered too slowly or a drop at a time (over extracted).	The coffee is ground too finely.	Access the settings menu (C3) and follow the instructions to adjust grinding. The effect is only visible after delivering 3 coffees (see section "7.4 Adjust grinder").
Coffee does not come out of one or both spouts.	The coffee spouts (A7) are clogged.	Clean the coffee spouts with a sponge or toothpick.
The coffee delivered is watery.	The funnel (A4) is clogged.	Clean the funnel with the help of the brush (D4) as described in section "16.7 Cleaning the pre-ground coffee funnel".

PROBLEM	POSSIBLE CAUSE	SOLUTION
Too little beverage is delivered	Insufficient water in the tank	Always fill the tank above Level 1.
The appliance does not make coffee.	The appliance has detected impurities in its internal circuits. "Just doing a little cleaning..." is displayed.	Wait for the appliance to be ready again and reselect the required beverage. Contact a service center.
The brewing unit (A6) cannot be extracted.	The appliance has not been turned off correctly	Turn the appliance off by pressing the button (A9) (see section "6. Turning the appliance off").
At the end of descaling, the appliance requests a third rinse.	During the two rinse cycles, the water tank (A20) has not been filled to the MAX level	Follow the instructions displayed by the appliance, but first empty the drip tray (A15) to avoid the water overflowing.
Milk does not flow from the milk spout (E5) or (F5).	The milk carafe lid (E1) or (F1) is dirty The lid (E1) or (F1) is not assembled correctly.	Clean the milk carafe lid as described in section "16.9 Cleaning the milk carafes (E) and (F)". Assemble all the components correctly as described in sections "10.1 Preparing the milk carafes (E and F)" and "10.4 Adjusting the amount of froth".
The milk contains large bubbles and squirts out of the milk spout (E5) or (F5) there is little froth.	The milk is not cold enough or not suitable for the beverage requested The milk carafe lid (E1) or (F1) is dirty There is water in the groove under the froth adjustment dial (E3) or (F3) Plant-based beverages have been used.	For best results, make sure to use the right type of milk to prepare hot or cold beverages (see section "10.2 Which milk to use?"). Use beverages at refrigerator temperature (about 5° C). Clean the milk carafe as described in section "10.6 Cleaning the milk carafe after use" Extract the dial and dry thoroughly. For best results, use beverages at refrigerator temperature (about 5° C). Adjust the amount of froth as described in section "10.4 Adjusting the amount of froth"
The cup shelf (A13) is hot.	A number of beverages have been prepared in rapid succession	This is part of normal operation.
After cleaning, you can't put the drip tray back in the machine	The condensate tray (A12) is not in the correct position	Make sure the condensate tray is inserted correctly
The machine emits noises or small puffs of steam while not in use	The machine is ready for use, or has recently been turned off, and condensate is dripping into the hot vapouriser	This is part of normal operation. To limit the phenomenon, empty the drip tray.
The appliance emits puffs of steam from the drip tray (A15) and/or there is water on the surface the appliance rests on.	The drip tray grille (A14) has not been put back after cleaning.	Put the drip tray grille back in the drip tray.
The To Go beverage is too much or has spilled out of the travel mug	An unsuitable quantity has been selected	Choose a smaller quantity (Medium or Small) Adjust the quantity in the mug so that the next beverage is prepared correctly
Too little To Go beverage is prepared	An unsuitable quantity has been selected	Choose a larger quantity (Medium or Large) Adjust the quantity in the mug so that the next beverage is prepared correctly
The travel mug cannot be inserted in the appliance	The travel mug compartment flap (A16) is closed and/or the coffee spouts (A7) are lowered	Open the flap and/or raise the coffee spouts
*Models with Wi-Fi connectivity:		
The App is not working	App malfunction	Close the App, then run it again
The App indicates a problem, but there is no problem with the appliance	The data between the appliance and App are not synchronized	Disable and re-enable connectivity (section "7.3 Connectivity (certain models only)")

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

PRINTED IN MEXICO / Elbrd.: J.M
SC: 07-03-2026 / OBPn: 57132C7703
SHNMDL:ECAM45055S_D



REFURBISHED PRODUCT LIMITED NINETY DAYS WARRANTY

The **Refurbished Product Service Center** offers the following WARRANTY to the ORIGINAL purchaser of a product which we have refurbished.

This product that has been refurbished is warranted against any electronic or mechanical defects for a period of NINETY DAYS from the date of the original purchase by the consumer. Since this unit was sold as a refurbished item, the warranty does not apply to any cosmetic appearance items such as scratches. Should a defect occur, the **Refurbished Product Service Center** will repair or, at its option, replace defective unit/parts with new or rebuilt materials without charge for either parts or labor. Replacement unit/parts will be warranted for the remaining portion of the original warranty period.

This warranty does not cover installation or damage from accident, misuse, abuse, improper wiring, incorrect voltage, operating the unit against the instructions in the owner's manual or any product which has been opened, altered, or tampered with.

This warranty does not cover costs for removal and/or installation of the unit for repair. Under no circumstances shall the service center be liable for any special, incidental or consequential damages or for any other expenses incurred by reason of use or sale of this product. This warranty is in lieu of any other warranties expressed or implied warranty of merchantability of fitness for particular use or otherwise.

This warranty gives the consumer specific legal rights and they may also have other rights which vary from State to State. Some States do not follow the exclusion or limitation of incidental or consequential damages, hence the above exclusion and limitations may not apply.

Refurbished Product Service Center
9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

WARRANTY REPAIR INFORMATION

If you need service on your unit and this product requires repair during the 90 days warranty period; please go to **www.ConsumerService-Refurbish.com** or call the **Refurbished Product Service Center** at 562-946-3531 to obtain the required return authorization (RA) number. Pack the unit properly (the original carton is ideal for this purpose) along with a copy of your purchase receipt and a letter describing the problem. Send the unit freight prepaid and insured to:

Refurbished Product Service Center,
Att: Customer Service Department 9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

Your unit will be promptly repaired and returned to you. We will refuse to accept delivery of the returned unit unless the assigned RA number appears on the outside of the shipping carton.

Owner's Information
(Keep for your permanent records)

NAME:

ADDRESS:

CITY:

STATE:

ZIP CODE:

PHONE:

E-MAIL:

MODEL:

SERIAL NO.:

ELETTA explore

814000767




“Recipe book not included”

QUICK START GUIDE




Please Read this guide carefully before using the device and keep it for future reference.

IN THE BOX



The images shown in this guide are for illustrative purposes only and may be subject to change.

CONTROL PANEL



Control Panel:

- B1. “Cold” beverages menu
- B2. “To Go” beverages menu
- B3. “Hot” beverages menu
- B4. “Favorites” beverages menu

Touch Screen:

- C1. Selectable beverages (direct selection)
- C2. To display and customize the beverage settings
- C3. Appliance settings menu
- C4. Indicator lights:
 - Energy saving active light
 - Milk carafe cleaning required light
 - Descaling required light
 - Exhausted filter light

NOTE: The actual descriptions of control panel and their locations may vary depending on the model.


ACCESSORIES



Accessories in the Starter pack:

- D1. “Total Hardness Test” indicator paper
- D2. Pre-ground coffee measuring spoon
- D3. Water softener filter
- D4. Cleaning brush
- D5. Hot water spout
- D6. Ice cube tray
- D7. Travel mug

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.



Description of milk carafe (hot)



- E1. Milk carafe lid
- E2. Milk carafe
- E3. Froth adjustment/Clean dial
- E4. Milk carafe connector (removable for cleaning)
- E5. Milk spout (adjustable height)
- E6. Milk intake tube (silicone)
- E7. Milk spout extension

Description of milk carafe (cold)



- F1. Milk carafe lid
- F2. Milk carafe
- F3. Froth adjustment/Clean dial
- F4. Milk carafe connector (removable for cleaning)
- F5. Milk spout
- F6. Milk intake tube (rigid plastic)


Accessory type and quantity may vary depending on the model.

GET READY


Download the De’Longhi Coffee Link App. Connect via Wi-Fi to your machine to access many functions and settings remotely. Remove all and clean all accessories with warm water and mild detergent and dry them. Priming the machine is only required the first timeout of the box.

Once the machine is plugged in, it will turn on automatically. Select your language and follow instructions on the screen.

Place a container (7oz min) under both the water spout and coffee spouts. Caution: the machine will deliver hot water.



BREW



The first time using the machine, brew and dump the first 4-5 cappuccinos. If you haven’t been using the machine for 3-4 days, perform a rinsing cycle (Settings Menu) before brewing.

To brew the perfect espresso set your grinder following the “Extraction Guidelines”.


Select one of the recipes on the touch screen. Preparation will start with default strength and quantity, which can be changed by customizing your recipes.

You can refine the recipe menu displayed on the screen using the touch icons on the control panel.


MILK RECIPIES

To make a Milk recipe, choose the carafe based on the recipe you want to prepare (hot or cold). For cold foam, use fat free cow milk only or any type of plant-based milk.

- 1 Open the lid and make sure the milk intake tube is correctly inserted in the bottom of the milk container lid.
- 4 Select a milk based recipe.
- 5 Use the selector to choose the amount of foam. On the screen, the machine will suggest what to select based on your chosen recipe.
- 6 Once finished, place an empty container under the coffee spouts and twist the selector to "clean" position to perform a rinsing of the milk container lid. If you prepare multiple milk recipes, you should do this only after you finished your last recipe. To proceed to the next recipe press "Cancel" on the screen. Store the remaining milk in the container in the fridge.



CUSTOMIZE RECIPES




- 1 You can change the default parameter at any time by clicking the '+' icon underneath the beverage icon you want to customize.
- 2 Select Size and Strength of your choice. You will have the option to save or discard the change to the default settings.
- 3 With the 'my' function, you can save an additional set of parameters. You can easily enable or disable 'my' function as needed.
- 4 By pressing the 'my' icon, you can save the recipe in the Favorites collection, which you can access directly from the control panel.

Pre-Ground
To use pre-ground coffee, press the 'Pre-Ground' button and click "Brew". Then lift the funnel lid and add one measuring spoon of pre-ground coffee.

EXTRACTION GUIDELINES

Depending on your choice of beans, you might need to adjust the grinder setting to a finer or more coarse choice.



- Flow like warm honey
- Nut-brown Crema
- Well balanced and lingering taste


- Flowing fast like water
- Light and pale Crema

- Flowing in drips or not at all
- Crema very dark and not uniform


- To make it perfect:
- Adjust grinding setting to a finer setting
 - Select a higher strength



- To make it perfect:
- Adjust grinding setting to a coarser setting
 - Select a lower strength



CLEANING



Keeping your machine clean will improve quality of the beverage and life span of the machine.

- 1 Empty drip tray daily and empty coffee ground container when the corresponding message is displayed .
- 2 Once a month, clean the inside of the machine. Follow User Manual detailed instruction.
- 2 Remove and clean each part of the milk container lid. Follow User Manual detailed instruction.

DESCALING




- 4 Promptly descale when indication light comes on. Follow user Manual detailed instruction.

De'longhi Descaler is not included

INSERT WATER FILTER

You can purchase extra filters on www.delonghi.com. The type of filter may vary.

- 2 From the Settings menu, select Water filter and follow the step by step instructions on the screen.
- 3 Be ready with a large container (17 fl oz min), to collect the water that will be delivered from the water spout during the installation process.




The images shown in this guide are for illustrative purposes only and may be subject to change.

Analyze the hardness of your water to set your machine accordingly. Different water levels will require for your machine to be descaled more or less frequently. To set your machine access "Water Hardness" on the settings menu.

- 1 Dip the provided Total Hardness Indicator in a glass of water for one second and shake it.
- 2 Wait a couple of minutes. Read the Indicator paper colors and compare with this table.

SET WATER HARDNESS



Level 1 - Soft Water	
Level 2 - Slightly Hard Water	
Level 3 - Hard Water	
Level 4 - Very Hard Water	

PRINTED IN MEXICO / Elbrd: J.M / OBPN: 57132C7756_03_0522
SC: 07-03-2026 / SHNMDL: ECAM45055S_D

8 1 4 0 0 0 7 6 7

