Shark
EVERYMESS™
Wet + Dry + Stain



OWNER'S GUIDE

IMPORTANT SAFETY INSTRUCTIONS
FOR HOUSEHOLD USE ONLY

⚠ WARNING
To reduce the risk of fire, electric shock, injury, or property damage, when using an electrical appliance, basic precautions should always be followed, including the following:

ELECTRICAL & POWER SAFETY
1. Inspect power cord and plug for any damage before use. **DO NOT** use vacuum cleaner with a damaged cord or plug. Turn off all controls before plugging in or unplugging the vacuum cleaner. To minimize the risk of power cord damage, store your vacuum cleaner with the power cord secured around the handle.
2. **DO NOT** handle the plug or vacuum with wet hands.
3. The use of an extension cord is **NOT** recommended.
4. This appliance has a polarized plug. If the plug does not fit fully into the outlet, reverse the plug (one blade is wider than the other). If it still does not fit, contact a qualified electrician. **DO NOT** force into outlet or try to modify to fit.
5. **DO NOT** damage the charging cord:
   - **a) DO NOT** pull or carry vacuum cleaner by the cord or use the cord as a handle.
   - **b) DO NOT** unplug by pulling on cord. Grasp the plug, not the cord.
   - **c) DO NOT** run vacuum over the cord, close a door on the cord, pull the cord around sharp corners, or leave the cord near heated surfaces.
6. Turn off all controls before unplugging the vacuum.
7. Unplug from electrical outlet when not in use and before any maintenance or cleaning.
8. **DO NOT** immerse the product in water.
9. To reduce the risk of electrical shock, use indoors only.
10. To reduce the risk of electric shock, always install the debris screen before any wet pickup operation.
11. This appliance is provided with double insulation. Use only identical replacement parts. See instructions for Servicing of Double-Insulated Appliances.

GENERAL USE & MAINTENANCE
12. Carefully observe and follow the instructions provided below to avoid improper use of the appliance. **DO NOT** use the vacuum for any purpose other than those described in this manual.
13. Before use, carefully inspect all parts for any damage. **DO NOT** use if any parts are damaged.
14. **DO NOT** use if vacuum cleaner is not working as it should, or has been dropped, damaged, left outdoors, or dropped into water.
15. Use only identical replacement parts.
16. Only use Shark® branded filters and accessories.
17. **DO NOT** modify or attempt to repair the vacuum yourself. **DO NOT** use the vacuum if it has been modified or damaged.
18. Your vacuum cleaner consists of a vacuum pod. This device contains electrical connections, electrical wiring, and moving parts that potentially present a risk to the user. **DO NOT** use when damaged.
19. This vacuum cleaner contains no serviceable parts.
20. Always turn off the vacuum cleaner before connecting or disconnecting the hose or opening and closing the lid.
21. Make sure the dust cup, debris screen, and all filters are in place before plugging in and turning on the unit.
22. **DO NOT** use without filters in place.
23. Make sure the dust cup and all filters are in place after routine maintenance.
24. **DO NOT** leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
25. **DO NOT** leave the vacuum cleaner unattended while plugged in.
26. Store indoors. **DO NOT** expose to rain.
27. **DO NOT** place vacuum cleaner on unstable surfaces such as chairs or tables.
28. Secure the hose around the unit lid and power cord around the handle during storage.
29. Use extra care when cleaning on stairs.

CHILDREN & PETS SAFETY
30. This appliance can be used by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
31. Cleaning and user maintenance shall not be made by children.
32. Keep the appliance and its cord out of reach of children.
33. **DO NOT** allow the appliance to be used by children. **DO NOT** allow to be used as a toy. Close supervision is necessary when used near children.
34. **DO NOT** use near pets or in occupied pet enclosures.
35. Allow all treated surfaces to dry completely before reintroducing pets.
36. Any treated surface should be allowed to dry completely, and ventilate areas as needed before allowing pets access to the treated areas.

FIRE, CHEMICAL & MATERIAL SAFETY
37. **DO NOT** use to pick up:
   - **a)** Large quantities of dust (e.g., drywall dust, fireplace ash, or embers). **DO NOT** use as an attachment to power tools for dust collection.
   - **b)** Smoking or burning objects (e.g., hot coals, cigarette butts, or matches).
   - **c)** Flammable or combustible materials (e.g., lighter fluid, gasoline, or kerosene).
   - **d)** Toxic materials (e.g., chlorine bleach, ammonia, or drain cleaner).
38. To reduce the risk of fire, **DO NOT** use a flammable or combustible liquid to clean a floor.
39. **DO NOT** spray solution on your skin or in your eyes.
40. **DO NOT** use in the following areas:
   - **a)** Poorly lit areas.
   - **b)** Spaces that are enclosed and may contain explosive or toxic fumes or vapors (lighter fluid, gasoline, kerosene, paint, paint thinners, mothproofing substances, or flammable dust).

CLEANING & MAINTENANCE
41. Hand wash components with warm soapy water. Washing with harsh cleaning chemicals could damage the unit.
42. Allow all filters to air-dry completely before replacing in the vacuum to prevent liquid from being drawn into electric parts.
43 Before cleaning a surface with the cleaning solution, check the manufacturer's tag. **DO NOT** clean delicate rugs (including wool, cotton, silk, antique, or area rugs) unless they have a manufacturer's tag. If the manufacturer's tag says S or "Dry Clean Only", **DO NOT** clean that surface. If the tag says W or WS, you **CAN** use SHARK Cleaning Solution on that surface.

OPERATION & AIRFLOW SAFETY
44. **DO NOT** put any objects into end of the hose or accessory openings. **DO NOT** use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
45. **DO NOT** use if the hose or accessory airflow is restricted. If the air paths become blocked, turn the vacuum cleaner off and unplug from electrical
46. Keep all vacuum openings away from hair, face, fingers, uncovered feet, or loose clothing.
47. When using on any surface, always keep the end of the hose or accessory moving to avoid damaging the surface (e.g., carpet fibers).


▣ SERVICING OF DOUBLE-INSULATED APPLIANCES
A double-insulated appliance is marked with one or more of the following: The words "DOUBLE INSULATION" or "DOUBLE INSULATED."


In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace.

SAVE THESE INSTRUCTIONS

GETTING TO KNOW THE EVERYMESS™

NOTE: *DISHWASHER SAFE.





NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process.
For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

Scan QR code to view
HOW-TO VIDEOS

TECHNICAL SPECIFICATIONS

Voltage:	120V~, 60Hz
Watts:	780W

AVAILABLE ACCESSORIES

NOTE: Included accessories differ by model.


(Accessory type and quantity may vary depending on the model.)

Ⓐ **Squeegee Tool***
A tool designed to clean wet and mixed messes on bare floors. Also effective at removing stubborn embedded pet hair from carpet and upholstery.

Ⓑ **Stain Tool**
Use with StainForce™ solution to remove stubborn spots and stains.


Ⓒ **StainForce Spray Solution**
Spray generously directly onto stains, then use the Stain Tool to scrub.

NOTE: *DISHWASHER SAFE.




The images shown in this manual are for illustrative purposes only and may be subject to change.

SPRAY BOTTLE ASSEMBLY




Twist off both caps on the cleaning solution bottle, then peel off the foil seals.




Press the sprayer down over the openings on top of the bottle. Make sure it clicks securely in place.


ASSEMBLY




Insert rear hose clip into the back of the main unit, just above the power cable.




Insert the **Accessory Holder** into the notch on the side of the unit. Press the holder down over the **Dust Cup** until it clicks securely into place.




Insert the **Hose Connector** into the opening on the side of the unit until it clicks into place.



Insert the hose into the rear hose clip, then into the accessory holder clip. Wrap the hose around the bottom of the main unit.




To store the hose on the unit, press the tab Ⓐ on the hose inlet, then inset the tab into the opening Ⓑ near the bottom of the main unit. When connected properly, it will click securely into place.



Insert accessories into the slots in the holder. Store the power cord by wrapping it around the handle.

USING YOUR EVERYMESS™

DUST CUP CAPACITY



The dust cup has a dry debris capacity of 1 gallon and a wet debris capacity of 1/2 gallon. When vacuuming wet or sloppy messes, **do not fill the dust cup above the Wet Debris Max Fill** line.

When debris reaches the Max Fill line, the float mechanism in the dust cup will rise automatically to cut off airflow. Suction will cease and motor noise will become higher in pitch. When this happens, turn off the vacuum, unplug the power cord, and empty the dust cup.

OPENING THE LID

Pull out the bottom of the latch to release, then pull the latch down to unhook from the lid.

After unlatching the lid, open it by lifting the handle.

IMPORTANT: Unplug the power cord before opening the lid.


ANYBAG TECHNOLOGY™


The EveryMess can be used **with or without** a bag.

Vacuuming without a bag
You can vacuum straight into the dust cup without a bag. The dust cup is removable and dishwasher safe.


Vacuuming with AnyBag Technology
Line the inside of the dust cup with any plastic trash bag (2 to 13 gallons) for easy disposal of debris.

Note: Carefully inspect the bag for damage or holes. **DO NOT** use a bag with holes. **DO NOT** use a bag when vacuuming sharp or industrial debris.







1. Insert an undamaged plastic bag to line the inside of the dust cup. Push the bottom of the bag down to the base of the dust cup.
2. Tuck the top of the bag between the **Bag Guides** and **Dust Cup Shelf**.




3. Run any excess bag through the **Bag Holder Slot** on the top of the accessory holder.
4. Close the lid to secure the bag in place. The lid should clamp over the excess bag.



Press the power button to turn on the vacuum.




Use the hose inlet to suction up **ANY** mess.




Attach a cleaning tool by inserting it into the hose inlet until it clicks into place.

*Accessory tools may vary by model.



DRY VACUUMING



Use the hose inlet to vacuum up any mess, wet or dry.



Use the Squeegee Tool to remove embedded pet hair on carpets and upholstery.

WET VACUUMING



Use the hose inlet to vacuum up any mess, wet or dry.




The squeegee tool's wide cleaning path is ideal for removing liquid messes.

STAIN CLEANING


PRE-TREAT

WET STAIN CLEANING



First, suction up the liquid spill to prevent spreading the stain.


DRY STAIN CLEANING




Scrub stain back and forth using bristles or fins, then, turn on unit, tilt handle, and drag backwards to extract dry debris.



Spray cleaning solution to over-saturate, 2 inches from the stain. Let soak for a few minutes and spray again. Apply at least 2 layers of solution.




Scrub the stain with the bristles again with a back-and-forth motion.



For best suction be sure to tilt up (as shown) and apply pressure. Slowly pull backwards to extract the solution. **Pull back only.**

LET DRY, THEN REPEAT STEPS 2 TO 4 UNTIL THE STAIN FULLY FADES.

REVERSIBLE BRISTLES AND FINS



The Stain Tool has both bristles and hair-gripping fins. To use the fins, lift off the bristles, turn them over, then reinstall, with the fins on top.

TIPS:

- Use bristles for deep cleaning and to agitate stains.
- Use the Hair-Gripping Fins to remove hair from delicate or hairy surfaces and to prevent tangling.

MAINTENANCE

EMPTYING THE DUST CUP*



IMPORTANT:
Unplug the power cord before opening the lid.

Always empty the dust cup after vacuuming.

1. Open the lid, then lift out the dust cup by the sides. **DO NOT** grab the dust cup by the bag guides.
2. Dump debris into the trash and rinse out the dust cup with warm water.
3. Allow the dust cup to air-dry completely before reinstalling it back into the unit.

RINSE & READY: AUTOMATICALLY RINSING THE HOSE, LID, AND DUST CUP




Run a Rinse & Ready cleaning cycle after picking up any **wet** or **organic mess.**


1. Empty the dust cup. If using AnyBag Technology™, remove the bag and dispose of it.
2. Vacuum up 10 oz. of water from a cup, bowl, or other container.
3. Unplug the unit and open the lid. If any stubborn debris remains, follow the instructions in the Cleaning the Lid and Debris Screen section.


RINSING THE LID AND DEBRIS SCREEN

IMPORTANT: Unplug the power cord before opening the lid.


Rinse the lid and debris screen after picking up any **wet** or **organic mess.**








1. Open the lid to a 180-degree angle then pull out to detach it from the hinges.
2. Twist the debris screen counterclockwise and pull it out.
3. Rinse the lid and debris screen in the sink with warm water. Allow the lid and debris screen to air-dry completely before reinstalling.



4. To reinstall the debris screen, align the arrow in the lid with the arrow on the side of the debris screen and twist clockwise to the lock symbol to secure.
5. To reattach the lid, align the hinge connection points at 180 degrees and push until it snaps into place.

CLEANING THE ACCESSORIES



The Squeegee Tool* and Stain Tool should be cleaned after picking up any wet and organic mess.


1. Wash the accessories in the sink with warm, soapy water.
2. Allow accessories to air-dry completely.

NOTE: *DISHWASHER SAFE. STAIN TOOL IS NOT DISHWASHER SAFE.

NOTE: Included accessories differ by model.


CLEANING THE FILTERS

Regularly rinse and replace the filters to maintain your vacuum's suction power. The pre- and post-motor filters should be cleaned **once a month** and replaced **once a year** for optimal performance.




1. Lift out the foam filter by the handle, then pull out the felt filter.
2. Rinse both filters with cold water **ONLY. DO NOT** use soap. Allow both filters to air-dry completely before reinstalling.
3. Reinsert the felt filter first, followed by the foam filter.

IMPORTANT: DO NOT use soap when cleaning the filters.




1. Pull up on the post-motor filter cover to remove it, then lift out the post-motor filter.
2. Wash the filter gently with cold water **ONLY. DO NOT** use soap. Leave the filter out to air-dry completely before reinstalling it.
3. Reinsert the post-motor filter back into the opening, then place the cover over it and press down until it clicks into place.


CHECKING FOR BLOCKAGES



Remove any attached accessories and check the inlet for blockages.




Check the hose and opening in the unit for blockages.




Remove the debris screen and check for any blockages inside the openings in the lid. Wash the debris screen if needed.

STORAGE


Before storing the EveryMess™, empty the dust cup. Clean the unit and allow all parts to air-dry completely. Always store the EveryMess indoors.



Wrap the hose around the unit and clip it in place. (See Assembly section.)



Neatly wrap the power cord around the handle.



Use the cord clip on the plug to hold the wrapped cord securely in place.

TROUBLESHOOTING

⚠ **WARNING:** To reduce the risk of shock and unintended operation, turn off power before servicing.

ISSUE	WHAT IT MEANS	WHAT TO DO
Vacuum will not operate.	1. No power supply.	1. Check power cord, breakers, fuses.
	2. Faulty power cord.	2. Unplug and check the power cord. If damaged, contact a service center.
Fine dust comes out from the motor exhaust.	1. The pre- or post-motor filters are missing or need maintenance.	1. Follow the instructions in the Cleaning the Filters section.
No suction or low suction.	1. There are blockages in the accessory, hose, hose port, debris screen, or lid openings.	1. Unplug and check accessories, hose, hose port, debris screen, and lid openings for blockages.
	2. The pre- and post-motor filters need maintenance.	2. Follow the instructions in the Cleaning the Filters section.
	3. Dust cup is full.	3. Empty the dust cup.
	4. The bag was not inserted correctly.	4. Carefully follow the instructions in the AnyBag Technology™ section.
Motor noise.	1. Dust cup filled beyond Max Fill line and float valve has been activated.	1. Empty the dust cup.
	2. The pre- and post-motor filters need maintenance.	2. Take out the filters and clean with cold water only or install new filters.
Wet debris leaking.	1. Dust cup filled beyond Wet Debris Max Fill line.	1. Follow the instructions in the Maintenance section. Once complete, plug in and turn on the vacuum. Allow it to run for 2 minutes to dry out.
Vacuum is emitting air that smells bad.	1. The unit needs to be cleaned.	2. Follow the instructions in the Maintenance section.
Vacuum turns off while vacuuming.	1. Motor has overheated.	1. Shut the vacuum off, unplug, and let it sit for 60 minutes.

For all other issues, contact a service center.

PRINTED IN MEXICO / **Elbrd**: J.M
OBPN: VX100_IB_E_MP_Mv10_250806
SHNMDL: VX100_EGB / **SC**: 03-10-2026
8 1 4 1 0 0 7 3 5