Quick Setup Guide

Before using the TV, please read this guide carefully and keep it for future reference.

Disclaimer

Disclaimer: Subscriptions or other payments may be required to access content through some applications. Some or all of the included or downloaded application services in this Hisense device may not function depending on the Internet connection, local limitations of included applications or other reasons outside of Hisense's control. HISENSE EXPRESSLY DISCLAIMS RESPONSIBILITY FOR ANY APPLICATION SERVICE FROM FUNCTIONING AT ANY TIME, FOR CONTENT IN ANY APPLICATION SERVICE, FOR DISRUPTIONS OF SERVICE, LOCAL OR REGIONAL LIMITATIONS, WARRANTIES OF TITLE, NO INFRINGEMENT, AND FOR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. By purchasing this device, you accept such Disclaimer without any claim on Hisense at any time.

This Quick Setup Guide supports the following models:

55U6SF Pro / 55U6SFD Pro / 55U60SF Pro / 55U65SF Pro / 55U65SFB Pro / 55U65SFC Pro / 55U68SF / 55U6SF / 55U68SF Pro / 55U6SFM / 55U65SFM / 55U6SFM Pro / 55U65SFM Pro

65U6SF Pro / 65U6SFD Pro / 65U60SF Pro / 65U65SF Pro / 65U65SFB Pro / 65U65SFC Pro / 65U68SF / 65U6SF / 65U68SF Pro / 65U6SFM / 65U65SFM / 65U6SFM Pro / 65U65SFM Pro

75U6SF Pro / 75U6SFD Pro / 75U60SF Pro / 75U65SF Pro / 75U65SFB Pro / 75U65SFC Pro / 75U68SF / 75U6SF / 75U68SF Pro / 75U6SFM / 75U65SFM / 75U6SFM Pro / 75U65SFM Pro

85U6SF Pro / 85U6SFD Pro / 85U60SF Pro / 85U65SF Pro / 85U65SFB Pro / 85U65SFC Pro / 85U68SF / 85U6SF / 85U68SF Pro / 85U6SFM / 85U65SFM / 85U6SFM Pro / 85U65SFM Pro

100U6SF Pro / 100U6SFD Pro / 100U60SF Pro / 100U65SF Pro / 100U65SFB Pro / 100U65SFC Pro / 100U68SF / 100U6SF / 100U68SF Pro / 100U6SFM / 100U65SFM / 100U6SFM Pro / 100U65SFM Pro / 100U65QFM / 100U6QF

What's in the box

Your Hisense TV comes with the following items:

- TV
- Remote control
- base stands
- Power cord
- screws (55"/65"/75"/100")(139.7cm/165.1cm/190.5cm/254.0cm) (85")(215.9cm)

NOTE:
The accessories may be different from the list above due to different models, countries/ regions, please refer to the actual accessory bag.

IMPORTANT:
To prevent accidentally discarding items that came with your TV, be sure to **check ALL of the foam** in the carton box.

Disclaimer: *This Quick Setup Guide is intended as a general guideline to help you set up your TV. Images throughout this document are for illustrative purposes only and may differ from the actual product.*

NOTE: Accessory type and quantity may vary depending on the model.

Getting started

Step 1. Attach stand or mount

Before you start using your TV, attach your TV stand or mount it on the wall.

CAUTION:

- Disconnect the AC power cord before installing a stand or a wall mount bracket.
- The display on your TV is fragile. Make sure the TV screen is not scratched or damaged by hard objects or from pressure.
- After the installation is completed, make sure the TV is steady on a table or firmly attached to a wall mount, before removing all protective film, if any.

Attach the TV stand

55"/65"/75"/85"(139.7cm/165.1cm/190.5cm/215.9cm)

To attach the TV base stands to your TV:

1. Carefully place your TV on a clean, soft, flat surface.
2. Insert the TV base stands into the bottom slots on your TV.
3. Use the screws provided to secure each stand tightly.

55"(139.7cm)



65"/75"/85"(165.1cm/190.5cm/215.9cm)

Note: If your table is long enough to place the TV on top of, then insert the stands into the screw holes 'A' that are shown in the illustration. If your table is NOT long enough, then insert the stands into the screw holes 'B' that are shown in the illustration. Note that these two installation types cannot be mixed.

65"/75"(165.1cm/190.5cm)



85"(215.9cm)



100"(254.0cm)

NOTE: Three or more people are needed to install the TV. One person holds the TV to prevent tipping through the whole installation process.

1. One person holds the side of the TV, and the others remove the side cushions. Do not pinch the screen when hold the TV.
2. Insert the TV base stands into the bottom slots on your TV. Use the screws provided to secure each base stand tightly.
3. It takes three people to transport the TV. The weight of TV with base stands is 140.0 lbs (63.5 kg), the furniture where the TV is placed should be tough enough to support. Please make sure the width of the furniture is above 18.9 inches (480 mm).

Note: If your table is long enough to place the TV on top of, then insert the base stands into the screw holes 'A' that are shown in the illustration. If your table is NOT long enough, then insert the base stand into the screw holes 'B' that are shown in the illustration. Note that these two installation methods cannot be mixed.





Attach the wall mount bracket (not included)

55"/65"/75"/85"(139.7cm/165.1cm/190.5cm/215.9cm)

Before you begin the third-party manufacturer instructions, be sure to do the following things:

1. Place the TV on a clean, safe and cushioned surface.
2. Remove the TV stand if you have already attached it.
3. Place spacers (not included) in the corresponding bracket holes.

NOTE:Wall mount kit not included



Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

100"(254.0cm)

Before you begin the third-party manufacturer instructions, be sure to do the following things:

1. Keep the television vertically on the cushions. The TV weight without base stands is 136.7 lbs (62.0kg), make sure the wall is tough enough before hanging the TV.
2. Remove the TV stand if you have already attached it.
3. Place spacers (not included) in the corresponding bracket holes.



CAUTION:

- Follow instructions provided with the wall mount bracket. If it is not correctly mounted, the TV may fall and cause property damage or personal injury.
- When you attach the mount, be sure to use spacers (provided by the third-party manufacturer) between the TV and the bracket.
- To prevent internal damage to the TV and to ensure it is mounted securely, be sure to use fixing screws (not included) that are 9.5 - 11.5 mm (55"/65"/75"/85")(139.7cm /165.1cm/190.5cm/215.9cm) or 11.0 - 13.0 mm (100")(254.0cm) in length when measured from the attaching surface of the rear cover.



Wall mount hole pattern(mm)	200 × 300 (55")(139.7cm) 400 × 300 (65")(165.1cm) 500 × 400 (75")(190.5cm) 600 × 400 (85")(215.9cm) 800 × 400 (100")(254.0cm)
Wall mount screw size	M6 (55"/65"/75"/85")(139.7cm/165.1cm/ 190.5cm/215.9cm) M8 (100")(254.0cm)
Number of wall mount screw	4

- We do not recommend hanging the TV on a slanted wall, and when wall mounting make sure your television remains parallel to the wall and does not lean forward.



NOTE:

- If installed on a ceiling or slanted wall, or the television installed is not parallel to the wall, the television may fall and result in property damage or severe personal injury.
- If you have additional questions, please contact the wall mount manufacturer or the contact a service center.
- The diameter and length of the screws differ depending on the wall mount bracket model.

Step 2. Connect devices to your TV

Check to ensure that you have connected the right cables to the right ports securely. Loose connections can affect the quality of the picture image and color.

Back View



- **Power indicator**: The light is white in standby mode.
- **Power button (Standby/Source)**: When the TV is in standby mode, quick press the power button, and TV will be turned on.
  When the TV is on, quick press the power button to call up the menu: Quick press to change the selection.
  Long press to confirm your selection.
- **ANT/CABLE**: Connect an outdoor VHF/UHF antenna or cable.
- **HDMI**: Connect a High Definition Multimedia Interface (HDMI) cable from an external device.
- **USB**: Connect a USB device for browsing photos, music and movies. The rate of speed of USB 3.0 port 10 times faster than the USB 2.0 port. NOTE: You can still plug a USB 2.0 device into a USB 3.0 port; however, the rate of speed will not be as fast. USB 3.0 devices are also backwards compatible with USB 2.0 ports.
- **DIGITAL AUDIO OUT**: Connect an optical cable from an external digital audio system.
- **LAN**: Connect an Ethernet cable to access a network or the Internet. The TV also has a wireless connectivity feature.

Only for 100"(254.0cm):

- **AV IN**: Connect a composite video cable and left-right audio cables from an external AV device.
- **HEADPHONE /** : Connect headphones to hear audio from the TV. Headphones with microphones are not supported.
- **RESET**: Quick press to make the TV enter standby mode. Long press for 5 seconds to reset the TV back to the factory setting.

NOTE: The cables mentioned in this manual is not supplied with your unit.
NOTE: If you have any problem with your TV, please reset the unit using RESET button.
NOTE: The actual number of ports may have a different name or location.

Step 3. Get to know controls

Control on the TV

Front view



Introduction

Unlock the power of your Hisense with Fire TV built-in with the included Voice Remote with Alexa. Use your voice to watch live TV, search for titles, play music, switch inputs, control compatible smart home devices, and more. Switch inputs and go from watching your favorite TV show to the big game. You can also ask Alexa to check the weather, set timers and reminders, and more. Here are a few things that you can do with your voice on your Hisense Fire TV:

To do this on your Hisense FireTV…	Say this…
Live TV Controls For supported apps that feature live TV access, you can use Alexa to change channels. You can also use Alexa to navigate to the Channel Guide and the Live tab.	"Alexa, go to [channel / network] on [app]." "Alexa, watch [channel / network]." "Alexa, go to Channel Guide." "Alexa, go to Live."
Search for movies and TV shows Alexa can find movies and TV shows.	"Alexa, show me new [tv shows / movies]." "Alexa, find [title / genre]."
Alexa Requests See the responses on Hisense with Fire TV when you make an Alexa request	"Alexa, show me the weather." "Alexa, add x to my shopping list." "Alexa, play songs by [artist]." "Alexa, show me restaurants nearby."

Get your remote ready

The following table shows the buttons on your remote control and describes what they are for.



① **POWER**: Turn your TV on or off
② / ⓘ **Voice button**: Holding down the Voice Button to activate the microphone
③ **Select**: Confirm a selection or action
④ **D-pad** (up/down/left/right navigation buttons)
⑤ **Back**: Return to the previous place in the menu or app
⑥ **REWIND**: Rewind streaming video
⑦ **PLAY/PAUSE**: Pause or resume playback. This button is also used to activate and use the Live TV pause feature
⑧ **VOLUME +** / **VOLUME -**: Increase/decrease the volume
⑨ **Guide**: Open the Live TV Channel Guide
⑩ **MUTE**: Mute or un-mute the sound
⑪ **App buttons**: Quick access buttons to apps
⑫ **Microphone**: Receive the voice
⑬ **HOME**: Display your TV's Home screen
⑭ **MENU**: The button for the Menu
⑮ **FAST FORWARD**: Fast forward streaming video
⑯ **Channel ▲** / **Channel ▼**: Switch channel
⑰ **Quick Settings**: Activate quick settings overlay
⑱ **Recents**: Open a row of recently watched content so you can easily switch between contents

NOTE:

- The picture is only for reference. Check information according to the actual remote control.

NOTE: The remote control vary depend of model: The buttons on the remote control may have a different name or location than the remote control shows in this manual.



① **POWER**: Turn your TV on or off
② **App buttons**: Quick access buttons to apps
③ **Guide**: Open the Live TV Channel Guide
④ **D-pad** (up/down/left/right navigation buttons)
⑤ **Back**: Return to the previous place in the menu or app
⑥ **VOLUME +** / **VOLUME -**: Increase/decrease the volume
⑦ **MUTE**: Mute or un-mute the sound
⑧ **REWIND**: Rewind streaming video
⑨ **PLAY/PAUSE**: Pause or resume playback. This button is also used to activate and use the Live TV pause feature
⑩ **Microphone**: Receive the voice
⑪ **Input**: Change TV input source
⑫ **Apps**: Fast access to all applications
⑬ / **Voice button**: Holding down the Voice Button to activate the microphone
⑭ **Quick Settings**: Activate quick settings overlay
⑮ **Select**: Confirm a selection or action
⑯ **MENU**: The button for the Menu
⑰ **HOME**: Display your TV's Home screen
⑱ **Channel ▲** / **Channel ▼**: Switch channel
⑲ **FAST FORWARD**: Fast forward streaming video

NOTE:

• The picture is only for reference. Check information according to the actual remote control.

NOTE: The remote control vary depend of model: The buttons on the remote control may have a different name or location than the remote control shows in this manual.

Insert the batteries

Remove the battery door and insert the two AAA batteries into your Voice Remote with Alexa.

Important information about the remote and batteries

- **Discard batteries in a designated disposal area. Do not throw them into a fire.**
- **Remove old batteries immediately to prevent them from leaking into the battery compartment.**
- **If you do not intend to use the remote control for a long time, then remove the batteries.**
- **Battery chemicals can cause a rash. If the batteries leak, clean the battery compartment with a cloth. If chemicals touch your skin then wash it immediately.**
- **Do not mix old and new batteries.**
- **Do not mix alkaline, standard (carbon-zinc) or rechargeable (NiCd, NiMH, etc.) batteries.**
- **Do not continue using the remote if it gets warm or hot.**
- **Contact a service center.**

Using your cable set-top box or satellite receiver remote as a 'universal' remote

If you prefer to use your Cable Set-top Box or Satellite Receiver Remote as a 'universal' remote, then visit the Support page to view a list of the codes.

Step 4. Power on the TV

Connect your power cord to the TV and plug it into a power outlet. Press power button of the TV or the power button on the remote to turn on the TV.
Your TV will display a launch screen showing the Hisense logo.

Step 5. Complete the first-time setup

The first time you turn on your TV, there is a guided setup to make it easy to connect your TV to the Internet and complete the setup of your TV.
Your TV will automatically pair with your new Alexa Voice Remote.

1. If there are issues with the remote pairing, you will be prompted to pair your remote by pressing and holding the **HOME** button. If you continue to have issues, try re-inserting or replacing your batteries.
2. Select your Wi-Fi network from the list of Wi-Fi networks displayed on the screen.

NOTE:

• If your Wi-Fi network is password protected, please have your Wi-Fi network password handy to connect your TV to the Internet. If your network is hidden, select the **Join Other Network**. If required, enter your network password using the on-screen keyboard.

Step 6. Enjoy your TV!

Now that you've completed the first-time setup, your Home screen is your starting point for using your TV. Your Hisense TV provides a variety of entertainment options, so you'll always find something new. Use your TV to watch live channels, access video on demand to watch movies, and much more.

NOTE: Batteries not included

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

Troubleshooting

If you are having trouble with your TV, first try turning it off and on again. If this does not fix the problem, check the tips in the following table. If your problem is not listed in the following table, contact a service center.

Issues	Possible solutions
No sound or picture	• Check if the power cord is plugged into a powered AC outlet. • Press the Power button on the remote control to activate the unit from 'Standby' mode. • Check to see if the LED light is on or not. If it is, then the TV is receiving power.
I have connected an external source to my TV and I get no picture and/or sound.	• Check for the correct output connection on the external source and for the correct input connection on the TV. • Make sure you have made the correct selection for the input mode for the incoming signal.
When I turn on my TV, there is a delay for a few seconds before the picture appears. Is this normal?	• Yes, this is normal. The TV is initializing and searching for previous setting information.
The picture is normal but there is no sound	• Check the volume settings. • Check if 'Mute' mode is set to On.
Sound but no picture or black and white picture	• If the picture is black and white, unplug the TV from the AC outlet and replug it after 60 seconds. • Check that the Color is set to 50 or higher. • Try different TV channels.
The sound and/or picture is distorted or appears wavy	• An electric appliance may be affecting the TV. Turn off any appliances that are nearby and move it farther away from the TV. • Insert the power plug of the TV set into another power outlet.
The sound and picture is blurry or cuts out	• If using an external antenna, check the direction, position and connection of the antenna. • Adjust the direction of your antenna or reset or fine tune the channel.
A horizontal or vertical stripe appears on the picture and/or the picture is shaking	• Check if there is an appliance or electric tool nearby that is causing interference.
The plastic cabinet makes a "clicking" type of sound	• The 'click' sound can occur when the temperature of the television changes. This change causes the television cabinet to expand or contract, which makes the sound. This is normal and the TV is OK.
The remote control does not work	• Confirm that TV still has power and is operational. • Change the batteries in the remote control. • Check if the batteries are correctly installed.

Product Specifications

Model Name		55U6SF Pro / 55U6SFD Pro / 55U60SF Pro / 55U65SF Pro / 55U65S-FB Pro / 55U65SFC Pro / 55U68SF / 55U6SF / 55U68SF Pro / 55U6SFM / 55U65SFM / 55U6SFM Pro / 55U65SFM Pro	65U6SF Pro / 65U6SFD Pro / 65U60SF Pro / 65U65SF Pro / 65U65S-FB Pro / 65U65SFC Pro / 65U68SF / 65U6SF / 65U68SF Pro / 65U6SFM / 65U65SFM / 65U6SFM Pro / 65U65SFM Pro
Dimension (W × H × D)	Without Stand	48.3 × 28.1 × 2.6 inches (1 226 × 715 × 67 mm)	56.9 × 33.0 × 2.6 inches (1 445 × 837 × 66 mm)
	With Stand	48.3 × 29.8 × 11.7 inches (1 226 × 756 × 298 mm)	56.9 × 34.6 × 11.7 inches (1 445 × 878 × 298 mm)
Weight	Without Stand	29.8 lbs (13.5 kg)	40.8 lbs (18.5 kg)
	With Stand	30.2 lbs (13.7 kg)	41.2 lbs (18.7 kg)
TV Stand Width (W × D)		38.7 × 11.7 inches (984 × 298 mm)	49.1 × 11.7 inches / 15.2 × 11.7 inches (1 246 × 298 mm) / (386 × 298 mm)
Active Screen Size (Diagonal)		54.6 inches (138.7 cm)	64.5 inches (163.8 cm)
Audio Power		10 W × 2 + 20 W	10 W × 2 + 20 W
Screen Resolution		3840 × 2160	3840 × 2160
Power consumption		190 W	250 W
Power Supply		100-240 V~ 50/60 Hz	
Connectivity		Built-in Wireless feature (2x2, dual band)	
Receiving Channels		VHF: 2 - 13, UHF: 14 - 69, CATV: 1 - 125 Digital Terrestrial Broadcast (8VSB): 2 - 69 Digital cable (64/256 QAM): 1 - 135	
Wireless LAN Module specifications	Frequency Range	2.4-2.4835 GHz 5.15-5.85 GHz	
	Output Power (Max.)	2.4-2.4835 GHz 17 dBm 5.15-5.25 GHz 14 dBm 5.25-5.35 GHz(DFS Band) 14 dBm 5.49-5.71 GHz(DFS/TPC Band) 14 dBm 5.725-5.85 GHz(for Non EU) 14 dBm	
	Standards	IEEE 802.11 a/b/g/n/ac/ax	
Bluetooth Module specifications	Version/Profiles	Bluetooth 5.3	
	Frequency Range	2.4-2.4835 GHz	
	Output Power (Max.)	2.4-2.4835 GHz,Class1,6 dBm	
	Modulation Type	GFSK,π/4-DQPSK and 8-DPSK	
Tuner Type		Frequency synthesized	
Receiving System		Analog: NTSC Digital: ATSC/QAM	
Operating Temperature		41°F - 95°F (5 °C - 35 °C)	
Operating Humidity		20 % to 80 % non-condensing	
Storage Temperature		5 °F to 113 °F (-15 °C to 45 °C)	
Storage Humidity		10 % to 70 %, non-condensing	

Model Name		75U6SF Pro / 75U6SFD Pro / 75U60SF Pro / 75U65SF Pro / 75U65S-FB Pro / 75U65SFC Pro / 75U68SF / 75U6SF / 75U68SF Pro / 75U6SFM / 75U65SFM / 75U6SFM Pro / 75U65SFM Pro	85U6SF Pro / 85U6SFD Pro / 85U60SF Pro / 85U65SF Pro / 85U65S-FB Pro / 85U65SFC Pro / 85U68SF / 85U6SF / 85U68SF Pro / 85U6SFM / 85U65SFM / 85U6SFM Pro / 85U65SFM Pro
Dimension (W × H × D)	Without Stand	65.7 × 37.9 × 2.6 inches (1 668 × 963 × 67 mm)	74.4 × 42.8 × 2.6 inches (1 891 × 1 087 × 67 mm)
	With Stand	65.7 × 39.7 × 11.7 inches (1 668 × 1 008 × 298 mm)	74.4 × 44.7 × 16.9 inches (1 891 × 1 136 × 430 mm)
Weight	Without Stand	56.9 lbs (25.8 kg)	68.3 lbs (31.0 kg)
	With Stand	57.3 lbs (26.0 kg)	69.4 lbs (31.5 kg)
TV Stand Width(W × D)		54.3 × 11.7 inches / 16.4 ×11.7 inches (1 378 × 298 mm) / (416 × 298 mm)	58.5 × 16.9 inches / 24.0 × 16.9 inches (1 487 × 430 mm) / (610 × 430 mm)
Active Screen Size (Diagonal)		74.5 inches (189.3 cm)	84.5 inches (214.7 cm)
Audio Power		10 W × 2 + 20 W	10 W × 2 + 20 W
Screen Resolution		3840 × 2160	3840 × 2160
Power consumption		320 W	330 W
Power Supply		100-240 V~ 50/60 Hz	100-240 V~ 50/60 Hz
Connectivity		Built-in Wireless feature (2x2, dual band)	
Receiving Channels		VHF: 2 - 13, UHF: 14 - 69, CATV: 1 - 125 Digital Terrestrial Broadcast (8VSB): 2 - 69 Digital cable (64/256 QAM): 1 - 135	
Wireless LAN Module specifications	Frequency Range	2.4-2.4835 GHz 5.15-5.85 GHz	
	Output Power (Max.)	2.4-2.4835 GHz 17 dBm 5.15-5.25 GHz 14 dBm 5.25-5.35 GHz(DFS Band) 14 dBm 5.49-5.71 GHz(DFS/TPC Band) 14 dBm 5.725-5.85 GHz(for Non EU) 14 dBm	
	Standards	IEEE 802.11 a/b/g/n/ac/ax	
Bluetooth Module specifications	Version/Profiles	Bluetooth 5.3	
	Frequency Range	2.4-2.4835 GHz	
	Output Power (Max.)	2.4-2.4835 GHz,Class1,6 dBm	
	Modulation Type	GFSK,π/4-DQPSK and 8-DPSK	
Tuner Type		Frequency synthesized	
Receiving System		Analog: NTSC Digital: ATSC/QAM	
Operating Temperature		41°F - 95°F (5 °C - 35 °C)	
Operating Humidity		20 % to 80 % non-condensing	
Storage Temperature		5 °F to 113 °F (-15 °C to 45 °C)	
Storage Humidity		10 % to 70 %, non-condensing	

Model Name		100U6SF Pro / 100U6SFD Pro / 100U60SF Pro / 100U65SF Pro / 100U65SFB Pro / 100U65SFC Pro / 100U68SF / 100U6SF / 100U68SF Pro / 100U6SFM / 100U65SFM / 100U6SFM Pro / 100U65SFM Pro / 100U6QFM / 100U6QF
Dimension (W × H × D)	Without Stand	87.8 × 50.5 × 3.2 inches (2 229 × 1 282 × 82 mm)
	With Stand	87.8 × 51.9 × 18.9 inches (2 229 × 1 317 × 480 mm)
Weight	Without Stand	136.7 lbs (62.0 kg)
	With Stand	140.0 lbs (63.5 kg)
TV Stand Width(W × D)		68.3 × 18.9 inches / 35.2 × 18.9 inches (1 735 × 480 mm) / (895 × 480 mm)
Active Screen Size (Diagonal)		99.5 inches (252.7 cm)
Audio Power		15 W × 2 + 20 W
Screen Resolution		3840 × 2160
Power consumption		500 W
Power Supply		AC 120 V, 60 Hz
Connectivity		Built-in Wireless feature (2x2, dual band)
Receiving Channels		VHF: 2 - 13, UHF: 14 - 69, CATV: 1 - 125 Digital Terrestrial Broadcast (8VSB): 2 - 69 Digital cable (64/256 QAM): 1 - 135
Wireless LAN Module specifications	Frequency Range	2.4-2.4835 GHz 5.15-5.85 GHz
	Output Power (Max.)	2.4-2.4835 GHz 17 dBm 5.15-5.25 GHz 14 dBm 5.25-5.35 GHz(DFS Band) 14 dBm 5.49-5.71 GHz(DFS/TPC Band) 14 dBm 5.725-5.85 GHz(for Non EU) 14 dBm
	Standards	IEEE 802.11 a/b/g/n/ac/ax
Bluetooth Module specifications	Version/Profiles	Bluetooth 5.3
	Frequency Range	2.4-2.4835 GHz
	Output Power (Max.)	2.4-2.4835 GHz,Class1,6 dBm
	Modulation Type	GFSK,π/4-DQPSK and 8-DPSK
Tuner Type		Frequency synthesized
Receiving System		Analog: NTSC Digital: ATSC/QAM
Operating Temperature		41°F - 95°F (5 °C - 35 °C)
Operating Humidity		20 % to 80 % non-condensing
Storage Temperature		5 °F to 113 °F (-15 °C to 45 °C)
Storage Humidity		10 % to 70 %, non-condensing

Disclaimer: *All products, product specifications, and data are subject to change without notice to improve reliability, function, design or otherwise.*

Certification and compliance

NOTE: The following warnings only apply to products with such certification.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of [20] cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with radio frequency exposure limits set forth by the Innovation, Science and Economic Development Canada for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the device and the user or bystanders.
This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Declaration of conformity

Trade Name: Hisense
Model: 55U6SF Pro / 55U6SFD Pro / 55U60SF Pro / 55U65SF Pro / 55U65SFB Pro / 55U65SFC Pro / 55U68SF / 55U6SF / 55U68SF Pro / 55U6SFM / 55U65SFM / 55U6SFM Pro / 65U6SF Pro / 65U6SFD Pro / 65U60SF Pro / 65U65SF Pro / 65U65SFB Pro / 65U65SFC Pro / 65U68SF / 65U6SF / 65U68SF Pro / 65U6SFM / 65U65SFM / 65U6SFM Pro / 75U6SF Pro / 75U6SFD Pro / 75U60SF Pro / 75U65SF Pro / 75U65SFB Pro / 75U65SFC Pro / 75U68SF / 75U6SF / 75U68SF Pro / 75U6SFM / 75U65SFM / 75U6SFM Pro / 75U6SFM Pro / 85U6SF Pro / 85U6SFD Pro / 85U60SF Pro / 85U65SF Pro / 85U65SFB Pro / 85U65SFC Pro / 85U68SF / 85U6SF / 85U68SF Pro / 85U6SFM / 85U65SFM / 85U6SFM Pro / 85U65SFM Pro / 100U6SF Pro / 100U6SFD Pro / 100U60SF Pro / 100U65SF Pro / 100U65SFB Pro / 100U65SFC Pro / 100U68SF / 100U6SF / 100U68SF Pro / 100U6SFM / 100U65SFM / 100U6SFM Pro / 100U65SFM Pro / 100U65QFM / 100U6QF

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Dolby Vision IQ is a trademark of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012-2024 Dolby Laboratories. All rights reserved.

55"/65"/75"/85"(139.7cm/165.1cm/190.5cm/215.9cm)

Manufactured under license from DTS, Inc. and/or its affiliates. For patents, see https://xperi.com/dts-patents/. DTS, the DTS logo, DTS:X, the DTS:X logo, Virtual:X, and the DTS Virtual:X logo are trademarks or registered trademarks of DTS, Inc. and/or its affiliates in the U.S. and/or other countries. © DTS, Inc. and/or its affiliates. All rights reserved.

Manufactured under license from IMAX Corporation. IMAX® is a registered trademark of IMAX Corporation in the United States and/or other countries. For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS and the DTS logo are registered trademarks or trademarks of DTS, Inc. in the United States and other countries. © 2020 DTS, Inc. ALL RIGHTS RESERVED.

100"(254.0cm)

Manufactured under license from DTS, Inc. and/or its affiliates. For patents, see https://xperi.com/dts-patents/. DTS, the DTS logo, DTS:X, and the DTS:X logo are trademarks or registered trademarks of DTS, Inc. and/or its affiliates in the U.S. and/or other countries. © DTS, Inc. and/or its affiliates. All rights reserved.

Environmental Protection

This mark indicates that this product should not be disposed together with other domestic garbage, to avoid damage to the environment or human health due to the disposal of uncontrolled waste. Recycle it responsibly for promoting the sustainable reuse of material resources. To return your used device, please use the return systems available in your location.

©2026. All rights reserved.

Amazon, Fire, Alexa, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.

This television is a product of Hisense and is not manufactured by Amazon.com or any Amazon affiliate. Certain services and features are subject to change or withdrawal at any time, may not be available in all countries, areas and languages, and may require separate subscriptions.

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM

PRINTED IN MEXICO / **sc**: 09-08-2026 / **Elbrd**:J.M
Shnmdl: 65U65SFC Pro_B / Add: 75U65SFCPRO / **obpn**: 20204296

814100822