



CLEANING THE DUST CUP AND FILTER



1. With the dust cup open and the power off, press the filter release latch below the handle and pull out the filter housing.



M

ded operation, turn off

icator light on hand vacuum is


the brushroll.
var blockages if required.
ing and completely air-drying the

ing area rugs or rugs with delicately

ing the vacuum back on. Make sure
while in use.
a connection issue between the
ecting them.

, including blockages, battery
wing steps:
d vacuum. If recharging is needed,

Filter section).
es.
i to room temperature.




Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

QUICK START GUIDE

WHAT'S INSIDE

- (A) Hand Vacuum
- (B) Wand
- (C) PowerFins™ Floor Nozzle
- (D) WANDVAC® System Auto Empty Docking Station
- (E) Battery Pack
- (F) Duster Crevice Tool
- (G) Pet Multi-Tool




1. Slide the wand onto the neck of the floor nozzle until it clicks into place.
2. Slide the hand vacuum nozzle over the wand until it clicks into place.
3. Slide the Docking Station post onto the Auto Empty base until it clicks into place.
4. Place the dock on the floor near a wall outlet. Plug the power cord into the outlet.
5. Store cleaning accessories in the on-board accessory storage on the back of the dock post.

For proper operation, ensure all components are completely connected and clicked into place.

NOTE: Accessories may vary depending on the model.

ASSEMBLY



8 1 4 0 0 0 0 4 8

PRINTED IN MEXICO / SC: 07-17-2023

MODEL: WS642AE_B / Elbrd: M.C. / 0.25P / OBPN: N/A