

Please read this guide carefully before operating your unit and retain for future reference.

814000085


IN THE BOX C2

- A1. Espresso water tank lid
- A2. Espresso removable water tank
- A4. Antichlorine filter support
- A5. Filter-holder for drip coffee
- A6. Water fill compartment A7. Drip coffee warming plate
- A11. Frother


- **B4**. Display
- C1. Espresso portafilter
- C2. One-cup filter C3. Two-cups espresso filter
- C4. Filter for espresso pods
- C5. Coffee measure with presser
- C6. Permanent gold tone filter
- C7. Drip coffee carafe C8. Antichlorine filter

Note: The image shown here is for illustrative purposes only and may be subject to change. The actual number of accessories may vary depending on the model.

MACHINE SET UP



Remove water tank, fill with water and replace.



To turn on machine, push Espresso ON/OFF button on the left side.



Put espresso filter

into the espresso

portafilter.

When Espresso ON/OFF light is solid, press □|& button to start coffee delivery. Press □l& button to stop.



Wait until water is completely delivered then press espresso/ hot water □1& button to stop

Turn espresso portafilter

to the right to lock into

position.

Machine is now ready to work!

BREWING ESPRESSO



Use correct filter, note that the cups are marked on the bottom of the filter. Tamp the coffee.


1 CUP 2 CUPS




Attach portafilter holder in place into boiler



Turn portafilter holder to right to lock into position.










Brew 1 or 2 Espresso at one time.

BREWING CAPPUCCINO OR LATTE

Refer to previous section BREWING ESPRESSO for the espresso related part.



Prepare the coffee as described in the previous section. Brew in a larger cup. Press steam Fill 1/3 of the pitcher, button. 3.5 oz. for Cappuccino, 6 oz. for Latte.





Wait for the button light to turn on.





Turn the steam dial counter-clockwise to ON to release the steam.



When the desired level of foam is reached, turn the steam dial clockwise to OFF to stop the steam.

Pour the milk over the espresso and enjoy!

Tip for the BEST CAPPUCCINO

Use Whole or 2% Milk at Refrigerator Temperature (about 41F/5C)

BREWING DRIP COFFEE

For first use, brew a full carafe without using coffee grounds.




Remove coffee pot, fill with Open the water fill desired amount of water. compartment.





Pour water into water reservoir then replace coffee pot onto warming plate.



into filter reservoir.



Place gold tone coffee filter Add desired amount of coffee into coffee filter.





Press **ON** button to start brewing process.

DRIP COFFEE

Setting the CLOCK







To set minutes press the MIN button repeatedly until desired time is set.

Programing the AUTO Start



Press and hold **AUTO** button for 3 seconds until the display flashes.




Press HOUR and/or MIN buttons repeatedly until desired time is set.




To activate/deactivate auto program, press AUTO button.


MAINTENANCE



Remove the perforated Rinse filter unde water, not blocked.





If necessary clean with a pin make sure filter holes are or needle.




inner filter.

frother by rotating counterclockwise and pulling downwards.






from the steam tube by pulling it downwards.



nozzle with cloth and warm water.



Clean nozzle with warm running water and use a needle to clean the hole.

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as

part of the process.
For this item, water may be used during the refurbishing process and so; you may notice some condensation in the

recommended to rinse the water reservoir with fresh water prior to its first use.

W PRINTED IN MEXICO Elbrd: A.M SC: 11-01-2023 MODEL:COM530M OBPN:COM50M/COM530BM

