













LED LCD COMPUTER MONITOR

805001365





+ Depending on country

It is recommended that use the supplied components.



- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Make sure to use the supplied cable. Otherwise, this may cause the device to malfunction.



- Accessory type and quantity may vary depending on the model.
- The image shown here is for illustrative purposes only and may be subject to change.
- The cables mentioned in this guide is not supplied with your unit.
- The images shown here are for illustrative purposes only and may be subject to change, the actual descriptions of control panel and their locations may vary depending on the model.

PRINTED IN MEXICO / SC: 11/12/2024_TAB

Elbrd: J.E. / OBPN: *MBM67489685*

SHDML: 34WR50QC_B

805001365

