



43UP7100ZUF
43UP7670PUC


804006645



1



2




3




43UP71*

1



2




3




43UP76*

1



2



3



The images shown here are for illustrative purposes only and may be subject to change.



The cables mentioned in this guide is not supplied with your unit.




(Batteries Not Included)



The remote control vary depend of model: The buttons on the remote control may have a different name or location than the remote control shows in this manual.



A, B, C, D, E : mm (inches)
F, G : kg (lbs)



MODELS	A		B		C		D		E		F		F-G		Power consumption
43UP7100ZUF	973	973	611	611	187	187	572	572	85.0	85.0	8.1	8.1	8.0	8.0	110 W
	(38.3)	(38.3)	(24.0)	(24.0)	(7.3)	(7.3)	(22.5)	(22.5)	(3.3)	(3.3)	(17.8)	(17.8)	(17.6)	(17.6)	
43UP7670PUC	967	967	609	609	187	187	564	564	57.1	57.1	8.9	8.9	8.8	8.8	110 W
	(38.0)	(38.0)	(23.9)	(23.9)	(7.3)	(7.3)	(22.2)	(22.2)	(2.2)	(2.2)	(19.6)	(19.6)	(19.4)	(19.4)	
Power requirement										AC 120 V~ 50/60 Hz					



Read **Safety and Reference**.

Easy Setup Guide

Please read this manual carefully before operating your set and retain it for future reference.

⊕ : Depending upon model