

Please read carefully before operating your unit and retain for future reference.

804106607

NINJA[™] Foodi[™] NeverStick[™]

3½-QUART SAUCEPAN WITH GLASS LID

NOTE: CLEAN BEFORE USE

The NeverStick[™]
cookware that NEVER
sticks, chips, or flakes

All Range
Capable



Gas



Electric



Glass
Ceramic



Induction

**OVEN SAFE
TO 500°F**

**PFOA, CADMIUM
& LEAD FREE**

**DISHWASHER
SAFE**

**METAL UTENSIL
SAFE**

**INDUCTION
READY**

The difference
is in the degrees

[MAX MANUFACTURING TEMP]



30,000°F
Never sticks,
chips, or flakes

VS



900°F
Can rapidly
lose nonstick

NINJA FOODI NEVERSTICK AFTER 3 YEARS OF SIMULATED USE
VS A TRADITIONAL PAN AFTER 3 YEARS OF HOME USE

Accessory type and quantity may vary
depending on the model.

The images shown here are for illustrative purposes only and may be subject to change.

Use & Care: Ninja™ Foodi™ NeverStick™ cookware is dishwasher safe. Before first use, hand-wash your cookware in hot, soapy water, then rinse and dry thoroughly. For best cooking results, preheat the pan for 1 to 2 minutes using the heat setting you intend to use when cooking. Do not use aerosol cooking sprays. After cooking, allow cookware to cool completely before washing.

⚠ WARNING: CHOKING HAZARD: Protective separator clips between lid and pan are small parts and hazardous to children. Discard immediately when unpacking your cookware.

⚠ WARNING: BURN/SCALD HAZARD: Shorter handles, high cooking temperatures, and longer cooking times may cause handles to get hot. Exercise caution when cooking on the stovetop, and always use a potholder or oven mitt to prevent burns when removing from the oven.

⚠ WARNING: FIRE HAZARD: Do not leave pots and pans unattended while cooking. Never let a pot or pan boil dry.

⚠ CAUTION: Birds are sensitive to cooking fumes and burned food fumes. These fumes can be caused from overheating your cookware or from burning food, and can be hazardous or fatal to birds. Never keep pet birds in your kitchen.

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

