

PowerXL™
products that excel

BOOST BLENDER PLUS™

“Recipe book
not included”



814100100

Owner's Manual

Save These Instructions - For Household Use Only

When using electrical appliances, basic safety precautions should always be followed. Do not use the **PowerXL™ Boost Blender Plus™** until you have read this manual thoroughly.



BEFORE YOU BEGIN

The **PowerXL™ Boost Blender Plus™** will provide you many years of delicious and healthy blending. But before you begin, it's very important that you read this entire manual, making certain that you are totally familiar with this appliance's operation and precautions.

Appliance Specifications

Rated Power

396 watts

Blending Jar Max. Capacity

48 oz

PRINTED IN MEXICO

Elbrd: J.M. SC: 06-20-2024

OBPN: PXL-BBP_IB_WM_ENG_V1_220422

SHDML: BL1600XLBG_B

814100100



IMPORTANT SAFEGUARDS

⚠ WARNING

PREVENT INJURIES! - CAREFULLY READ ALL INSTRUCTIONS BEFORE USE!

When using electrical appliances, always follow basic safety precautions to reduce the risk of fire, electric shock, and/or injury, including the following:

1. Read all instructions.
2. To protect against risk of electrical shock, do not put blender base, cord, or plug in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Turn the appliance OFF, then unplug from the outlet when not in use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
5. Avoid contacting moving parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or is dropped or damaged in any manner. If this happens, contact service center. This appliance has important markings on the plug blade. The attachment plug or entire cordset (if plug is molded onto cord) is not suitable for replacement. If damaged, the appliance must be replaced.
7. The use of attachments, including canning jars, not recommended or sold by the appliance manufacturer may cause fire, electric shock or injury.
8. Do not use outdoors.
9. Do not let the plug or cord hang over the edge of table or counter.
10. Do not place on or near a hot gas or electric burner or in a heated oven.
11. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
12. Blades are sharp. Handle carefully.
13. To reduce the risk of injury, never place blade assembly on base without the jar properly attached.
14. Always operate blender with cover in place.
15. Do not blend hot liquids.
16. Do not use appliance for other than intended use.
17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
18. Children should be supervised to ensure that they do not play with the appliance.

**SAVE THIS INSTRUCTION MANUAL.
FOR HOUSEHOLD USE ONLY**

SAFETY FEATURES

Polarized Plug (120v Models Only)

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Tamper-Resistant Screw


WARNING: This appliance is equipped with a tamper-resistant screw to prevent removal of the base outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

Electrical Cord

1. A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
2. Extension cords are available and may be used if care is exercised in their use.
3. If an extension cord is used,
 - a) The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance,
 - b) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - c) The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

NOTE: If the power cord is damaged, contact service center.

Parts & Accessories



1. Dual-Opening Lid
2. PerfectPour™ Spout
3. Ingredient Slot
4. Blending Jar
5. Handle
6. Jar Base/ Blade Assembly
7. Base
8. Off Button
9. Speed Buttons
10. Pulse Buttons

• Accessory type and quantity may vary depending on the model.

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

Instructions for Use

Before First Use

- Remove all packing material, from the product, and the plastic band around the plug.
- Remove and save literature.
- Wash all removable parts as instructed in the "Cleaning & Storage" section of this manual.

Blender Jar Assembly

- Turn the blending jar upside down and place it flat on a counter top or work surface.
CAUTION: The blades are sharp. Handle carefully.
- Place the jar base/blade assembly onto the jar and rotate clockwise until it is tight.
- Turn the assembled jar right side up.
- Place the lid on the blending jar.
NOTE: Make sure the ingredient slot is closed.
- Unwrap the power cord from the storage area under the base.
- Place the jar assembly on the base and turn clockwise to lock into place. The marks on the jar assembly will align with the marks on the top edge of the base.
- The blender is now ready for use.

Using the Boost Blender Plus™

IMPORTANT: The appliance should always have its lid in place when in use.
CAUTION: Do not place the blender jar onto the base when the motor is running.

- Make sure the appliance is OFF.
- Place the food to be blended into the jar. For best results, place ingredients in jar in the following order: liquids, powders, soft foods, hard foods, ice.
NOTE: You must always add a liquid before blending.
- Place the lid on the jar. Make sure the pour spout and ingredient slot are closed.
- Plug the power cord into an electrical outlet.
NOTE: When in use, do not leave the blender unattended. When using hard foods, such as ice or cheese, keep one hand on the lid to keep the blender in place.
- Select the speed that best suits your desired task (see the "Speed Chart" section).
- When blending thick mixtures, such as smoothies and milkshakes, press the high pulse

- button for several seconds and then release. Repeat until the food has desired consistency.
NOTE: Use the pulse function for no more than five seconds at a time, allowing the blender to rest briefly between each pulse—no more than two minutes total. This helps break up the ice and distribute the ingredients.
- Open the ingredient slot to add ingredients while the blender is running. Drop ingredients through the opening. If air pockets or clogs form in the mixture, press down on the lid to break them up. This lowers the jar and raises the blades within the mixture (see the "Using the Boost Function" section).
IMPORTANT: Do not remove the lid while the blender is running.
 - When finished, press the off button. Make sure the blades have completely stopped before attempting to remove the blending jar from the base.
 - To remove the jar, grasp the handle, turn jar counterclockwise, and lift up. **NOTE:** Always unplug the appliance when not in use.


Using the Boost Function

The blades can reach up through an air pocket into the ingredients above. This allows the blending vortex to reestablish. If an air pocket is persistent, add liquid.

NOTE: The images shown here are for illustrative purposes only and may be subject to change, the actual descriptions of control panel and their locations may vary depending on the model.



Press down on the lid to raise the blade height and clear jams.



Speed Chart

Speed	Functions	Usage
LOW	Mix Milkshake Easy Clean	<ul style="list-style-type: none"> Prepare sauces and remove lumps from gravies. Blend milkshakes and malts. Blend a drop of soap with hot water for quick cleaning.
HIGH	Puree Icy Drink Smoothie	<ul style="list-style-type: none"> Puree fruits and vegetables. Liquefy frozen drinks. Prepare smoothies.
LOW PULSE	Dice Chop Salsa Crumb	<ul style="list-style-type: none"> Chop fruits, vegetables, and cooked meats. Create salsas. Make cookie, cereal and bread crumbs.
HIGH PULSE	Crush Ice	<ul style="list-style-type: none"> Crush ice and frozen food.

Tips

- Cut food into pieces no larger than ¾ inch for use in the blender.
- When blending several different kinds of ingredients, always add liquid ingredients first.
- When making breadcrumbs, make sure the blender jar is completely dry.
- When using the pulse function, use short bursts. Allow the blades to stop rotating between pulses. Do not use the pulse function for more than 1 ½ minutes.
- Use the high pulse button when crushing ice cubes or anything frozen. For efficient ice crushing, repeatedly press down and release the high pulse button and the lid in unison.
- It is helpful to begin the blending process on the lowest speed and then increase to a higher speed if necessary.
- To stop blending at any time, press the off button.
- Do not store foods in the blending jar.
- Do not overfill the blender (the blender is more efficient with less rather than more).
- Do not run the blender for more than 1 ½ minutes at a time. Scrape down the sides of the blending jar if necessary and continue blending.
- Do not use if the blending jar is chipped or cracked.
- It is not recommended to use your blender to beat egg whites, mix dough, mash potatoes, or grind meats.
- Refrain from tapping or banging the jar base/blade assembly on the counter.

Do Not Place Any Of The Following In The Blender:

- Large pieces of frozen foods
- Tough foods, such as raw turnips, sweet potatoes, and potatoes
- Bones
- Hard salami or pepperoni
- Boiling liquids (cool for 5 minutes before placing in the blending jar)

Cleaning & Storage

Clean the appliance after each use.

- Before cleaning, turn off and unplug the appliance.
- Use the handle to lift the blending jar off of the base.
- Remove jar base/blade assembly by turning it counterclockwise until loose.
CAUTION: The blades are sharp. Handle carefully.
- Combine 1 cup hot water and a drop of liquid dish soap in the blending jar. Cover and blend for about 30 seconds while pressing down on the lid a few times to clean the seal mechanism.

- Disassemble and wash the removable parts by hand or in the dishwasher. Place the jar on the bottom rack and the rest of the parts on the top rack only.

Important:

- Do not place the jar parts in boiling liquids.
- Do not immerse the base in liquid. Wipe the base with a damp cloth and dry thoroughly.
- Remove stubborn spots by rubbing with a damp cloth and nonabrasive cleaner.
NOTE: Do not use rough scouring pads or cleansers on the parts or finish.