

KEURIG

Let's get brewing.

K·Café

SMART™

SINGLE SERVE COFFEE MAKER

Quick Start Guide

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:



- READ ALL INSTRUCTIONS.**
 - For household use only.
 - Do not use distilled water.
 - Scalding may occur if the handle is opened during the brewing process.
 - Do not touch hot surfaces. Use handles or knobs.
 - To protect against fire, electric shock, and injury to persons, do not immerse appliance, cord, or plugs in water or other liquid.
 - Close supervision is necessary when any appliance is used by or near children.
 - Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
 - Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
 - The use of accessory attachments not authorized by the appliance manufacturer may result in fire, electric shock, or injury to persons.
 - Do not use outdoors.
 - Do not let cord hang over edge of table or counter, or touch hot surfaces.
 - Do not place on or near a hot gas or electric burner, or in a heated oven.
 - Always attach plug to appliance first (if not permanently attached), then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
 - Do not use appliance for other than intended use.
 - Use brewer in upright position only. Allow brewer to cool (90 minutes) prior to turning it in any position other than upright.
 - Do not immerse brewer in water.
 - Only use K-Cup® pods intended for this appliance. If the pod does not fit, do not force it into the appliance.
- WARNING:** There is extremely hot water under pressure in the K-Cup® pod holder during the brew process. To avoid risk of injury, do not lift the handle or otherwise open the handle during the brew process.
 - CAUTION:** There are sharp needles that puncture the K-Cup® pod, five above the K-Cup® pod holder and one in the bottom of the K-Cup® pod holder. To avoid risk of injury, be aware of the needle locations.
 - POWER CORD INSTRUCTIONS:**
 - A short power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
 - Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
 - If a long detachable power-supply cord or extension cord is used:
 - The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance.
 - If the appliance is of the grounded type, the extension cord should be a grounding type 3-wire cord.
 - The longer cord should be arranged so that it will not drape over the countertop or tabletop, where it can be pulled on by children or tripped over.
 - CAUTION: HOT COCOA/OTHER NON-COFFEE PODS:** Immediately after using a hot cocoa/other non-coffee pod, run a hot water brew cycle without a pod to avoid the possibility of clogging the exit needle. DO NOT assume the next user will do this.

FCC Compliance Notice Contains FCC ID: 2AXNJ-JSOM-XP
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This device complies with applicable sections of Part 15 of the FCC Rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna or product suffering interference.
- Increase the separation between this equipment and receiver/product.
- Connect this equipment to an outlet on a circuit different from that to which the receiver/other product is connected. Consult Keurig for troubleshooting or if further help is needed.

SAVE THESE INSTRUCTIONS.

For detailed brewer cleaning and maintenance instructions, videos, and the full Use & Care Guide, visit support.keurig.com.

- WARNING:** Keep all plastic bags away from children.
- CAUTION:** Keurig recommends using only Keurig® My K-Cup® Reusable Coffee Filter and Keurig® K-Cup® pods in this appliance. If the reusable coffee filter or pod does not fit, do not force them into the appliance. The use of non K-Cup® pods or non-Keurig® accessories may cause coffee maker malfunction or injury.
- WARNING:** Used K-Cup® pods should be removed from the pod holder after brewing, or as part of the daily cleaning routine.



Before You Brew



Rinse & Fill

Rinse reservoir with fresh water and fill to the **Max** fill line. If you have a Keurig® Water Filter, install it now.

NOTE: Do not use distilled water.

Clean the Frother

Remove the lid and whisk from inside the frother. Wash the interior of the frother, lid, and whisk with warm, soapy water. Dry all parts thoroughly using a soft, nonabrasive cloth, then reassemble.

NOTE: Frother is not dishwasher safe. Do not submerge frother in water. Only use nonabrasive cleaning materials to prevent damage to the inner surface of the frother. Dry interior of frother and base with a soft cloth after cleaning.

Cleansing Brew

Press any button to **power on**.

Place a large mug (10 oz minimum) on the drip tray. Follow the instructions on the brewer screen to perform a cleansing brew.

Do not remove the water reservoir once the BREW button has been pressed until the brew has completed. The one-time setup process is now complete, and you are ready to brew!

The image shown here is for illustrative purposes only and may be subject to change.

Brew Your First Cup



Place Mug & Insert Pod

Lift the handle and place a K-Cup® pod in the K-Cup® pod holder.

Lower the handle completely to close the lid.

Do not remove the foil lid on the K-Cup® pod.

NOTE: Remove the drip tray to accommodate a travel mug up to 7" tall.

Brew & Enjoy!

Enjoy the **Signature Brew** or customize your settings, choose a size, and press the blinking **BREW** button. Once the brew is completed, dispose of the used K-Cup® pod.

Brewing is complete, when the **"Enjoy"** screen is displayed.

CAUTION: While brewing, there is extremely hot water in the K-Cup® pod holder. To avoid injury, do not lift the handle during the brewing process.

Brew a Café Beverage

Go to **Café Creations** in the app for access to a full menu and easy, step-by-step instructions.

1. Froth Milk

Fill frother to the **Min** line for cappuccino or **Max** line for latte. Attach lid and place on base.

Press the button to choose a setting:

- Cold Froth
- 1, 2, 3 Hot Froth

The higher the number, the more froth.

Press the K to begin frothing. Frothing is complete when the button is no longer illuminated.



2. Queue Your Brew

Press the **SHOT** button to choose a 2 oz or 4 oz shot, then press the blinking **BREW** button.

When frothing is completed, the shot will automatically brew next.

NOTE: The brewer cannot brew coffee and froth milk at the same time.

3. Create Your Café Beverage

When shot is complete, pour or spoon the frothed milk over your shot of coffee.

• Accessory type and quantity may vary depending on the model.

• The images shown here are for illustrative purposes only and may be subject to change, the actual descriptions of control panel and their locations may vary depending on the model.

Tips

For best results, we recommend one-time use with our K-Cup® pods. A twice-brewed pod won't provide full flavor, and if the pod holder isn't lined up with the original holes, it can cause an overflow of water and coffee grounds.

For the best coffee experience, we recommend a cleansing brew after coffee before brewing other types of beverages or a hot water brew.

Milk Matters! Different types of milk produce different results. Depending on which milk you use, here's what you can expect:

- **Fat-Free/Skim Milk:** Easy to froth, it creates a light, airy foam.
 - **2% Milk:** Easy to foam like skim milk, but with a creamier consistency.
 - **Whole Milk:** Higher fat content creates the richest-tasting foam.
 - **Dairy Alternatives:** Results will vary depending on type; loses its bubbles quicker than dairy milk.
- Use frother setting 3 for best results.**
- **Lactose-Free Milk:** Less reliable, due to its different properties.

Not All Brands Are the Same
Even individual brands of milk can froth differently, so experiment with different brands to see what works best.

Caring for Your Frother

Clean immediately after each use and before first use. Frother is not dishwasher safe or microwavable.

NOTE: Do not under- or overfill frother. Do not operate before adding milk.

To Clean:

1. Remove frother from the base, remove silicone ring from lid, and remove the whisk.
 2. Wash the inner frother, silicone ring, lid, and whisk with warm, soapy water. Use a soft, nonabrasive material to prevent damage.
 3. Dry all parts thoroughly and reassemble for next use.
- NOTE:** Do not put the frother or frother parts into the dishwasher. Do not immerse the frother in water for cleaning. Do not wash the bottom part of the frother, which contains the electrical plug.

Caring for Your Brewer

Keep your brewer running at peak performance by following the recommended maintenance schedule:

Frequency	Product	Benefit
Weekly	Keurig® Rinse Pods	A simple, fast, and convenient way to reduce flavor carry-over between brews.
Every 2 months	Keurig® Water Filters	Keep your water fresh and clean for a great-tasting cup of coffee every time.
Every 3 months or when the Descaler notification turns on	Keurig® Descaling Solution	Remove calcium deposits, or scale, that can build up inside a brewer over time; this can help extend the life of your brewer (when used regularly).

Periodically hand-wash the water reservoir and lid and drip tray with warm, soapy water and rinse clean. Do not use any vinegar-based cleaning products to clean the outside of your brewer.

CAUTION: Parts are not dishwasher safe.

NOTE: Do not dry the inside of the water reservoir with a cloth, as lint may remain.

ATTENTION!

This brewer is only compatible with newly designed Keurig® My K-Cup® Universal Reusable Coffee Filters. Do not attempt to use any other reusable filter or previous versions of Keurig® My K-Cup® Universal Reusable Coffee Filter; may cause damage to brewer.

Visit keurig.com/recyclable to learn more.



Coffeehouse taste in your own home.

NOTE: In order to ensure the highest possible standard for refurbished items, all units are thoroughly inspected as part of the process. For this item, water may be used during the refurbishing process and so; you may notice some condensation in the water reservoir. It is recommended to rinse the water reservoir with fresh water prior to its first use.

The image shown here is for illustrative purposes only and may be subject to change.

The images shown here are for illustrative purposes only and may be subject to change, the actual descriptions of control panel and their locations may vary depending on the model.

The image shown here is for illustrative purposes only and may be subject to change.

REFURBISHED PRODUCT LIMITED THIRTY DAY WARRANTY

The **Refurbished Product Service Center** offers the following WARRANTY to the ORIGINAL purchaser of a product which we have refurbished.

This product that has been refurbished is warranted against any electronic or mechanical defects for a period of THIRTY DAYS from the date of the original purchase by the consumer. Since this unit was sold as a refurbished item, the warranty does not apply to any cosmetic appearance items such as scratches. Should a defect occur, the **Refurbished Product Service Center** will repair or, at its option, replace defective unit/parts with new or rebuilt materials without charge for either parts or labor. Replacement unit/parts will be warranted for the remaining portion of the original warranty period.

This warranty does not cover installation or damage from accident, misuse, abuse, improper wiring, incorrect voltage, operating the unit against the instructions in the owner's manual or any product which has been opened, altered, or tampered with.

This warranty does not cover costs for removal and or installation of the unit for repair. Under no circumstances shall the service center be liable for any special, incidental or consequential damages or for any other expenses incurred by reason of use or sale of this product. This warranty is in lieu of any other warranties expressed or implied warranty of merchantability of fitness for particular use or otherwise.

This warranty gives the consumer specific legal rights and they may also have other rights which vary from State to State. Some States do not follow the exclusion or limitation of incidental or consequential damages, hence the above exclusion and limitations may not apply.

Refurbished Product Service Center
13225 Marquardt Avenue Santa Fe Springs, CA 90670

WARRANTY REPAIR INFORMATION

If you need service on your unit during the 30 day warranty period; please go to www.ConsumerServiceRefurbish.com or call the Refurbished Product Service Center at 562-946-3531 to obtain the required claim number. Once you obtain your claim number, pack the unit properly (the original carton is ideal for this purpose) along with a copy of your purchase receipt.

Send the unit freight prepaid and insured to:

Refurbished Product Service Center,
Att: Customer Service Department 13225 Marquardt Avenue Santa Fe Springs, CA 90670

Your unit will be promptly exchanged and returned to you. We will refuse to accept delivery of the returned unit unless the assigned claim number appears on the outside of the shipping carton.

Owner's Information
(Keep for your permanent records)

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP CODE: _____

PHONE: _____ E-MAIL: _____

MODEL: _____ SERIAL NO.: _____

8 0 4 1 0 0 2 3 2 PRINTED IN MEXICO SC: 06-24-2024 ELBRD: J.E.

 MODEL:K27KCSBK_B OBPN: AW000000562 REV A