
LAYERING GUIDE

Get a perfect blend every time by stacking your ingredients in the right order. **Always start with liquid**, and be sure to leave some room at the top.



Pro tip: For tougher blends, hold your BlendJet upside down, then turn it on and slowly flip it right-side up.

DELICIOUS ON DEMAND

Meet the JetPacks

Make your own Smoothie, Protein Smoothie or Latte in seconds.



Simply pour a JetPack into your BlendJet with milk or water, plus optional ice, and blend!

Proudly made in California, JetPacks are loaded with healthy, plant-based ingredients to help you *power through your day*.



Gluten Free



Non-GMO



No Artificial Flavors



Vegan



Good Source of Fiber



No Artificial Sugar

Oblendjet

THE NEXT-GEN BLENDER



Take your cordless, portable blender anywhere to shake up your routine.

Make a smoothie, shake, latte or cocktail in 20 seconds, anywhere.

Accessory type and quantity may vary depending on the model.

• The image shown here is for illustrative purposes only and may be subject to change.

YOUR FIRST BLEND



Charge your BlendJet with the included USB cable for 1 hour or until you see a solid blue circle.



Ensure the arrows on the back of the jar & base are closely aligned. Power button will flash white.



Clean your BlendJet by blending water with a drop of soap, then rinse.

(Deep clean as needed – visit BlendJet.com/Guide for video demo).



Add liquid first, then throw in your solids. Leave a little room at the top.



Tighten the lid & press the power button to blend for one 20-second cycle.

Repeat as needed for thicker blends.



Enjoy your blended creation & clean immediately after each use.

POWERING UP

BlendJet takes about 1.5 hours to fully charge & lasts for 15+ blends. Battery life is visible while charging.

Do not charge your BlendJet when it's wet.



Zero Charge Circle flashes red & purple.



50% Charge Circle is half purple, half blue.



Full Charge Circle is solid blue.

Circle will turn purple (vs. blue) while blending to indicate low battery.

TROUBLESHOOTING



Flashing Red

Jar isn't aligned with base.

Loosen jar from base & screw it back in until arrows on back of jar & base are closely aligned, and the power button flashes white instead of red.



Solid Red Blades are blocked.

Turn upside down & start blending, then turn right-side up again so your ingredients hit the blades at full speed.

A MODE FOR EVERY MOOD



Blend Mode

Perfect for smoothies, shakes & mixed drinks.

Press power button once to start a 20-second blend cycle, or press it again to stop mid-cycle.



Pulse Mode

Perfect for quacamole, salsa & hummus.

To enter Pulse Mode, double-press power button. Blue lights will flash left to right 3 times & the swirl will stay illuminated while Pulse Mode is active. Press & hold power button repeatedly to pulse. Pulse Mode will end after 5 seconds of inactivity.



Lock Mode
Perfect for sipping & travel.

To lock, you must be in Blend Mode.
Secure lid, then hold down power button until purple circle flashes 3 times.
To unlock, hold down power button until blue circle flashes 3 times.

Accessory type and quantity may vary depending on the model.

• The image shown here is for illustrative purposes only and may be subject to change.

